

[Manuals.plus](#) /

› [CAMPINGAZ](#) /

› Campingaz Class 3 LBD Gas Barbecue Instruction Manual

CAMPINGAZ 3000005043

Campingaz Class 3 LBD Gas Barbecue Instruction Manual

Model: 3000005043

1. INTRODUCTION

Thank you for choosing the Campingaz Class 3 LBD Gas Barbecue. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new gas barbecue. Please read these instructions carefully before using the appliance and retain them for future reference.



Image 1.1: The Campingaz Class 3 LBD Gas Barbecue with its lid open, revealing the grill and griddle cooking surfaces.

The Class 3 LBD barbecue is designed for outdoor cooking, featuring three stainless steel burners and a cooking surface made of double-enameled steel. It incorporates the patented InstaClean system for simplified cleaning and a Piezo ignition system for quick startup.

2. SAFETY INFORMATION

WARNING: Failure to follow these instructions could result in fire, explosion, or burn hazard, which could cause property damage, personal injury, or death.

- This appliance is for outdoor use only. Do not operate indoors.

- Read all instructions before assembly and use of the appliance.
- Keep children and pets away from the barbecue at all times.
- Ensure the barbecue is placed on a stable, level surface.
- Do not store or use gasoline or other flammable liquids or vapors in the vicinity of this or any other appliance.
- Always connect the gas cylinder outdoors in a well-ventilated area.
- Check for gas leaks before each use. Use a soapy water solution; never use a flame.
- Do not obstruct the flow of combustion and ventilation air.
- Wear protective gloves when handling hot components.
- A hose and pressure regulator are not included and must be purchased separately. Ensure they are compatible with your gas cylinder and local regulations.

3. PACKAGE CONTENTS

The Campingaz Class 3 LBD Gas Barbecue package includes the following main components:

- Barbecue unit with 3 stainless steel burners
- Lid with integrated thermometer
- Double-enameled steel cooking surface (grill and griddle configuration)
- Steel trolley with integrated spice basket
- Two foldable side shelves
- Two wide wheels
- Warming rack
- Assembly hardware and instructions (refer to separate assembly guide for detailed steps)

4. ASSEMBLY INSTRUCTIONS

Assembly of the Campingaz Class 3 LBD Gas Barbecue is required. Please follow the detailed assembly guide provided in the product packaging. Ensure all components listed in Section 3 are present before beginning assembly.

1. Unpack all components and verify against the parts list in the separate assembly manual.
2. Assemble the steel trolley frame according to the instructions, ensuring all screws are securely tightened.
3. Attach the two wide wheels to the trolley for mobility.
4. Mount the main barbecue body onto the assembled trolley.
5. Install the three stainless steel burners and connect the gas manifold.
6. Place the double-enameled steel cooking surfaces (grill and griddle) and the warming rack.
7. Attach the foldable side shelves and the lid.
8. Once assembled, perform a leak test as described in the safety section before connecting to a gas supply.



Image 4.1: The Campingaz Class 3 LBD Gas Barbecue in an outdoor setting, demonstrating its use for cooking.

5. OPERATING INSTRUCTIONS

5.1 Connecting the Gas Cylinder

This barbecue operates on a standard gas cylinder. A hose and pressure regulator are not included and must be purchased separately. Ensure the regulator is compatible with your gas cylinder and meets local safety standards.

1. Ensure all burner control knobs are in the OFF position.
2. Connect the regulator to the gas cylinder valve.
3. Connect the hose from the regulator to the barbecue's gas inlet.
4. Tighten all connections securely.
5. Perform a leak test using soapy water on all connections. Bubbles indicate a leak. If a leak is detected, turn off the gas supply immediately and re-tighten connections. Do not use the barbecue if a leak persists.

5.2 Piezo Ignition

The barbecue features a Piezo ignition system for easy startup.

1. Open the gas cylinder valve.
2. Open the barbecue lid.
3. Push in and turn one burner control knob to the HIGH position.
4. Press and hold the Piezo ignition button. You should hear a clicking sound and see a flame ignite.
5. If the burner does not ignite within 5 seconds, turn the control knob to OFF, wait 5 minutes, and repeat the ignition process.
6. Once one burner is lit, you can ignite other burners by turning their control knobs to HIGH.

5.3 Cooking and Temperature Control

The barbecue's lid includes an integrated thermometer to monitor internal cooking temperature. Adjust the burner control knobs to achieve desired heat levels.

- **Direct Cooking:** Use for searing, grilling steaks, burgers, and other foods that cook quickly.
- **Indirect Cooking:** Turn off the burner directly under the food and use adjacent burners for roasting larger items.
- **Culinary Modular System (Optional):** The center of the cooking grid can be removed to accommodate optional accessories such as a pizzasteen, wok, or paellaschaal (sold separately).



Image 5.1: The Campingaz Class 3 LBD Gas Barbecue with its lid closed, highlighting the control knobs and foldable side shelves.

5.4 Shutting Down the Barbecue

1. Turn all burner control knobs to the OFF position.
2. Close the gas cylinder valve.
3. Allow the barbecue to cool completely before cleaning or covering.

6. MAINTENANCE AND CLEANING

6.1 InstaClean System

The patented InstaClean system simplifies the cleaning process. After the barbecue has cooled, you can easily disassemble the tank components for washing.

1. Ensure the barbecue is completely cool and the gas supply is off.
2. Remove the cooking grids and warming rack.
3. Carefully remove the internal tank components (e.g., firebox liners, grease tray).
4. These components are designed to be dishwasher safe. Place them in your dishwasher for thorough cleaning.
5. Once clean and dry, reassemble the components in reverse order.

6.2 General Cleaning and Care

- Clean cooking grids after each use with a grill brush.
- Wipe exterior surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners.
- Regularly check the gas hose for kinks, cuts, or abrasions. Replace if damaged.
- Store the barbecue in a dry, protected area when not in use, preferably with a cover.

7. TROUBLESHOOTING

If you encounter issues with your Campingaz Class 3 LBD Gas Barbecue, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply	Check gas cylinder, regulator, and hose connections.
	Clogged burner port	Clean burner ports with a wire brush.
	Faulty igniter	Ensure igniter electrode is clean and properly spaced from burner.
Uneven heating	Clogged burner ports	Clean burner ports.
	Low gas pressure	Check gas cylinder level and regulator.
Yellow or orange flame	Improper air/gas mixture	Clean burner ports.
	Clogged burner ports	Consult a qualified technician if problem persists.

If you cannot resolve an issue using the troubleshooting guide, please contact Campingaz customer support or a qualified service technician.

8. SPECIFICATIONS

Feature	Detail
Model Number	3000005043
Brand	CAMPINGAZ
Burners	3 Stainless Steel Burners
Power	9.6 kW

Feature	Detail
Gas Consumption	698 g/h
Cooking Surface Area	2800 cm² (61 x 46 cm)
Cooking Surface Material	Double-enameled Steel (Grill and Griddle)
Ignition	Piezo
Cooking Height	90.5 cm
Side Shelves	2, Foldable
Trolley Configuration	Steel with integrated spice basket, 2 wheels
Weight	44 kg
Dimensions (Open shelves, open lid)	W 144 x D 66 x H 142 cm
Dimensions (Folded shelves, closed lid)	W 96 x D 64 x H 110 cm
Product Dimensions (from specs)	128 x 60 x 111 cm
Assembly Required	Yes



Image 8.1: Dimensional overview of the Campingaz Class 3 LBD Gas Barbecue.

9. WARRANTY AND SUPPORT

Campingaz products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Campingaz website. Keep your proof of purchase for any warranty claims.

For technical support, spare parts, or further assistance, please contact Campingaz customer service. Contact details can typically be found on the official brand website or in the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B075RDPMZW>

More documents and user manuals: <https://manuals.plus/>