

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LEGO](#) /
- › [LEGO Friends Mia's Tree House 41335 Instruction Manual](#)

LEGO 41335

LEGO Friends Mia's Tree House 41335 Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of the LEGO Friends Mia's Tree House (Set 41335). Designed for children aged 6-12, this creative building set offers an engaging experience with various interactive features and accessories.

should be placed. Take your time and ensure all connections are secure for a stable model.



Image: The product packaging, illustrating the completed Mia's Tree House set.

OPERATING THE SET FEATURES

Once assembled, the Mia's Tree House offers several interactive play features:

- **Folding Ladder:** Use the ladder to access the upper levels of the tree house.
- **Scramble Net:** The orange scramble net provides an alternative way to climb up or slide down from the tree house.
- **Zip Wire:** Attach a mini-doll to the zip wire for an exciting ride from the tree house to the ground.
- **Water Gun:** The water gun accessory can be held by mini-dolls for imaginative play.
- **Bird's Nest:** A bird's nest with an egg is located on a branch, adding to the natural theme.
- **Bunny House:** A small house for Mimi the bunny is included for pet care roleplay.
- **Skateboard:** Mia's skateboard allows for dynamic play scenarios.



Image: Daniel mini-doll ascending the ladder to the tree house entrance.



Image: Mia enjoying the zip line while Daniel uses the scramble net.

Your browser does not support the video tag.

Video: An official overview of the LEGO Friends Mia's Tree House set, demonstrating its various features and play possibilities.

MAINTENANCE

To keep your LEGO set in optimal condition:

- **Cleaning:** Clean LEGO bricks with mild soap and water (not exceeding 104°F or 40°C). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or mechanical drying methods.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration and warping of plastic elements. Keep small pieces in a container to avoid loss.

TROUBLESHOOTING

Missing Pieces: If you find any pieces missing from your new LEGO set, please contact LEGO Customer Service directly. They can assist with replacement parts.

SPECIFICATIONS

Brand	LEGO
Model Number	41335

Number of Pieces	351
Recommended Age	6 - 12 years
Product Dimensions	11.1 x 10.32 x 2.99 inches
Item Weight	1.15 pounds

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years. This set contains small elements that may pose a choking risk if swallowed. Adult supervision is recommended during play, especially with younger children.

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. If you encounter any issues with your set, such as missing or defective parts, please visit the official LEGO website or contact their customer service for assistance. Information regarding product warranty and support can typically be found on the LEGO Group's official channels.

For further support, visit: www.lego.com/service