

[Manuals.plus](#) /

› [Miele](#) /

› Miele CM6150 Countertop Coffee Machine Instruction Manual

Miele CM6150

Miele CM6150 Countertop Coffee Machine Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Miele CM6150 Countertop Coffee Machine. The Miele CM6150 is designed to offer a comprehensive coffee experience with features such as a Coffee Pot Function, Direct Sensor Control Panel, OneTouch for Two beverage preparation, a height-adjustable coffee spout, a dishwasher-safe drip tray, and a removable brew unit.



Figure 1: Front view of the Miele CM6150 Countertop Coffee Machine.

1. SETUP

1.1 Unpacking and Placement

Carefully remove all packaging materials. Place the coffee machine on a stable, level, and heat-resistant surface. Ensure adequate ventilation around the appliance. Avoid placing it near heat sources or in direct sunlight. The machine requires a standard 110 Volt power supply.

1.2 Initial Cleaning

Before first use, clean the water tank, drip tray, and coffee grounds container with warm water and a mild detergent. Rinse thoroughly and dry. The drip tray is dishwasher safe.

1.3 Filling Water Tank and Bean Container

- Fill the water tank with fresh, cold tap water up to the maximum mark.
- Open the bean container lid and fill with whole coffee beans. Close the lid securely to maintain freshness.

1.4 First Use and Priming

After plugging in the machine, follow the on-screen prompts for initial setup. The machine will guide you through a priming process to fill the system with water. This is crucial for proper operation.



Figure 2: Side view of the Miele CM6150, showing its compact design.

2. OPERATING INSTRUCTIONS

2.1 Control Panel Overview

The Miele CM6150 features a Direct Sensor Control Panel. Use the touch buttons and the rotary selector with the OK button to navigate menus and select options. The display provides clear instructions and status updates.



Figure 3: Detailed view of the Direct Sensor Control Panel.

2.2 Preparing Coffee Beverages

1. **Power On:** Press the power button to turn on the machine. It will perform a brief rinse cycle.
2. **Select Beverage:** Use the control panel to select your desired coffee beverage (e.g., Espresso, Coffee, Cappuccino).
3. **Adjust Settings (Optional):** For personalized drinks, use the "Expert Mode" to adjust grind quantity and water amount. You can also save up to ten personal user profiles with the "Connoisseur profile" feature.
4. **Place Cup(s):** Position one or two cups under the height-adjustable coffee spout. The "OneTouch for Two" function allows simultaneous preparation of two beverages.
5. **Start Brewing:** Press the start button. The machine will grind the beans and brew your selected drink.

2.3 Milk Frothing

For beverages requiring milk froth, the machine will guide you through the process. Ensure the milk system is clean and the milk container (if applicable) is filled. The machine produces creamy milk froth for various coffee specialties.



Figure 4: The Miele CM6150 preparing two coffee beverages simultaneously.

3. MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your Miele CM6150 coffee machine. The machine will prompt you when specific maintenance tasks are due.

3.1 Daily Cleaning

- **Drip Tray and Coffee Grounds Container:** Empty and clean these components daily. The drip tray is dishwasher safe.
- **Coffee Spout:** Wipe the coffee spout with a damp cloth.
- **Milk System (if used):** Perform the automatic milk system rinse after each use. Regularly disassemble and clean milk system components.

3.2 Removable Brew Unit

The brew unit is removable for thorough cleaning. Follow the instructions in the display to remove it, rinse under warm running water, and allow it to air dry before reinserting.

3.3 Descaling and Cleaning Tablets

The machine will indicate when descaling or cleaning is required. Use only Miele-approved descaling and cleaning tablets. The accessory pack includes 2 descaling tablets and 6 cleaning tablets. Follow the on-screen instructions for these processes.

4. TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, or if solutions do not resolve the issue, please contact Miele customer support.

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into the machine and the wall outlet. Verify the outlet has power.
No coffee is dispensed.	Water tank empty; brew unit blocked; descaling needed.	Fill the water tank. Clean the brew unit. Perform a descaling cycle if prompted by the machine.
Coffee is not hot enough.	Temperature setting too low; cups not pre-heated.	Adjust the coffee temperature setting in the menu. Pre-heat cups with hot water.
Machine frequently requests cleaning/maintenance.	Normal operation for optimal performance.	Follow the machine's prompts for cleaning, descaling, and emptying containers. This ensures consistent coffee quality and machine longevity.

5. SPECIFICATIONS

Brand: Miele

Model Name: CM6150

Model Number: 10662820 (Part Number: ABT-114420)

Capacity: 8 Cups

Color: Obsidian Black

Coffee Maker Type: Espresso Machine

Operation Mode: Fully Automatic

Wattage: 1500 watts

Voltage: 110 Volts

Human Interface Input: Buttons

Coffee Input Type: Beans

Filter Type: Reusable

Item Weight: 29 Pounds

Material: Plastic

Included Components: Countertop Coffee Machine and accessory pack with 2 descaling tablets, 6 cleaning tablets

GTIN (UPC): 810002431296

6. WARRANTY INFORMATION

The Miele CM6150 Countertop Coffee Machine comes with a **1-year manufacturer's warranty**. An extended **2nd year warranty** is available upon product registration. Please refer to the official Miele website or your purchase documentation for detailed warranty terms and conditions, including registration procedures.

7. CUSTOMER SUPPORT

For technical assistance, service requests, or further inquiries regarding your Miele CM6150 coffee machine, please contact Miele customer service. You can find contact information, including phone numbers and online support options, on the official Miele website: www.miele.com.

When contacting support, please have your model number (CM6150) and serial number ready. The serial number is typically located on a label on the back or bottom of the appliance.