



Manuals.plus /

› Miele /

› Miele CM6150 Countertop Coffee Machine User Manual

## Miele CM6150

# Miele CM6150 Countertop Coffee Machine User Manual

Model: CM6150

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Miele CM6150 Countertop Coffee Machine. Please read these instructions thoroughly before initial use to ensure proper functionality and longevity of your appliance.

## PRODUCT OVERVIEW

---

The Miele CM6150 is a fully automatic countertop coffee machine designed to deliver a variety of coffee and milk-based beverages. Key features include:

- Coffee Pot Function for multiple servings.
- Intuitive Direct Sensor Control Panel for easy operation.
- OneTouch for Two function to prepare two coffee specialties simultaneously.
- Height Adjustable Coffee Spout to accommodate various cup sizes.
- Dishwasher Safe Drip Tray for convenient cleaning.
- Removable Brew Unit for thorough maintenance.



Figure 1: Miele CM6150 Countertop Coffee Machine in Lotus White, showing its front and side profile with dimensions (18.12" H x 16.75" W x 10" D).

## SETUP

Before first use, ensure the machine is placed on a stable, level surface. Follow these steps for initial setup:

1. **Fill Water Container:** Remove the water container from the side of the machine. Fill it with fresh, cold water up to the maximum mark. Reinsert the container securely.
2. **Add Coffee Beans:** Open the coffee bean container lid on top of the machine. Pour fresh whole coffee beans into the container. Close the lid.

3. **Power On:** Connect the power cord to a suitable electrical outlet. Press the power button to turn on the machine. The display will guide you through initial rinsing and setup procedures.

Your browser does not support the video tag.

Video 1: An overview of the Miele CM6150 coffee machine, demonstrating how to fill the water container and add coffee grounds. It also highlights the removable brew unit and the height-adjustable coffee spout.

## OPERATING INSTRUCTIONS

---

Your Miele CM6150 offers various options for preparing your favorite coffee beverages:

1. **Selecting a Drink:** Use the Direct Sensor Control Panel to navigate through the menu and select your desired coffee specialty (e.g., Espresso, Coffee, Cappuccino, Latte Macchiato).
2. **Adjusting Settings:** Customize drink parameters such as coffee strength, temperature, and volume according to your preference. The machine allows for personalized profiles to save your favorite settings.
3. **OneTouch for Two:** For simultaneous preparation of two identical beverages, select the "OneTouch for Two" option. Place two cups under the coffee spout.
4. **Height Adjustable Spout:** Adjust the height of the coffee spout to fit your cup size, minimizing splashes and maintaining optimal temperature.
5. **Milk-Based Drinks:** For beverages requiring milk, connect the milk tube to the designated port and place the other end into a container of cold milk. The machine will automatically froth and dispense the milk.

## MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance are crucial for the performance and lifespan of your coffee machine. The machine will prompt you when specific cleaning actions are required.

- **Daily Cleaning:** Empty and rinse the drip tray and coffee grounds container daily. The drip tray is dishwasher-safe.
- **Removable Brew Unit:** The brew unit can be removed for rinsing under warm water. Refer to the machine's display for instructions on when and how to remove it.
- **Descaling:** The machine will indicate when descaling is necessary. Use Miele-approved descaling tablets and follow the on-screen instructions.
- **Cleaning Tablets:** Periodically, the machine will prompt for a cleaning cycle using cleaning tablets to remove coffee oil residue.

## TROUBLESHOOTING

---

If you encounter issues with your Miele CM6150, consult the following common solutions:

Problem	Possible Cause / Solution
Machine not dispensing coffee.	Check water tank level. Ensure coffee beans are present. Verify brew unit is correctly inserted.
"Rinse appliance" message appears frequently.	This is a normal function to maintain hygiene. Follow the on-screen prompts.
Machine requires cleaning/descaling.	The machine provides advance notice for these cycles. Ensure you have the necessary cleaning/descaling tablets. The machine will not operate until these cycles are completed if overdue.
Grinder not working.	Check for foreign objects in the bean hopper. Ensure the bean container lid is properly closed. If the issue persists, contact Miele customer support.
Coffee is not hot enough.	Adjust the temperature setting in the machine's menu. Pre-heat cups before brewing.

## SPECIFICATIONS

Feature	Detail
Brand	Miele
Model Name	CM6150
Model Number	10662810
Color	Lotus White
Product Dimensions (D x W x H)	10"D x 16.75"W x 18.13"H
Item Weight	29 Pounds
Capacity	1200 Milliliters
Coffee Maker Type	Drip Coffee Machine (Super-Automatic Espresso Machine)
Operation Mode	Fully Automatic
Wattage	1500 watts
Voltage	120 Volts
Human Interface Input	Buttons
Filter Type	Reusable
Material	Plastic
Included Components	Countertop Coffee Machine and accessory pack with 2 descaling tablets, 6 cleaning tablets

## WARRANTY AND SUPPORT

Your Miele CM6150 Countertop Coffee Machine comes with a comprehensive warranty and dedicated support:

- **Warranty:** The product includes a 1-year warranty. An extended 2nd year warranty is available upon product registration.

- **Customer Support:** For technical assistance, service requests, or to register your product, please visit the official Miele website or contact Miele customer service directly.