

GUESS U0668G8

GUESS Men's U0668G8 Chronograph Watch Instruction Manual

WELCOME

Thank you for choosing the GUESS Men's U0668G8 Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

The GUESS U0668G8 is a sophisticated men's chronograph watch featuring a durable stainless steel gold-tone case and bracelet, a black dial with Roman numerals, and multiple functions including a stopwatch and date display. Its robust construction and water resistance make it suitable for daily wear.

Key Features:

- Black chronograph dial with date window and Roman numerals.
- Chronograph stopwatch feature with date function window.
- 44.5 mm case size with durable mineral crystal that protects the watch from scratches.
- Polished stainless steel gold-tone case.
- Stainless steel polished gold-tone bracelet with fold-over clasp and double push-button closure.
- Water resistant to 50 meters / 165 feet.
- Japanese Quartz Movement.
- Battery included.



Front view of the GUESS Men's U0668G8 Chronograph Watch, showcasing the black dial, Roman numerals, and gold-tone finish.

INITIAL SETUP

Setting Time and Date:

1. Pull the crown (the knob on the side of the watch) out to the first click position to set the date. Turn the crown clockwise or counter-clockwise until the correct date appears in the date window.

2. Pull the crown out to the second click position to set the time. Turn the crown to move the hour and minute hands to the desired time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator or if setting the date.
3. Once the time and date are set, push the crown back in to its original position to start the watch.

Adjusting the Bracelet:

The stainless steel bracelet can be adjusted by removing links to achieve a comfortable fit. It is recommended to have this procedure performed by a professional watchmaker to avoid damage. For visual guidance on watch sizing, please refer to the video below.

Your browser does not support the video tag.

This video from Sequel International provides a size chart and visual examples to help determine the appropriate watch case size for different wrist measurements.





Detail of the watch's gold-tone stainless steel bracelet and the double push-button fold-over clasp mechanism.

OPERATING YOUR WATCH

Basic Timekeeping:

Your watch is powered by a precise Japanese Quartz Movement, ensuring accurate timekeeping. The main hands display hours, minutes, and seconds.

Using the Chronograph Function:

The chronograph feature allows you to measure elapsed time. The watch typically has two push-buttons on the side, in addition to the crown.

1. Press the top push-button to start the chronograph. The chronograph second hand will begin to move.
2. Press the top push-button again to stop the chronograph. The elapsed time will be displayed.
3. Press the bottom push-button to reset the chronograph to zero.

Water Resistance Guidelines:

This watch is water resistant up to 50 meters (165 feet). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown or push-buttons when the watch is wet or submerged to prevent water intrusion.

Your browser does not support the video tag.

This video from Merchant Video highlights the features of the GUESS Gold-Tone Stainless Steel Chronograph Bracelet Watch, including its design and functionality.

CARE AND MAINTENANCE

- **Cleaning:** Wipe your watch regularly with a soft, dry cloth to remove dust and dirt. For the metal bracelet, a

slightly damp cloth can be used, followed by immediate drying.

- **Avoid Chemicals:** Do not expose your watch to harsh chemicals, solvents, or detergents, as these can damage the case, crystal, or bracelet.
- **Temperature Extremes:** Protect your watch from extreme temperatures, both hot and cold, as this can affect the battery life and movement accuracy.
- **Magnetic Fields:** Keep your watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones) to prevent interference with the quartz movement.
- **Battery Replacement:** When the battery runs out, have it replaced by a qualified watch technician to ensure the water resistance seal is maintained.
- **Storage:** When not wearing your watch, store it in a cool, dry place, preferably in its original box or a watch case to protect it from dust and scratches.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low battery.	Replace the battery.
Time is incorrect.	Crown pulled out; time needs adjustment.	Push crown in fully; reset time as per 'Setting Time and Date' instructions.
Date is incorrect.	Date needs adjustment.	Adjust date as per 'Setting Time and Date' instructions.
Condensation inside the crystal.	Temperature change; water resistance compromised.	Seek professional service immediately to prevent damage to the movement.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Number	U0668G8
Brand	GUESS
Movement	Japanese Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	44.5 mm
Case Thickness	12 mm
Crystal Material	Mineral
Band Material	Stainless Steel
Band Width	21.5 mm
Band Color	Gold-Tone

Feature	Detail
Dial Color	Black
Water Resistance Depth	50 Meters (165 Feet)
Clasp Type	Deployant Clasp with Push-Button
Additional Features	Chronograph, Date Window, Roman Numerals
Item Weight	7.84 ounces
UPC	091661479328

WARRANTY INFORMATION

This GUESS watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

CUSTOMER SUPPORT

Should you require assistance with your GUESS watch, including warranty claims, repairs, or general inquiries, please contact the manufacturer, Sequel International, or visit their official support channels. Contact information can typically be found on the warranty card or the GUESS Watches official website.

For more information, you may visit the [GUESS Store on Amazon](#).