



Manuals.plus /

› Maxi-Cosi /

› Maxi-Cosi MiloFix Car Seat Instruction Manual

Maxi-Cosi Milofix

Maxi-Cosi MiloFix Car Seat Instruction Manual

Model: MiloFix | Brand: Maxi-Cosi

1. INTRODUCTION

The Maxi-Cosi MiloFix is a versatile car seat designed to provide safety and comfort for children from birth up to approximately 4 years old, covering weight groups 0-18 kg. It features a secure ISOFIX installation system and adapts to your child's growth with both rear-facing and forward-facing positions.

2. SAFETY INFORMATION

Always read and understand all instructions before installing and using the car seat. Failure to follow these instructions could result in serious injury or death to your child.

- Ensure the car seat is correctly installed and secured in your vehicle according to the instructions.
- Never leave your child unattended in the car seat.
- Always secure your child with the 5-point harness, ensuring it is snug and properly adjusted.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage.
- Refer to your vehicle's owner's manual for specific information regarding child restraint installation and airbag warnings.



Image 2.1: The Maxi-Cosi MiloFix car seat in Vivid Red, showcasing its overall design and harness system. Note the airbag warning label on the side.

3. PRODUCT OVERVIEW

The MiloFix car seat is designed with several key components for safety and ease of use:

- **Adjustable Headrest:** Provides head and neck support, adjustable to 7 positions.
- **5-Point Harness System:** Secures your child safely in the seat.
- **ISOFIX Connectors:** For rigid and secure attachment to your vehicle's ISOFIX anchor points.

- **Top Tether:** An additional anchor point for enhanced stability in forward-facing mode.
- **New-born Cushion:** Provides extra comfort and support for infants.



Image 3.1: A top-down view of the Maxi-Cosi MiloFix car seat, highlighting the 5-point harness, buckle, and padded seating area.



Image 3.2: A close-up view of the Maxi-Cosi MiloFix car seat's 5-point harness system and central buckle, showing the padded shoulder straps and crotch pad.

4. SETUP AND INSTALLATION

The Maxi-Cosi MiloFix car seat offers two installation modes: rear-facing and forward-facing, both utilizing the ISOFIX system.

4.1. ISOFIX Installation

The ISOFIX system provides a rigid and permanent connection between the car seat and your vehicle's chassis. Locate the ISOFIX anchor points in your car (usually indicated by labels or slots in the seat crease).

1. Extend the ISOFIX connectors from the car seat base.

2. Align the connectors with your vehicle's ISOFIX anchor points and push firmly until you hear a 'click' and the indicators turn green.
3. Push the car seat firmly against the vehicle's backrest to remove any slack.

4.2. Rear-Facing Installation (Group 0+, Birth to approx. 15/18 months)

For infants, the car seat must be installed in the rear-facing position. This provides optimal protection for a baby's fragile head and neck.

1. Ensure the car seat is in the rear-facing orientation.
2. Follow the ISOFIX installation steps (4.1).
3. Ensure the support leg is extended and firmly placed on the vehicle floor. The indicator should show green.
4. Check for a secure installation by attempting to move the seat; it should not move more than 1 inch (2.5 cm) at the belt path.

4.3. Forward-Facing Installation (Group 1, approx. 15/18 months to 4 years)

Once your child reaches the appropriate age and weight, the seat can be easily turned forward-facing.

1. Rotate the car seat to the forward-facing orientation.
2. Follow the ISOFIX installation steps (4.1).
3. Attach the Top Tether strap to the designated anchor point in your vehicle (refer to your vehicle's manual for location). Tighten the Top Tether until the indicator shows green and there is no slack.
4. Verify the secure installation by checking for movement.



Image 4.1: A hand demonstrating the adjustment mechanism for a car seat strap, likely part of the ISOFIX or top tether installation process, located on the underside of the seat base.



Image 4.2: Two perspectives of the Maxi-Cosi MiloFix car seat, illustrating its adaptability for different installation configurations, possibly rear-facing and forward-facing setups.

5. OPERATING INSTRUCTIONS

5.1. Securing Your Child

1. Place your child in the car seat.
2. Bring the two harness buckles together and insert them into the central buckle until you hear a 'click'.
3. Pull the harness adjustment strap at the front of the seat to tighten the harness. Ensure it is snug against your child's body, with no more than one finger's slack at the collarbone.
4. To loosen the harness, press the release button (usually located near the adjustment strap) and pull the shoulder straps forward.

5.2. Headrest and Harness Adjustment

The MiloFix features a simultaneous headrest and harness adjustment system with 7 positions to accommodate your growing child.

1. Locate the adjustment lever, typically at the top or back of the headrest.
2. Squeeze the lever and slide the headrest up or down until the shoulder straps are at or just below your child's shoulders for rear-facing, or at or just above for forward-facing.
3. Release the lever to lock the headrest and harness in place.

5.3. Switching Orientation

The MiloFix car seat can be easily switched between rear-facing and forward-facing modes. Consult your manual for the specific mechanism, which usually involves releasing a locking mechanism on the base and rotating the seat shell.



Image 5.1: A young child comfortably secured in a Maxi-Cosi car seat in a rear-facing position, demonstrating proper harness usage and headrest alignment.

6. MAINTENANCE

6.1. Cleaning the Cover

The car seat cover is machine washable for easy cleaning.

- Remove the fabric cover from the car seat. Refer to your specific manual for detailed removal instructions.
- Machine wash the cover at 30°C on a gentle cycle. Do not tumble dry, bleach, or iron.
- Allow the cover to air dry completely before reattaching it to the car seat.

6.2. Cleaning Plastic Parts

Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.

6.3. Harness Care

Wipe the harness straps with a damp cloth. Do not machine wash or submerge the harness straps in water, as this can weaken the webbing.

7. TROUBLESHOOTING

- **Harness too loose:** Ensure the harness is properly routed and tightened using the adjustment strap. Check that no clothing is interfering with the harness path.
- **Car seat feels unstable:** Recheck all ISOFIX connections and the Top Tether (if forward-facing). Ensure the support leg is correctly deployed and locked. Push the seat firmly into the vehicle's backrest.
- **Difficulty adjusting headrest/harness:** Ensure no fabric is caught in the mechanism. Apply firm but gentle pressure when operating the adjustment lever.
- **Buckle not clicking:** Check for obstructions in the buckle mechanism. Ensure both buckle tongues are fully inserted.

If you encounter persistent issues, refer to the full product manual or contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	8536721110
Target Gender	Unisex
Maximum Child Weight	18 Kilograms
Product Dimensions	53 x 44 x 65 cm
Item Weight	11.3 Kilograms
Harness Type	5-Point
Installation Type	ISOFIX
Orientation	Rear Facing (0-15/18 months), Forward Facing (15/18 months-4 years)
Manufacturer	Dorel Juvenile

9. WARRANTY AND SUPPORT

9.1. Warranty Information

The Maxi-Cosi MiloFix car seat comes with a 3-Year Local (Singapore) Manufacturer Warranty. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use.

9.2. Customer Support

For further assistance, technical support, or warranty inquiries, please contact Maxi-Cosi customer service through

their official website or the retailer where the product was purchased.