

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Casio](#) /
- › [Casio XJ-V10X DLP Hybrid Light Source Portable Projector User Manual](#)

## Casio XJ-V10X

# Casio XJ-V10X DLP Hybrid Light Source Portable Projector User Manual

Model: XJ-V10X | Brand: Casio

## PRODUCT OVERVIEW

The Casio XJ-V10X is a high-performance DLP Hybrid Light Source Portable Projector designed for clear and brilliant color reproduction. Featuring a long-lasting LED light source, it is suitable for various presentation environments, from home cinema to office use. Its compact design and multiple connectivity options make it a versatile choice.



Front view of the Casio XJ-V10X projector, showcasing its compact design and central lens.

## SETUP GUIDE

- Unpacking:** Carefully remove the projector and all accessories from the packaging. Ensure all components listed in the 'What's in the Box' section are present.
- Placement:** Place the projector on a stable, flat surface. Ensure adequate ventilation around the unit.
- Power Connection:** Connect the power cable to the projector's power input port (located at the bottom left of the rear panel) and then to a suitable power outlet.

#### 4. Input Source Connection:

- For digital video and audio, connect an HDMI cable from your source device to the projector's HDMI port.
- For analog video, connect a VGA cable from your computer to the projector's 'COMPUTER' port.
- For audio input, use the 'AUDIO IN' 3.5mm jack.
- A 'SERIAL' port is available for control purposes.

5. **Adjusting Height:** Utilize the adjustable leg/ledge at the front of the projector to tilt the unit and achieve the desired projection angle. Press the "PUSH" button to release and adjust the leg.

## OPERATING INSTRUCTIONS

---

1. **Power On/Off:** Press the **POWER/STANDBY** button on the top panel to turn the projector on or off. The projector features a Direct ON/OFF function, eliminating warm-up and cool-down phases.
2. **Input Selection:** Press the **INPUT** button on the top panel to cycle through available input sources (HDMI, Computer/VGA).
3. **Focus and Zoom Adjustment:** Use the **FOCUS** and **ZOOM** levers located near the lens on the top panel to sharpen the image and adjust its size on the screen.
4. **Image Adjustment:** Adjust the projector's position and the screen's distance to achieve the desired image size and clarity.

## MAINTENANCE

---

To ensure optimal performance and longevity of your Casio XJ-V10X projector, regular maintenance is recommended:

- **Cleaning the Lens:** Gently wipe the projector lens with a soft, lint-free cloth, such as the included Projector Supercenter microfiber cloth. Avoid using abrasive cleaners.
- **Cleaning the Exterior:** Wipe the exterior of the projector with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.
- **Ventilation:** Ensure that the ventilation grilles are not blocked to prevent overheating. Periodically check for dust accumulation and gently clean if necessary.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

If you encounter issues with your Casio XJ-V10X projector, try the following basic troubleshooting steps:

- **No Power:**
  - Check if the power cable is securely connected to both the projector and the power outlet.
  - Verify that the power outlet is functional.
  - Ensure the **POWER/STANDBY** button has been pressed.
- **No Image:**
  - Confirm that the input cable (HDMI, VGA) is securely connected to both the projector and the source device.
  - Press the **INPUT** button to select the correct input source.
  - Check the source device (computer, media player) to ensure it is powered on and outputting a signal.
- **Blurry Image:**
  - Adjust the **FOCUS** lever until the image is sharp.
  - Ensure the projector is at an appropriate distance from the projection surface.
- **No Audio:**

- If using HDMI, ensure the source device's audio output is enabled.
- If using the 'AUDIO IN' jack, ensure the cable is connected correctly and the source device's volume is up.
- Check the projector's volume settings.

## SPECIFICATIONS

Feature	Detail
Model Number	XJ-V10X
Light Source	Hybrid LED
Brightness	3,300 Lumens
Lamp Life	20,000+ Hours
Contrast Ratio	20,000:1
Native Resolution	1024 x 768 (XGA)
Aspect Ratio	Native 4:3
Connectivity	HDMI, VGA (Computer), Serial, Audio In/Out
Dimensions (L x W x H)	11.8 x 3.8 x 11.8 inches
Weight	10.6 pounds
Visible Screen Diagonal	Up to 300" / 762 cm
Manufacturing Origin	Made-in-Japan

## WARRANTY AND SUPPORT

For detailed warranty information regarding your Casio XJ-V10X projector, please refer to the official Casio website or the warranty card included with your purchase. Casio products are known for their quality, with this unit being "Made-in-Japan" for assurance.

For technical support, service, or further inquiries, please contact Casio customer support through their official channels. Keep your product model number (XJ-V10X) and purchase details ready when contacting support.



