

Edifier DA5100

Edifier DA5100 5.1 Speakers User Manual

Your comprehensive guide to setup, operation, and maintenance.

INTRODUCTION

Thank you for purchasing the Edifier DA5100 5.1 multimedia speaker system. This manual provides detailed instructions to help you set up, operate, and maintain your speakers for optimal performance and longevity. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Before proceeding, please verify that all components are present in your package:

- Subwoofer unit
- Center speaker
- Front satellite speakers (2)
- Rear satellite speakers (2)
- Remote control
- Audio input cables (RCA to RCA, 3.5mm to RCA)
- Speaker connection cables
- User manual (this document)



Figure 1: Overview of the Edifier DA5100 5.1 speaker system, showing the subwoofer, five satellite speakers, and remote control.

IMPORTANT SAFETY PRECAUTIONS

To ensure safe operation and prevent damage, please observe the following:

- Do not expose the unit to rain or moisture.
- Do not open the speaker enclosures; there are no user-serviceable parts inside.
- Place the unit on a stable, level surface to prevent tipping.
- Ensure adequate ventilation around the speakers and subwoofer.
- Disconnect from power during lightning storms or when unused for long periods.
- Keep away from heat sources and direct sunlight.
- Use only specified power supply and accessories.

SETUP GUIDE

1. Speaker Placement

Proper speaker placement is crucial for optimal 5.1 surround sound experience.

- **Center Speaker:** Place directly in front of the listening position, typically above or below your display.
- **Front Speakers (Left/Right):** Position equidistant from the listening position, forming an equilateral triangle with the listener.
- **Rear Speakers (Left/Right):** Place behind the listening position, slightly to the sides, at ear level or slightly above.
- **Subwoofer:** Can be placed anywhere in the room, but corner placement often enhances bass. Experiment for best results.



Figure 2: The center speaker, designed for clear dialogue reproduction.

2. Connecting the Speakers

Connect the satellite speakers to the subwoofer unit using the provided speaker cables. Ensure correct polarity (red to red, black to black) for each connection.

1. Identify the speaker output terminals on the rear of the subwoofer. These are typically labeled for Front Left (FL), Front Right (FR), Center (C), Surround Left (SL), and Surround Right (SR).
2. Connect each satellite speaker to its corresponding terminal on the subwoofer.



Figure 3: Speaker terminal on a satellite speaker, showing the red and black spring clips for wire connection.

3. Connecting Audio Sources

The DA5100 offers multiple input options. Choose the one that best suits your audio source.

- 1. 5.1 Channel Input:** For true 5.1 surround sound, connect your DVD player, Blu-ray player, or sound card's 5.1 analog outputs to the corresponding 5.1 input jacks on the subwoofer (FL, FR, C, SL, SR, SW).
- 2. PC Input:** Use the 3.5mm to RCA cable to connect your computer's audio output to the "PC" input jacks.
- 3. AUX Input:** Use the RCA to RCA cable to connect other stereo audio devices (e.g., TV, game console) to the "AUX" input jacks.



Figure 4: Rear panel of the subwoofer, detailing all audio input and speaker output connections.

4. Power Connection

After all audio and speaker connections are made, connect the power cord to the subwoofer and then to a wall outlet. Ensure the power switch on the rear of the subwoofer is in the "OFF" position before plugging in.

OPERATING INSTRUCTIONS

1. Powering On/Off

Locate the power switch on the rear panel of the subwoofer. Flip it to the "ON" position to power on the system. Flip it to "OFF" to power off.

2. Input Selection

Use the "Input" button on the remote control or the control panel on the subwoofer to cycle through the available audio inputs: 5.1, PC, AUX.

3. Volume Control

Use the "Volume +" and "Volume -" buttons on the remote control or the main volume knob on the subwoofer to adjust the overall system volume.

4. Individual Channel Volume Adjustment

The remote control allows for individual adjustment of the center, surround, and subwoofer volumes to fine-tune your sound experience.

- Press the "Center", "Surround", or "Subwoofer" button on the remote.
- Use the "Volume +" or "Volume -" buttons to adjust the level for that specific channel.

5. Mute Function

Press the "Mute" button on the remote control to temporarily silence the audio. Press it again to restore the sound.

MAINTENANCE AND CARE

To keep your Edifier DA5100 speakers in optimal condition:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the subwoofer's heat sink and ventilation ports are not obstructed.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place.
- **Cable Management:** Keep cables tidy and avoid sharp bends or kinks to prevent damage.

TROUBLESHOOTING

If you encounter issues with your Edifier DA5100 system, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No sound	Power off; incorrect input selected; loose cables; muted.	Check power switch; select correct input; re-connect all cables securely; un-mute.
Distorted sound	Volume too high; poor audio source quality; incorrect cable connection.	Reduce volume; try a different audio source; check cable connections and polarity.
Remote control not working	Dead batteries; obstruction between remote and sensor.	Replace batteries; ensure clear line of sight to the subwoofer's IR sensor.
Only some speakers producing sound	Incorrect 5.1 setup; loose speaker cables; audio source not 5.1.	Verify 5.1 input connections; check individual speaker cables; ensure audio source is outputting 5.1.

If the problem persists, please contact Edifier customer support.

SPECIFICATIONS

The following are the general specifications for the Edifier DA5100 5.1 speaker system. Specifications are subject to change without notice.

Power Output: RMS 8W x 5 + 38W (THD+N=10%)

Frequency Response: R/L/C/SL/SR: 150Hz-20KHz | SW: 20Hz-130Hz

Input Sensitivity: 5.1CH: L/R: 450mV+/-50mV; SW: 150mV+/-50mV | PC: 700mV+/-50mV | AUX: 350mV+/-50mV

Input Type: 5.1 Channel, PC, AUX

Bass Unit: 8 inch (210mm)

Mid-range Unit: 3 inch (78mm)

Treble Unit: 1 inch (25mm)

Dimensions (Subwoofer): 270mm x 300mm x 435mm (W x H x D)

Dimensions (Satellite): 130mm x 160mm x 100mm (W x H x D)

WARRANTY INFORMATION

Edifier products come with a limited warranty. Please refer to the warranty card included with your product or visit the official Edifier website for detailed warranty terms and conditions specific to your region. Keep your purchase receipt as proof of purchase for warranty claims.


CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries, please contact Edifier customer support through their official website or the contact information provided in your product packaging.

Edifier Official Website: www.edifier.com

© 2023 Edifier International. All rights reserved. Edifier and other Edifier marks are owned by Edifier and may be registered. All other trademarks are the property of their respective owners.

Documents - Edifier – DA5100



[\[pdf\] User Manual Specifications](#)

IB-100-D51000-03 DA5100- -V1 da5100 v1 3 DA5100-V1

3_S1st_sodO static edifier uploads 2021-05 Edifier *

Multimedia Speaker Manual Edition 1 2 Apr 2014 Printed in China 2014

edifier-asset ventmere cn


2014 20144 Copyright 2014 All Rights Reserved. Manual Edition 1.2, Apr. 2014

Printed in China GAME 5.1 reset S . W. PC AUX FUNC BASS ESC RC20D

www.edifier.com : 68 Beijing Edifier Technology Co., Ltd. Made in China Multimedia

Speaker **DA5100** GAME 5.1 reset S . W. PC AUX FUNC...

lang:en **score:30** filesize: 1.62 M page_count: 1 document date: 2021-04-21



[\[pdf\] User Manual Instructions Specifications Guide](#)

IB 100 D51000 03 DA5100 V1 Edifier Ib d51000 Da5100 v1 * Multimedia Speaker

Copyright 2014 All Rights Reserved Manual Edition 1 2 Apr Printed in China 2014

2014 4 afcd3e3b c3f1 4215 7581 9fb36df52665 DA5100UsageGuide

Syn6JWH7 edifier asset ventmere cn 2015 6 static 2017 06

2014 20144 Copyright 2014 All Rights Reserved. Manual Edition 1.2, Apr. 2014

Printed in China GAME 5.1 reset S . W. PC AUX FUNC BASS ESC RC20D IB-100-

D51000-03 Multimedia Speaker **DA5100** GAME 5.1 reset S . W. PC AUX FUNC

BASS ESC RC20D 1 27 330 AAA 16 2 3 4 1. 5.1- 2...

lang:en **score:22** filesize: 2.08 M page_count: 1 document date: 2014-05-15