

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [BBC](#) /
- › [Hidden DVD User Guide](#)

BBC B075WP97ZG

Hidden DVD User Guide

Comprehensive information for your "Hidden" DVD set.

PRODUCT OVERVIEW

The "Hidden" DVD set features the acclaimed 4-part BBC thriller. This guide provides essential information for enjoying and maintaining your DVD set.




Image: Front cover of the "Hidden" DVD set. It displays the main actors Philip Glenister, Thekla Reuten, and David Suchet, along with the title "HIDDEN" prominently. The cover also indicates it's a "2 DISC SET" and "As seen on BBC".

SETUP AND PLAYBACK

To begin watching "Hidden", follow these simple steps:

1. **Insert Disc:** Gently insert the "Hidden" DVD into your DVD player or computer's optical drive with the label side facing up.
2. **Power On:** Ensure your DVD player and television/monitor are powered on.
3. **Select Input:** Use your television remote to select the correct input source (e.g., HDMI 1, AV, Component)

corresponding to your DVD player's connection.

- 4. **Menu Navigation:** Once the DVD loads, the main menu should appear. Use your DVD player's remote control (typically arrow keys and 'Enter' or 'OK' button) to navigate through the menu options.
- 5. **Start Playback:** Select "Play All" or choose a specific episode to begin watching.

OPERATING CONTROLS

Familiarize yourself with standard DVD playback controls:

- **Play/Pause:** Starts or temporarily stops playback.
- **Stop:** Halts playback and returns to the beginning of the disc or menu.
- **Fast Forward/Rewind:** Skips through the content quickly in either direction.
- **Skip (Next/Previous Chapter):** Jumps to the next or previous chapter/scene.
- **Menu:** Returns to the main DVD menu.
- **Subtitle/Audio:** Toggles subtitles or changes audio tracks if available on the disc.

MAINTENANCE AND CARE

Proper care will extend the life of your "Hidden" DVD set:

- **Handling:** Always hold discs by their edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If a disc becomes dirty, gently wipe it with a soft, lint-free cloth (like a microfiber cloth) from the center outwards. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store discs in their original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Prevent scratches by placing discs back in their case immediately after use.

TROUBLESHOOTING

If you encounter issues while playing your "Hidden" DVD, consider these common solutions:

Problem	Possible Cause	Solution
Disc not playing/loading.	Disc is dirty or scratched; incorrect input selected; player malfunction.	Clean the disc; ensure correct input is selected on TV; try the disc in another player.
Skipping or freezing during playback.	Disc surface is dirty or damaged.	Clean the disc thoroughly. If damage is visible, the disc may be unplayable.
No audio or video.	Cables are loose; incorrect audio/video settings.	Check all cable connections (HDMI, AV); ensure TV volume is up and not muted; check DVD player's audio output settings.

SPECIFICATIONS

- **Title:** Hidden
- **Format:** DVD
- **Number of Discs:** 2

- **Run Time:** Approximately 240 minutes
- **MPAA Rating:** Unrated (Not Rated)
- **Director:** Niall MacCormick
- **Actors:** Philip Glenister, Thekla Reuten, David Suchet
- **Studio:** BFS Entertainment / BBC
- **ASIN:** B075WP97ZG
- **Package Dimensions:** 7.4 x 5.31 x 0.79 inches; 4.13 ounces

WARRANTY AND SUPPORT

For issues related to the physical DVD set (e.g., manufacturing defects), please contact the distributor, BFS Entertainment, or your point of purchase. As this is a media product, specific warranties beyond replacement for manufacturing defects are typically not offered.

For general inquiries about the "Hidden" series content, please refer to official BBC resources or fan communities.

Note: This guide pertains to the DVD release of "Hidden" and does not cover streaming services or digital versions.



© 2024 BBC / BFS Entertainment. All rights reserved.