

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MIKASA](#) /

› [MIKASA T-771075 Swirl Oval Plate User Manual](#)

MIKASA T-771075

MIKASA T-771075 Swirl Oval Plate User Manual

Model: T-771075

PRODUCT OVERVIEW



Figure 1: MIKASA T-771075 Swirl Oval Plate, top view. This image displays the white oval plate with a subtle swirl pattern on its surface.

Product Description

The MIKASA T-771075 Swirl Oval Plate is a durable ceramic dinnerware item designed for everyday use. Its simple yet elegant design features a subtle swirl pattern, adding a touch of style to any dining setting. This plate is engineered for convenience, being safe for use in microwaves, dishwashers, and ovens.

Key Features

- **Material:** Hard Ceramic construction for durability.
- **Dimensions:** Approximately 8.7 x 6.1 x 1.0 inches (22 x 15.4 x 2.6 cm).
- **Versatility:** Microwave, Dishwasher, and Oven Safe.
- **Design:** Elegant white finish with a subtle swirl pattern.
- **Origin:** Manufactured in Malaysia.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the MIKASA T-771075 Swirl Oval Plate. Retain this manual for future reference.

- Avoid sudden temperature changes, which can cause ceramic to crack or break. For example, do not place a hot plate directly into cold water.
- Handle with care. Ceramic items can break if dropped or struck against hard surfaces.
- Always use oven mitts when handling hot plates from the microwave or oven.
- Do not use abrasive cleaners or scouring pads, as these can damage the plate's surface.
- Ensure the plate is fully dry before storing to prevent water spots or mildew.

SETUP

Before first use, wash the plate thoroughly with warm soapy water and rinse well. Dry completely with a soft cloth. This removes any manufacturing residues and prepares the plate for food contact.

OPERATING INSTRUCTIONS

Microwave Use

The MIKASA T-771075 Swirl Oval Plate is safe for microwave use up to 1,000 W. Ensure the plate fits comfortably within your microwave oven and does not obstruct the rotating mechanism. Always use caution when removing the plate from the microwave, as it may become hot.

Oven Use

This plate is oven safe. Place the plate in a preheated oven. Avoid placing a cold plate directly into a very hot oven or vice-versa, as extreme temperature changes can cause thermal shock and damage the ceramic. Always use oven mitts when handling the plate from the oven.

Dishwasher Use

The plate is dishwasher safe for household use. Place the plate securely in the dishwasher rack, ensuring it does not block spray arms. Use standard dishwasher detergents. For best results and to prevent water spots, remove the plate promptly after the drying cycle is complete.

CARE AND MAINTENANCE

Cleaning

For daily cleaning, wash the plate with warm water and mild dish soap. For stubborn food residues, soak the plate in warm soapy water for a short period before washing. Avoid using abrasive sponges, steel wool, or harsh chemical

cleaners, as these can scratch or dull the ceramic surface.

Storage

Store plates in a dry place. If stacking multiple plates, consider placing a soft cloth or paper towel between them to prevent scratches, especially if the bottom surface is unglazed or rough.



Figure 2: Bottom view of the MIKASA T-771075 Swirl Oval Plate, showing the manufacturer's stamp.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Plate cracks or breaks	Thermal shock (sudden temperature change) or impact.	Avoid extreme temperature changes. Handle with care to prevent drops or impacts.
Food residue stuck	Food dried onto the surface.	Soak the plate in warm, soapy water before washing.

Problem	Possible Cause	Solution
Water spots after washing	Hard water or slow drying.	Ensure thorough rinsing and dry immediately with a soft cloth, or use a rinse aid in the dishwasher.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	T-771075
Brand	Tamaki (Manufacturer: MIKASA)
Material	Hard Ceramic / Earthenware
Color	White
Product Dimensions (L x W x H)	Approx. 8.7 x 6.1 x 1.0 inches (22 x 15.4 x 2.6 cm)
Item Weight	Approx. 10 ounces (0.29 Kilograms)
Microwave Safe	Yes (up to 1,000 W)
Dishwasher Safe	Yes
Oven Safe	Yes
Country of Origin	Malaysia



1000W 食器洗浄機 オーブンOK
レンジ OK OK



Figure 3: MIKASA T-771075 Swirl Oval Plate illustrating its dimensions (22cm length, 15.4cm width).

WARRANTY INFORMATION

Specific warranty details for the MIKASA T-771075 Swirl Oval Plate may vary by retailer or region. Please refer to your purchase receipt or contact the retailer where the product was purchased for information regarding applicable warranties.

CUSTOMER SUPPORT

For assistance with your MIKASA T-771075 Swirl Oval Plate, please contact the retailer or the manufacturer, MIKASA, directly. Contact information can typically be found on their official websites or through your purchase documentation.