

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Madam Sew](#) /

› Madam Sew 32 Piece Presser Foot Set Instruction Manual

Madam Sew XXS232-1A

Madam Sew 32 Piece Presser Foot Set Instruction Manual

Model: XXS232-1A

1. INTRODUCTION

This Madam Sew 32 Piece Presser Foot Set is designed to expand the capabilities of your sewing machine. It includes a variety of presser feet for different sewing tasks, a low shank adapter, and a durable storage case. This set is compatible with most low-shank sewing machines, including models from Singer, Brother, Janome, Husqvarna, Viking, and Kenmore.

2. PRODUCT OVERVIEW

The Madam Sew 32 Piece Presser Foot Set provides a comprehensive collection of presser feet to enhance your sewing projects. The set includes:

- 32 distinct presser feet for various sewing applications.
- A bonus low shank snap-on adapter for broader machine compatibility.
- A heavy-duty plastic storage case with numbered, form-fitting recesses for organization and protection.
- A full-color printed manual identifying each presser foot and its uses.
- Access to online tutorials and videos for detailed usage instructions.



The Madam Sew 32 Piece Presser Foot Set includes 32 distinct presser feet, a low shank snap-on adapter, and a durable storage case with numbered slots for easy organization.



Smart looking packaging with handsome outer sleeve



Bonus low shank snap-on adapter



Durable hard plastic storage case



32 high quality presser feet, numbered custom fit slots, snug fit - won't fall out

Think Inside The Box!


32 presser feet with loads of extra features



Numbered overview of all feet with names




Full color printed manual with description of use of each presser foot and pictures of each foot in use



Online manual with easy-to-read descriptions and tutorials

The set comes with a durable hard plastic storage case, a bonus low shank snap-on adapter, a full-color printed manual, and access to an online manual with tutorials.



The sturdy storage case features custom-fitted, numbered recesses to keep each presser foot secure and organized.

3. SETUP AND INSTALLATION

3.1 Attaching Presser Feet

Most Madam Sew presser feet are designed for snap-on installation. To attach a foot:

1. Raise the presser foot lever on your sewing machine.
2. Position the desired presser foot under the presser foot holder, aligning the pin on the foot with the groove on the holder.
3. Lower the presser foot lever until the foot snaps securely into place.
4. Before sewing, manually lower the needle to ensure it clears the foot's opening.

3.2 Using the Low Shank Adapter

A low shank adapter is included to ensure compatibility with a wider range of sewing machines. If your machine's presser foot holder does not directly accommodate the snap-on feet, use the adapter as follows:

1. Remove your sewing machine's existing presser foot and holder by unscrewing the small screw that secures it to the presser bar.
2. Attach the Madam Sew low shank adapter to the presser bar using the screw. Ensure it is tightened securely.
3. You can now snap on any of the Madam Sew presser feet to the adapter as described in section 3.1.

Refer to your sewing machine's manual for specific instructions on removing and attaching presser foot holders.

Presser Feet Explained Insert

Madam Sew
Ultimate Presser Foot Set
Set of 32 pcs.

All you need to get up to speed!

Online Manual and Video Tutorials

Full Color Manual describes usage of each presser foot, Online Tutorials, and a Bonus Low Shank Snap-On Adapter!

The included low shank snap-on adapter allows compatibility with a wide range of sewing machines. Refer to the manual for specific installation instructions.

4. OPERATING INSTRUCTIONS

Each presser foot in this set is designed for a specific sewing application, from basic stitching to specialized techniques like gathering, zipper insertion, and darning. To effectively use each foot:

- **Consult the Printed Manual:** The included full-color manual identifies each presser foot by number and provides a brief description of its function and basic usage.

- **Access Online Tutorials:** Madam Sew provides extensive online resources, including detailed tutorials and videos, demonstrating the proper application of each presser foot. These visual guides are highly recommended for practical understanding.
- **Test on Scrap Fabric:** Always test the chosen presser foot on a scrap piece of your project fabric before beginning your main work. This allows you to adjust stitch settings, tension, and ensure the desired outcome.

**Comes with
all you need
to get up to speed.
Full Color Manual describes
usage of each presser foot,
Online Tutorials, and a Bonus
Low Shank Snap-On Adapter!**

The comprehensive full-color manual identifies each presser foot and describes its uses. Online tutorials offer visual guidance for practical application.

IMAGINE THE POSSIBILITIES WITH A TOOL FOR EVERY TASK!



This image illustrates several presser feet in action, demonstrating their diverse applications for tasks like cording, quilting, and creating decorative stitches.

For specific video demonstrations, please refer to the official Madam Sew online resources.

5. MAINTENANCE

5.1 Cleaning

To ensure optimal performance and longevity of your presser feet, clean them regularly. Use a soft brush or cloth to remove any lint, thread, or fabric debris that may accumulate. Avoid using harsh chemicals or abrasive materials, as these can damage the finish or functionality of the feet.

5.2 Storage

Store all presser feet in the provided heavy-duty plastic case. The case features numbered, form-fitting recesses designed to protect each foot from damage, dust, and loss. Always ensure the lid is securely snapped shut to keep the contents organized and safe.

6. TROUBLESHOOTING

- **Presser Foot Does Not Fit:** Ensure your sewing machine is a low-shank model. If your machine requires it, verify that the low shank adapter is correctly installed and securely tightened to the presser bar. If issues persist, consult your sewing machine's manual for compatibility details.
- **Needle Breakage:** Before operating the machine with a new presser foot, manually lower the needle to confirm it clears the foot's opening. Incorrect needle alignment or using the wrong needle type for the fabric can cause breakage. Adjust needle position if your machine allows, or ensure the foot is correctly attached.
- **Stitching Irregularities:** If stitches are uneven or skipped, check that the presser foot is securely attached and that the fabric is feeding smoothly. Adjust tension settings on your sewing machine as needed, and ensure the correct needle and thread are being used for your fabric type.

7. SPECIFICATIONS

Model Number	XXS232-1A
Number of Pieces	32 Presser Feet + 1 Low Shank Adapter
Compatibility	Most low-shank sewing machines (e.g., Singer, Brother, Janome, Husqvarna, Viking, Kenmore)
Materials	Metal (presser feet), Plastic (storage case)
Package Dimensions	7.24 x 6.65 x 1.42 inches
Item Weight	15.5 ounces
Manufacturer	Madam Sew
UPC	866451000408

8. WARRANTY AND SUPPORT

Madam Sew offers a risk-free return policy if the presser foot set is found to be incompatible with your sewing machine. For detailed information regarding returns, exchanges, or product support, please refer to the official Madam Sew website or contact their customer service department directly.

For additional resources, including online tutorials and frequently asked questions, visit the [Madam Sew Store on Amazon](#).