SLLEA AC/DC Adapter for PX-A800/PX-A800BN

User Manual: SLLEA AC/DC Adapter

Model Compatibility: Casio Privia PX-A800, PX-A800BN Digital Pianos

Brand: SLLEA

Introduction | Safety Information | Package Contents | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides essential information for the safe and effective use of your SLLEA AC/DC Adapter, designed specifically for Casio Privia PX-A800 and PX-A800BN Digital Pianos. This power supply unit converts standard AC wall power to the DC power required by your digital piano, ensuring stable and reliable operation. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: The SLLEA AC/DC Adapter. This image shows the compact black power adapter unit with its attached power cord, designed to provide stable power to compatible digital pianos.

2. Safety Information

To ensure safe operation and prevent damage to the adapter or your device, please observe the following precautions:

- **Compatibility:** Only use this adapter with the specified Casio Privia PX-A800 and PX-A800BN Digital Pianos. Using it with incompatible devices may cause damage.
- **Voltage:** Ensure the wall outlet voltage matches the adapter's input specifications (100-240 VAC, 50/60Hz).
- **Environment:** Do not expose the adapter to water, moisture, extreme temperatures, or direct sunlight. Use in a dry, indoor environment.
- **Ventilation:** Do not cover the adapter during use, as this can lead to overheating. Ensure adequate ventilation.
- **Cable Care:** Do not bend, twist, or pull the power cord excessively. Avoid placing heavy objects on the cord.
- **Disconnection:** Always grasp the plug, not the cord, when disconnecting from the wall outlet or the device.
- **Damage:** If the adapter or cord appears damaged, discontinue use immediately and contact customer support. Do not attempt to repair the adapter yourself.
- **Children:** Keep the adapter out of reach of children.

3. Package Contents

Verify that all items are present in the package:

- 1 x SLLEA AC/DC Power Adapter
- 1 x Power Cord (for connecting the adapter to the wall outlet)

4. Setup Instructions

Follow these steps to properly connect your SLLEA AC/DC Adapter to your Casio Privia Digital Piano:

1. **Verify Compatibility:** Before connecting, confirm that your digital piano is a Casio Privia PX-A800 or PX-A800BN model.
2. **Connect Power Cord to Adapter:** Take the included power cord and firmly insert its connector into the AC input port on the SLLEA AC/DC adapter unit.
3. **Connect Adapter to Piano:** Locate the DC input jack on your Casio Privia digital piano. Carefully insert the DC output plug from the SLLEA adapter into this jack. Ensure a snug and secure connection.
4. **Connect to Wall Outlet:** Plug the other end of the power cord (the wall plug) into a standard, grounded electrical wall outlet.
5. **Power On:** Once all connections are secure, you can power on your digital piano using its power button.

Important: Always connect the adapter to the device first, then to the wall outlet. When disconnecting, unplug from the wall outlet first, then from the device.

5. Operating Instructions

The SLLEA AC/DC Adapter is designed for straightforward operation. Once properly connected as described in the "Setup Instructions" section, it will provide continuous power to your digital piano.

- The adapter automatically converts the input AC voltage (100-240V) to the required DC voltage for your piano.
- No user adjustments are required for voltage conversion.
- The adapter is equipped with over-voltage and over-heat protection features to safeguard your device.
- For optimal performance, ensure the adapter is placed in a well-ventilated area during extended use.

6. Maintenance

Proper care will extend the life of your SLLEA AC/DC Adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, unplug the adapter and store it in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cable.
- **Inspection:** Periodically inspect the adapter and its cables for any signs of damage, such as frayed wires, cracks, or discoloration.

7. Troubleshooting

If you encounter issues with your SLLEA AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Piano does not power on.	◦ Adapter not properly connected. ◦ Wall outlet not functioning. ◦ Adapter or cable damage. ◦ Piano's power button is off.	◦ Ensure all connections (adapter to piano, power cord to adapter, power cord to wall) are secure. ◦ Test the wall outlet with another device. ◦ Inspect the adapter and cable for visible damage. If damaged, discontinue use. ◦ Ensure the piano's power button is in the ON position.
Adapter feels hot.	◦ Normal operation (slight warmth). ◦ Poor ventilation. ◦ Overload or internal fault.	◦ A slight warmth is normal. ◦ Ensure the adapter is in a well-ventilated area and not covered. ◦ If excessively hot or emitting smoke/smell, immediately unplug and contact support.
Intermittent power to piano.	◦ Loose connection. ◦ Damaged cable or connector.	◦ Check all connections for looseness. ◦ Inspect the cable and connectors for fraying or bending. Replace if damaged.

If the problem persists after trying these solutions, please contact SLLEA customer support.

8. Specifications

Feature	Detail
Brand	SLLEA
Input Voltage	100-240 VAC
Input Frequency	50/60Hz
Compatibility	Casio Privia PX-A800, PX-A800BN Digital Pianos
Protection Features	Over Voltage Protection, Over Heat Protection

Feature	Detail
ASIN	B075YNZ5Z6
UPC	723044800169

9. Warranty and Support

SLLEA stands behind the quality of its products. The following warranty information is provided:

- **Money Back Guarantee:** 30 Days
- **Free Exchange:** 60 Days (with paid return label)
- **Worry-Free Warranty:** 360 Days Anytime

For any questions, concerns, or warranty claims, please do not hesitate to contact SLLEA customer support. We are here to help.
You can typically find contact information on the seller's page on the platform where you purchased the product, or by searching for "SLLEA customer support" online.

© 2024 SLLEA. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question