Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hikvision DS-7116HQHI-F1/N

Hikvision DS-7116HQHI-F1/N Digital Video Recorder User Manual

Model: DS-7116HQHI-F1/N

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of the Hikvision DS-7116HQHI-F1/N Digital Video Recorder (DVR). This device is designed for video surveillance applications, offering robust recording and management capabilities for security systems.



Figure 1: Front view of the Hikvision DS-7116HQHI-F1/N DVR. This compact white unit features the Hikvision logo on its top surface and ventilation grilles on the side, indicating its fanless design.

2. Safety Information

Please read these safety instructions carefully before operating the device to prevent damage and ensure proper functionality.

- Ensure the power supply voltage is within the specified range (12V DC).
- Do not expose the device to water or moisture.
- Avoid placing the device in direct sunlight or near heat sources.
- Ensure proper ventilation to prevent overheating. This model is fanless, but adequate airflow is still important.
- Use only accessories specified by the manufacturer.

- Do not attempt to disassemble or modify the device. Refer all servicing to qualified personnel.
- Protect power cables from being walked on or pinched.

3. Package Contents

Verify that all items are present in the package:

- Hikvision DS-7116HQHI-F1/N DVR Unit
- Power Adapter
- SATA Cables (for HDD connection)
- Screws (for HDD mounting)
- Quick Start Guide

Note: Hard Disk Drive (HDD) is not included and must be purchased separately.

4. Product Overview

The DS-7116HQHI-F1/N is a Penta-Hybrid DVR supporting multiple video input technologies. It features a compact, fanless design for quiet operation.

4.1 Front Panel

The front panel typically includes status indicators (Power, HDD, Network) and possibly USB ports for mouse or USB drive connection.

4.2 Rear Panel Interfaces

The rear panel provides all necessary connection ports:

- **Video Inputs:** 16 BNC connectors for HDTVI/AHD/CVI/CVBS analog cameras.
- **Audio Input/Output:** 1 RCA audio input, 1 RCA audio output.
- **Video Outputs:** 1 HDMI port, 1 VGA port.
- **Network Interface:** 1 RJ45 Ethernet port (10M/100M).
- **USB Ports:** 2 USB 2.0 ports.
- **Power Input:** 12V DC power jack.

5. Setup

5.1 Physical Installation

1. **Install Hard Disk Drive (HDD):**

- Unscrew and remove the top cover of the DVR.
- Connect the SATA data and power cables to the HDD.
- Secure the HDD to the DVR chassis using the provided screws.
- Replace the top cover and secure it with screws.

2. **Connect Cameras:** Connect your analog HDTVI/AHD/CVI/CVBS cameras to the BNC video input ports on the rear panel.
3. **Connect Monitor:** Connect a monitor to the HDMI or VGA output port.
4. **Connect Mouse:** Connect the USB mouse to one of the USB ports.
5. **Connect Network (Optional):** Connect an Ethernet cable from the DVR's RJ45 port to your router or network switch for remote access.
6. **Connect Power:** Connect the power adapter to the DVR's power input and then plug it into a power outlet. The DVR will power on automatically.

5.2 Initial Configuration

Upon first boot, the DVR will guide you through an initial setup wizard:

- **Set Password:** Create a strong password for the admin user.
- **Configure Network:** Set up network parameters (DHCP or Static IP).
- **Date and Time:** Adjust system date and time settings.
- **HDD Initialization:** Format the newly installed HDD for recording.

6. Operating

6.1 Basic Operations

- **Live View:** After setup, the DVR will display live video feeds from connected cameras on the monitor. Use the mouse to navigate the interface.
- **Recording:** The DVR is configured to record continuously by default after HDD initialization. Recording schedules can be customized in the menu.
- **Playback:**
  - Right-click on the live view screen and select "Playback".
  - Select the desired date and time, and the camera channel for playback.
  - Use the playback controls (play, pause, fast forward, rewind) to review footage.
- **Backup:** Connect a USB flash drive to a USB port. In the menu, navigate to "Backup" to export recorded footage.

6.2 Advanced Features

- **Remote Access:** Configure network settings and use Hik-Connect or other compatible client software/apps to access the DVR remotely via TCP/IP, PPPoE, DHCP, DNS, DDNS, NTP, SADP, NFS, iSCSI, UPnP, HTTPS, ONVIF protocols.
- **Motion Detection:** Set up motion detection zones and sensitivity for specific cameras to trigger recording or alarms.
- **Event Management:** Configure actions for various events, suchs as video loss, tampering, or alarm input.
- **User Management:** Create and manage different user accounts with varying permissions.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your DVR system.

- **Cleaning:** Periodically clean the exterior of the DVR with a soft, dry cloth. Do not use liquid cleaners or aerosols. Ensure ventilation openings are free from dust.
- **Firmware Updates:** Check the official Hikvision website for the latest firmware updates. Follow the provided instructions carefully to update the DVR's firmware, which can improve performance and add new features.
- **Data Backup:** Regularly back up important recorded footage to an external storage device to prevent data loss.
- **System Log Review:** Periodically review system logs for any errors or unusual activities.
- **HDD Health Check:** Monitor the health status of the installed HDD through the DVR's system menu.

8. Troubleshooting

This section addresses common issues you might encounter and provides solutions.

Problem	Possible Cause	Solution
No video display on monitor.	Loose video cable, incorrect input selected on monitor, DVR not powered on.	Check HDMI/VGA cable connections. Ensure monitor is on correct input. Verify DVR power indicator.
No recording.	HDD not installed/initialized, recording schedule not set, HDD full.	Install and initialize HDD. Check recording schedule. Delete old footage or replace HDD.
Cannot access DVR remotely.	Network configuration error, firewall blocking, incorrect port forwarding.	Verify network settings (IP address, gateway, DNS). Check router settings for port forwarding. Disable firewall temporarily for testing.
Poor image quality.	Camera resolution mismatch, cable interference, dirty lens.	Ensure camera resolution is compatible. Check cable quality and connections. Clean camera lens.

9. Specifications

Technical specifications for the Hikvision DS-7116HQHI-F1/N DVR.

Feature	Detail

Feature	Detail
Model Number	DS-7116HQHI-F1/N
Video Inputs	16-channel analog (HDTVI/AHD/CVI/CVBS), plus 1-channel 3MP IP, 1-channel 4MP IP
Video Compression	H.265+/H.265/H.264+/H.264
Audio Input/Output	1-channel RCA / 1-channel RCA
Video Outputs	1 HDMI, 1 VGA
Network Interface	1 RJ45 10M/100M Ethernet
USB Interface	2 USB 2.0 ports
HDD Interface	1 SATA interface, up to 4TB capacity
Power Supply	12V DC, 15W max (without HDD)
Operating Temperature	-10 °C to 55 °C (14 °F to 131 °F)
Dimensions (W x D x H)	21 x 28.5 x 4.5 cm
Weight	1.2 kg (without HDD)

10. Warranty Information

Hikvision products are covered by a limited warranty. Please refer to the official Hikvision website or your local distributor for detailed warranty terms and conditions applicable to your region. Keep your purchase receipt as proof of purchase for warranty claims.

11. Support

For technical assistance, product inquiries, or troubleshooting beyond this manual, please contact Hikvision customer support or your authorized dealer. You can find contact information and additional resources on the official Hikvision website.

- **Online Resources:** Visit the Hikvision official website for FAQs, software downloads, and updated documentation.
- **Technical Support:** Contact the technical support team for specific issues.

© 2024 Hikvision Digital Technology. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07611GMVB

More documents and user manuals: **https://manuals.plus/**