

808 4334207539

808 Singsation Karaoke Microphone Instruction Manual

Model: 4334207539

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your 808 Singsation Karaoke Microphone. Please read this manual thoroughly before using the device to ensure proper function and to maximize your experience.

PRODUCT OVERVIEW

Components

- Singsation Karaoke Microphone with integrated wireless Bluetooth speaker
- USB charging cable (not explicitly listed but implied for battery-powered device)

Key Features

- All-in-one karaoke system
- Wireless Bluetooth connectivity for audio streaming
- Integrated speaker
- LED light effects (14 distinct patterns)
- Voice effects (5 fun effects)
- Sound effects (6 distinct sound effects)
- Echo control
- Up to 6 hours of play time on a single charge
- Compatible with various karaoke music websites and applications







Figure 1: Front view of the 808 Singsation Karaoke Microphone, showcasing its controls and vibrant LED lighting.

SETUP

Charging the Microphone

1. Locate the charging port on the microphone.
2. Connect the provided USB charging cable to the microphone and a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. A full charge provides approximately 6 hours of operation.

Bluetooth Pairing

1. Press and hold the Power button on the microphone until the LED lights activate and a pairing tone is heard. The microphone will enter Bluetooth pairing mode.
2. On your audio device (smartphone, tablet, computer), navigate to the Bluetooth settings.
3. Search for available devices and select "Singsation" from the list.
4. Once paired, a confirmation tone will sound, and the microphone's LED lights may change pattern.
5. You can now stream music wirelessly from your device to the Singsation microphone.



Figure 2: Angled view of the microphone, highlighting its integrated speaker and Bluetooth logo.

OPERATING INSTRUCTIONS

Power On/Off

- Press and hold the **Power** button to turn the microphone on or off.

Volume Control

- Use the **Volume** slider on the microphone to adjust the overall sound output.
- Additional volume control can be managed via your connected Bluetooth device.

Voice Effects (Voice FX)

- Press the **Voice FX** button to cycle through the available voice effects. There are 5 distinct voice effects.

Sound Effects (Sound FX)

- Press the **Sound FX** button to activate various sound effects. There are 6 distinct sound effects.

Echo Control

- Use the **Echo** slider to adjust the intensity of the echo effect on your voice.

LED Light Effects

- The microphone features 14 different LED light patterns that activate automatically.
- Specific controls for cycling through or disabling light effects are not detailed in the product information, suggesting automatic operation.



Figure 3: Users enjoying the Singstation Karaoke Microphone, demonstrating its use in a social setting.

MAINTENANCE

Cleaning

- Wipe the microphone's exterior with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Avoid exposing the microphone to excessive moisture.

Storage

- Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

No Power

- Ensure the microphone is fully charged. Connect it to a power source using the USB cable.
- Verify the power button is pressed and held sufficiently to turn the device on.

Cannot Pair via Bluetooth

- Ensure the microphone is in pairing mode (LEDs flashing, pairing tone).
- Make sure Bluetooth is enabled on your audio device.
- Move the microphone closer to your audio device.
- Turn off and restart both the microphone and your audio device, then attempt pairing again.
- If previously paired, try unpairing and re-pairing the device.

No Sound from Microphone or Speaker

- Check the microphone's volume slider and ensure it is not set to minimum.
- Adjust the volume on your connected Bluetooth device.
- Ensure the microphone is properly paired and connected to your audio device.
- Confirm that the music source on your device is playing.

SPECIFICATIONS

Feature	Detail
Item Weight	1.6 ounces
Product Dimensions	3.54 x 4.33 x 12.2 inches
Item Model Number	4334207539
Date First Available	October 16, 2017
Color	Silver
Compatible Devices	Personal Computer, Smartphone
Connector Type	3.5 mm Jack, USB
Speaker Count	1
Battery Type	Lithium Ion
Power Source	Battery Powered
Special Feature	Wireless

SAFETY INFORMATION

Consumer Alert: Most users do not need a license to operate this wireless microphone system. Nevertheless,

operating this microphone system without a license is subject to certain restrictions: the system may not cause harmful interference; it must operate at a low power level (not in excess of 50 milliwatts); and it has no protection from interference received from any other device.

Always handle the device with care. Avoid dropping or subjecting it to strong impacts. Keep out of reach of small children.

PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.




Video: An overview of the 808 Singstation Karaoke Microphone, demonstrating its features including LED lights, voice effects, and wireless connectivity. This video highlights how the microphone functions as an all-in-one karaoke system.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for warranty claims.

© 2025 808 Audio. All rights reserved.

Related Documents - 4334207539

	<p>Beyerdynamic Wireless Application Guide: TG 1000, Opus 910, Opus 600 Systems</p> <p>A comprehensive application guide for Beyerdynamic's TG 1000, Opus 910, and Opus 600 wireless audio systems. This guide details transmitter options, multichannel configurations, and multi-antenna setups for professional audio applications.</p>
	<p>Wisyscom MTP61 Quick User Guide</p> <p>A concise guide to the Wisyscom MTP61 wireless microphone transmitter, covering setup, operation, accessories, and compliance information.</p>
	<p>MIPRO AT-90W Wideband Directional Antenna User Guide</p> <p>User guide for the MIPRO AT-90W Wideband Multi-function Directional Antenna, detailing its parts, installation, cautions, and coaxial cable specifications for optimal performance in wireless audio systems.</p>




[KONICA MINOLTA V4 Universal Print Driver System Administrator's Guide](#)

This guide provides system administrators with essential information for the Konica Minolta V4 Universal Print Driver, detailing its features, installation, uninstallation, system requirements, and supported bizhub models for Windows environments.



[HAAKE Viscotester 550 Instruction Manual](#)

Comprehensive instruction manual for the HAAKE Viscotester 550 viscometer. Covers setup, operation, safety precautions, technical specifications, and troubleshooting for accurate rheological measurements.



[UDG Equipment Compatibility Guide](#)

Comprehensive guide to UDG bags and cases, detailing compatibility with various DJ controllers, mixers, and music production equipment from brands like Pioneer, Denon, Native Instruments, Numark, Roland, Akai, M-Audio, Reloop, Korg, Novation, Rane, Technics, Stanton, Gemini, and Arturia. Includes dimensions for UDG products and compatible gear.