

GameSir F1

GameSir F1 Mobile Gaming Grip and Joystick User Manual

1. INTRODUCTION

The GameSir F1 Mobile Gaming Grip and Joystick is designed to enhance your mobile gaming experience by providing an ergonomic grip and a physical joystick for improved control. This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your GameSir F1 device.

2. PRODUCT OVERVIEW

The GameSir F1 combines a comfortable, ergonomic grip with a detachable, stick-on joystick. Its telescopic design accommodates various smartphone sizes, ensuring a secure fit. The ergonomic shape is crafted to reduce hand fatigue during extended gaming sessions. The conductive joystick offers precise control for in-game character movement, and a built-in kickstand provides convenient hands-free viewing.



Detachable Joystick

Image 2.1: GameSir F1 Grip with a smartphone, illustrating the detachable joystick and overall ergonomic design.



The grip has an ergonomic design and comfortable feeling to relax your hand fatigue for the long-time gaming.

Image 2.2: Hands holding the GameSir F1 Grip with a smartphone, showcasing the comfortable and secure hold during gameplay.

Video 2.1: Official GameSir F1 demonstration showcasing gameplay with the grip and joystick, highlighting its use in MOBA games.

3. SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove the GameSir F1 grip and the detachable joystick from its packaging.
2. **Adjust Grip Length:** The grip features a telescopic design. Gently pull the sides apart to extend the grip to fit your smartphone. Ensure your phone is securely held by the resilient EVA pads on both inner sides. The grip supports smartphones with screen sizes from 4.5 to 6 inches, and an extensible length of 143mm-186mm.
3. **Attach Joystick:** The joystick has a swing arm design. Position the swing arm on either the left or right side of the grip, depending on your preference. Once positioned, press the joystick firmly onto your smartphone screen over the virtual D-pad or movement control area in your game. The conductive material ensures proper input.
4. **Kickstand Deployment:** For hands-free viewing or gaming, locate the integrated kickstand on the back of the grip and pull it out to support your device.



Compatible with all touch-screen smartphones.
The telescopic boom design allows you to adapt to any size of the smartphone,
even has a case.

Image 3.1: The GameSir F1 Grip extended to accommodate a smartphone, highlighting its telescopic adjustment feature.

4. OPERATING INSTRUCTIONS

1. **Holding the Grip:** Hold the GameSir F1 grip with both hands, similar to a traditional game controller. The ergonomic design is intended to provide comfort during long gaming sessions.

2. **Using the Joystick:** Use your thumb to control the stick-on joystick. The ultra-low-friction design allows for smooth 360-degree movement, providing precise control for character movement in games.
3. **Screen Interaction:** While the joystick handles movement, use your other thumb and fingers to interact with other on-screen controls (buttons, camera movement, etc.) as you normally would.
4. **Game Compatibility:** The GameSir F1 is compatible with any touch-screen smartphone and is ideal for games with on-screen control pads, such as PUBG, Fortnite, Mobile Legends, Arena of Valor, FIFA Mobile, Dragon Nest SEA, and GTA.



Image 4.1: A user actively playing a mobile game with the GameSir F1 Grip, demonstrating the practical application of the joystick and grip.

5. MAINTENANCE

- **Cleaning:** Wipe the grip and joystick with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the product.
- **Joystick Care:** Ensure the conductive surface of the joystick remains clean for optimal responsiveness. If the joystick feels less responsive, gently clean the contact area on both the joystick and your phone screen.
- **Storage:** When not in use, store the GameSir F1 in a clean, dry place away from direct sunlight and extreme temperatures. The swing arm can be flicked up and folded easily for compact storage.

6. TROUBLESHOOTING

- **Joystick Unresponsive/Inaccurate:**
 - Ensure the joystick is firmly pressed onto the screen and correctly aligned with the in-game virtual control pad.

- Clean both the joystick's conductive surface and the smartphone screen to remove any dirt or oils that might interfere with conductivity.
- Verify that your smartphone screen is clean and free of smudges.
- Some phone cases might interfere with the joystick's contact or the grip's fit. Try removing the phone case if you experience issues.

- **Phone Does Not Fit Securely:**

- Ensure the telescopic grip is extended to the correct length for your smartphone.
- The grip supports smartphones with screen sizes between 4.5 and 6 inches, and an extensible length of 143mm-186mm. Check your phone's dimensions against these specifications.
- If using a thick phone case, it might prevent a secure fit. Consider removing the case.

- **Grip Discomfort:**

- Adjust your hand position on the ergonomic grips. Experiment with different holding styles to find what is most comfortable for you.


7. SPECIFICATIONS

Brand	GameSir
Model Name	F1
Compatible Devices	Smartphones (5.5"-6.5" support, 4.5-6 inch screen size, 143mm-186mm extensible length)
Controller Type	Gamepad (Grip with detachable joystick)
Item Weight	5.6 ounces
Product Dimensions	3.86 x 1.54 x 5.91 inches
Hardware Platform	Android (Compatible with all touch-screen smartphones)

4.5-6 inch
Screen Size of Smartphone

76 mm
Width of Inner Space

5-12 mm
Thickness of Smartphone



*Smartphone datas obtained in lab as of Sep 11, 2017. Actual results may vary.

Image 7.1: Diagram illustrating the compatible screen size, inner space width, and thickness for smartphones with the GameSir F1 Grip.

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your GameSir F1 purchase. If you require further assistance or have questions not covered in this manual, please visit the official GameSir website for customer support contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question