Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Redragon K567

Redragon K567 Rahu RGB Mechanical Gaming Keyboard User Manual

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of the Redragon K567 Rahu RGB Mechanical Gaming Keyboard, featuring blue mechanical switches and a detachable palm rest.

1. Setup

Follow these steps to set up your Redragon K567 Rahu mechanical gaming keyboard.

1.1 Package Contents

- Redragon K567 Rahu RGB Mechanical Gaming Keyboard
- Detachable Palm Rest
- User Manual (this document)

1.2 Connecting the Keyboard

1. Locate an available USB port on your computer.
2. Plug the USB connector of the Redragon K567 keyboard into the USB port.
3. The keyboard is plug-and-play and should be automatically recognized by your operating system (Windows 10 or later recommended).

Note: For optimal performance, connect the keyboard directly to a USB port on your computer, not through a USB hub.

1.3 Attaching the Palm Rest

The Redragon K567 Rahu includes a detachable palm rest for enhanced comfort during extended use.

1. Align the palm rest with the bottom edge of the keyboard.
2. Secure the palm rest using the two sturdy metal thumb screws provided, one on each end.



Image: Redragon K567 Rahu keyboard shown with its detachable palm rest separated, illustrating how the two components connect.



Image: Redragon K567 Rahu keyboard with the palm rest securely attached, viewed from an angled perspective.

2. Operation

This section details the primary functions and features of your Redragon K567 Rahu keyboard.

2.1 Key Functions

The Redragon K567 Rahu features full-size layout with standard alphanumeric keys, function keys (F1-F12), a numeric keypad, and navigation keys. The keyboard utilizes blue mechanical switches, known for their tactile bump and audible click, providing responsive feedback for typing and gaming.



Image: The Redragon K567 Rahu mechanical gaming keyboard displaying its full layout with vibrant RGB backlighting active.

2.2 RGB Backlighting Control

The keyboard features dynamic RGB backlighting with multiple patterns and customization options, accessible directly from the keyboard without software.

- **Changing Lighting Modes:** Use the dedicated lighting control keys (often marked with light bulb icons or specific function key combinations) to cycle through various preset RGB effects.
- **Adjusting Brightness:** Typically controlled via Fn + Up/Down arrow keys.
- **Adjusting Speed/Direction:** Some modes allow adjustment of effect speed or direction using Fn + Left/Right arrow keys.
- **Customization:** Refer to the specific key combinations printed on the keyboard or included quick start guide for advanced per-key or zone customization if available.



Image: A close-up view of the Redragon K567 Rahu keyboard keys, highlighting the individual RGB backlighting and keycap legends.

2.3 Function Key Combinations (Fn)

The Fn key (Function key) can be combined with other keys to access multimedia controls and other special functions. Specific combinations may vary, but common functions include:

- **Fn + F1-F12:** Multimedia controls (e.g., Play/Pause, Stop, Volume Up/Down, Mute, Previous/Next Track).
- **Fn + Windows Key:** Locks/unlocks the Windows key to prevent accidental presses during gaming.
- **Fn + PrtSc/ScrLk/Pause:** May control additional lighting effects or keyboard modes.

Consult the keycap legends for specific Fn key combinations on your keyboard.

3. Maintenance

Proper maintenance ensures the longevity and optimal performance of your keyboard.

3.1 Cleaning the Keyboard

- **General Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and keyboard surface. Avoid harsh chemicals.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keycaps.
- **Deep Cleaning:** For thorough cleaning, keycaps can be carefully removed using a keycap puller (not included) and cleaned separately. Ensure the keyboard is unplugged before removing keycaps.

3.2 Palm Rest Care

The detachable palm rest can be cleaned with a damp cloth. Avoid abrasive cleaners that may damage the surface material.

3.3 Storage

When not in use for extended periods, store the keyboard in a dry, dust-free environment. Avoid extreme temperatures.

4. Troubleshooting

This section addresses common issues you might encounter with your Redragon K567 Rahu keyboard.

4.1 Keyboard Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into both the keyboard and the computer. Try a different USB port.
- **Restart Computer:** A simple system restart can often resolve connectivity issues.
- **Test on Another Computer:** If possible, test the keyboard on a different computer to determine if the issue is with the keyboard or the computer's setup.
- **Driver Issues:** While the keyboard is plug-and-play, ensure your operating system's USB drivers are up to date.

4.2 Specific Keys Not Working

- **Clean Key:** Check for any debris or foreign objects lodged under the non-responsive keycap. Use compressed air.
- **Keycap Re-seating:** Carefully remove and re-seat the keycap to ensure it is properly aligned with the switch.
- **Software Interference:** Ensure no background applications or macros are interfering with key inputs.

4.3 RGB Lighting Not Functioning Correctly

- **Check Brightness Settings:** Ensure the brightness is not set to the lowest level. Adjust using Fn + Up arrow.
- **Cycle Modes:** Cycle through different lighting modes to see if the issue persists across all modes.
- **Power Cycle:** Unplug the keyboard, wait a few seconds, and plug it back in.

4.4 BIOS Boot-up Issues

On some older computer motherboards, the keyboard might not boot up correctly to allow access to the BIOS. If this occurs, try connecting a basic, non-RGB keyboard for BIOS access, or consult your motherboard's manual for specific USB legacy support settings.

5. Specifications

Brand	Redragon
Model	K567 Rahu
Keyboard Type	Mechanical
Switch Type	Blue Mechanical Switches
Connectivity	USB Wired

Backlighting	RGB (Multiple modes)
Construction Material	Aircraft-Grade Aluminium (Top Plate), Polycarbonate (Base)
Operating System Compatibility	Windows 10 (and compatible with earlier versions)
Dimensions (L x W x H)	43.43 x 12.45 x 3.81 cm (17.1 x 4.9 x 1.5 inches)
Weight	1.3 kg (2.87 lbs)
Special Features	Detachable Palm Rest, Full N-Key Rollover, Anti-Ghosting

6. Warranty and Support

6.1 Product Warranty

Redragon products typically come with a limited manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Redragon website for detailed warranty terms and conditions specific to your region.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Redragon customer support. Contact information can usually be found on the official Redragon website or on the product packaging.
It is recommended to have your product model number (K567) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0763RMTPX

More documents and user manuals: **https://manuals.plus/**