

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Stokke](#) /

› Stokke Tripp Trapp Tray (Model 228702) Instruction Manual

Stokke 228702

Stokke Tripp Trapp Tray (Model 228702) Instruction Manual

Brand: Stokke

Model: 228702

INTRODUCTION

This manual provides essential information for the safe and effective use of your Stokke Tripp Trapp Tray. The tray is designed to enhance the versatility of your Tripp Trapp high chair, offering a convenient surface for meals and activities. It is constructed from BPA-free plastic for easy cleaning and is specifically designed for use with the Stokke V2 Baby Set.



Image: The Stokke Tripp Trapp Tray in black, depicted in an outline of a high chair, highlighting its form and integration.

SETUP AND INSTALLATION

The Tripp Trapp Tray is designed for straightforward attachment and removal. Ensure your Tripp Trapp chair is equipped with the Stokke V2 Baby Set before proceeding.

1. **Positioning:** Align the tray with the front of the Baby Set. The tray is designed to fit snugly around the child's seating area.
2. **Attachment:** Gently push the tray downwards until you hear a distinct "click" sound. This indicates that the tray is securely locked into place.
3. **Verification:** After attachment, lightly pull upwards on the tray to ensure it is firmly secured and does not wobble.

To remove the tray, locate the release button or latch positioned underneath the tray, typically at the front center. Press this button while simultaneously lifting the tray upwards. The tray should detach easily for cleaning or storage.

Your browser does not support the video tag.

Video: Demonstrates the installation and removal process of the Stokke Tripp Trapp Tray, highlighting the secure click mechanism and the release button for easy detachment.

OPERATING INSTRUCTIONS

The Tripp Trapp Tray provides a stable and accessible surface for your child during meals and playtime. Its design helps contain food and spills, making mealtimes more manageable.

- **Mealtime Use:** Place food directly on the tray or use plates and bowls. The raised edges help prevent items from falling off.
- **Activity Surface:** The tray can also be used as a surface for toys or drawing activities, keeping items within your child's reach.
- **Compatibility:** Designed to be used with the Stokke V2 Baby Set, ensuring a secure and ergonomic fit for your child.



Tray shown in White. Chair and Cushion sold separately.

Image: A baby enjoying a meal with avocado slices placed directly on the Stokke Tripp Trapp Tray, demonstrating practical use.

MAINTENANCE AND CLEANING

Maintaining the cleanliness of your Tripp Trapp Tray is simple due to its BPA-free plastic construction.

- **Daily Cleaning:** For everyday spills and food residue, wipe the tray with a damp cloth and mild soap. Rinse thoroughly and dry.
- **Dishwasher Safe:** The tray is dishwasher safe for a more thorough cleaning. Place it on the top rack.
- **Stain Prevention:** To prevent staining, especially from highly pigmented foods, clean the tray immediately after use.

Your browser does not support the video tag.

Video: Illustrates the ease of cleaning the Tripp Trapp Tray, showing how quickly food residue can be wiped away.

FEATURES

Adds versatility to your Tripp Trapp® Chair and High Chair



Designed to be used only with
the Tripp Trapp® Baby Set



Dishwasher safe



Easy-to-clean, BPA-free plastic

Image: A graphic highlighting the key features of the tray: dishwasher safe, easy-to-clean BPA-free plastic, and designed for use with the Tripp Trapp Baby Set.

TROUBLESHOOTING

- **Difficulty Attaching/Removing:** Ensure the Baby Set is correctly installed on the Tripp Trapp chair. For removal, firmly press the release button underneath the tray while lifting. If resistance is met, re-check alignment.
- **Food Accumulation on Underside:** The underside of the tray features a honeycomb pattern for structural integrity. While this can sometimes trap food, rinsing immediately after use can prevent accumulation. For stubborn residue, a brush can be used.
- **Staining:** Although the BPA-free plastic is designed to resist stains, highly pigmented foods (e.g., tomato sauce, carrots) left for extended periods may cause discoloration. Prompt cleaning is recommended.

SPECIFICATIONS

Product Dimensions	18.1 x 12.6 x 1.6 inches
Item Model Number	228702
Material Type	Plastic (BPA-free)
Item Weight	1.31 pounds (0.6 Kilograms)
Color	Black
Is Portable	Yes
Age Range (Description)	Baby, Infant (when used with Baby Set)



Length: 18.1 in / Height: 1.6 in / Width: 12.6 in

Image: An overhead view of the Tripp Trapp Tray, illustrating its dimensions for reference.

WARRANTY INFORMATION

For detailed warranty information regarding your Stokke Tripp Trapp Tray, please refer to the official Stokke website or contact Stokke customer service directly. Warranty terms and conditions may vary by region and purchase date.

CUSTOMER SUPPORT

Should you require further assistance, have questions about product use, or need to report an issue, please visit the official Stokke website for their comprehensive support resources, FAQs, and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07644Q5ZY>

More documents and user manuals: <https://manuals.plus/>