

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lorell](#) /

› [Lorell 10-watt LED Bulb Table Lamp Model 99966 User Manual](#)

Lorell 99966

Lorell 10-watt LED Bulb Table Lamp User Manual

Model: 99966

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembling and using this lamp. Retain this manual for future reference.

- **Electrical Safety:** Ensure the power cord is not damaged. Do not operate the lamp if the cord or plug is damaged. Do not use with an extension cord unless the plug can be fully inserted.
- **Placement:** Place the lamp on a stable, flat surface to prevent tipping. Keep away from water and moisture.
- **Bulb Handling:** Always disconnect power before replacing the bulb. Allow the bulb to cool before touching. Use only the specified bulb type and wattage (10-watt LED).
- **Indoor Use Only:** This lamp is designed for indoor use in dry locations.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Base (Brushed Nickel)
- Lamp Pole (Brushed Nickel)
- Lamp Shade (White Linen)
- 10-watt LED Bulb





Image: The Lorell 10-watt LED Bulb Table Lamp, featuring a brushed nickel base and pole, topped with a cylindrical white

linen shade. The lamp is shown fully assembled.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Lorell Table Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a clean, flat surface.
2. **Attach Lamp Pole to Base:** Screw the threaded end of the lamp pole clockwise into the lamp base until it is securely tightened. Ensure the pole is straight and stable.
3. **Install LED Bulb:** Carefully screw the provided 10-watt LED bulb into the lamp socket located at the top of the lamp pole. Do not overtighten.
4. **Place Lamp Shade:** Position the white linen lamp shade over the bulb and onto the shade holder (usually a ring or saddle above the bulb socket). Secure it in place if there is a retaining ring or finial.
5. **Final Check:** Ensure all connections are secure and the lamp is stable on its base.

OPERATING INSTRUCTIONS

To operate your Lorell Table Lamp:

- **Connect Power:** Plug the lamp's power cord into a standard 120-volt AC electrical outlet.
- **Turn On/Off:** Locate the push-button switch, typically on the lamp base or cord. Press the button once to turn the lamp on, and press it again to turn the lamp off.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your lamp:

- **Cleaning the Base and Pole:** Wipe the brushed nickel finish with a soft, dry cloth. Do not use abrasive cleaners or polishes, as they may damage the finish.
- **Cleaning the Shade:** Gently dust the linen shade with a soft brush or a lint roller. For minor spots, dab with a slightly damp cloth and allow to air dry completely.
- **Bulb Replacement:** Always unplug the lamp before replacing the LED bulb. Allow the bulb to cool completely. Replace with a 10-watt LED bulb (B10 shape size).

TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on	<ul style="list-style-type: none"> Lamp not plugged in Loose bulb Faulty outlet Damaged switch 	<ul style="list-style-type: none"> Ensure the lamp is securely plugged into a working outlet. Tighten the bulb in the socket. Test the outlet with another device. Contact customer support if the switch is damaged.
Bulb flickers	<ul style="list-style-type: none"> Loose bulb Incorrect bulb type Power fluctuations 	<ul style="list-style-type: none"> Tighten the bulb. Ensure you are using a 10-watt LED bulb. Try plugging the lamp into a different outlet.
Lamp is unstable	<ul style="list-style-type: none"> Base not securely attached to pole Uneven surface 	<ul style="list-style-type: none"> Ensure the lamp pole is fully tightened into the base. Place the lamp on a flat, stable surface.

PRODUCT SPECIFICATIONS

Model Name	10-watt LED Bulb Table Lamp
Model Number	99966
Brand	Lorell
Dimensions (D x W x H)	11.02" x 10" x 22"
Item Weight	3.08 pounds
Material	Brushed Nickel (Base/Pole), Linen (Shade)
Finish Type	Brushed
Shade Color	White
Light Source Type	LED
Wattage	10 watts
Voltage	120 Volts
Switch Type	Push Button
Power Source	Corded Electric
Assembly Required	Yes

Indoor/Outdoor Usage	Indoor
----------------------	--------

WARRANTY AND SUPPORT

This Lorell Table Lamp is covered by a **90-day warranty** from the date of purchase, covering defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or replacement parts, please contact Lorell customer support. Keep your purchase receipt as proof of purchase.

Customer Support: Please refer to the contact information provided with your purchase or visit the official Lorell website for support details.