

[manuals.plus](#) /

› [Smeg](#) /

› [Smeg KLF03PGEU Electric Kettle User Manual](#)

Smeg KLF03PGEU

Smeg KLF03PGEU Electric Kettle User Manual

Model: KLF03PGEU

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Smeg KLF03PGEU Electric Kettle. Please read these instructions carefully before first use and retain them for future reference.

2. SAFETY INSTRUCTIONS

- Ensure the kettle is connected to a grounded power outlet.
- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not operate the kettle if the power cord or plug is damaged.
- Avoid overfilling the kettle beyond the maximum fill line to prevent boiling water from spilling.
- Always close the lid securely before operating.
- Do not touch hot surfaces. Use the handle.
- Unplug the kettle from the outlet when not in use and before cleaning.
- This appliance is for household use only.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Smeg KLF03PGEU Electric Kettle:

- **Kettle Body:** The main housing of the kettle.
- **Lid:** Hinged lid with a soft opening system for easy filling.
- **Handle:** Ergonomically designed for safe pouring.
- **Spout:** Designed for controlled pouring.
- **Water Level Indicator:** Transparent window showing water volume (1.7L / 7 cups max capacity).
- **On/Off Lever:** Integrated lever to start and stop the boiling process.
- **Power Base:** 360° cordless base with anti-slip feet.

- **Anti-Calc Filter:** Removable stainless steel filter located in the spout.
- **Concealed Heating Element:** For efficient heating and easy cleaning.



Figure 3.1: Front view of the Smeg KLF03PGEU electric kettle in pale green, showcasing the 'SMEG' logo and chrome accents.



Figure 3.2: Side view of the Smeg KLF03PGEU electric kettle in pale green, highlighting the spout and handle design.



Figure 3.3: Side view of the Smeg KLF03PGEU electric kettle in pale green, showing the water level indicator window and the on/off lever.

4. SETUP

- 1. Unpacking:** Carefully remove the kettle and all accessories from the packaging. Dispose of packaging materials responsibly.
- 2. Initial Cleaning:** Before first use, fill the kettle with cold water up to the MAX level. Boil the water, then discard it. Repeat this process twice to remove any manufacturing residues.
- 3. Placement:** Place the power base on a stable, flat, heat-resistant surface, away from the edge of the countertop. Ensure the power cord does not hang over the edge.

4. **Power Connection:** Plug the power cord into a suitable 240V AC electrical outlet.

5. OPERATING INSTRUCTIONS

1. **Filling the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of fresh cold water, ensuring it is between the MIN and MAX fill lines indicated on the water level indicator. Close the lid firmly until it clicks.
2. **Placing on Base:** Place the kettle securely onto its 360° power base.
3. **Boiling Water:** Push the On/Off lever downwards. The indicator light will illuminate, signifying that the kettle is heating. The kettle will automatically switch off once the water has boiled, and the lever will return to its original position.
4. **Pouring:** Carefully lift the kettle from the power base and pour the hot water. Always pour slowly and steadily to avoid splashing.
5. **Re-boiling:** If the kettle has just boiled, allow a few moments for the internal thermostat to reset before attempting to re-boil.

6. MAINTENANCE AND CLEANING

6.1 Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the finish.
- Ensure no moisture enters the electrical components.

6.2 Interior Cleaning and Descaling

Regular descaling is essential to maintain performance and prolong the life of your kettle, especially in hard water areas.

- **Filter Cleaning:** The stainless steel anti-calc filter can be removed for cleaning. Rinse it under running water and gently brush away any scale deposits. Reinsert the filter securely.
- **Descaling:** Use a commercially available descaling solution suitable for kettles. Follow the manufacturer's instructions for the descaling product. Alternatively, a solution of white vinegar and water (1:2 ratio) can be used. Fill the kettle with the descaling solution, boil, and let it stand for the recommended time (or about 30 minutes for vinegar solution). Rinse the kettle thoroughly several times with fresh water after descaling.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	No power supply. Kettle not properly seated on base. Overheat protection activated.	Check power outlet. Ensure kettle is correctly placed on the base. Allow kettle to cool down for 15-20 minutes.
Water takes too long to boil.	Excessive limescale build-up.	Descale the kettle as per maintenance instructions.

Problem	Possible Cause	Solution
Kettle switches off before boiling.	Limescale build-up. Kettle overfilled.	Descale the kettle. Do not fill above the MAX line.
Water leaks from the spout.	Lid not closed properly. Kettle overfilled.	Ensure lid is securely closed. Do not fill above the MAX line.

8. SPECIFICATIONS

- Brand:** Smeg
- Model Number:** KLF03PGEU
- Color:** Pale Green
- Capacity:** 1.7 Litres (7 cups)
- Power:** 2400 Watts
- Voltage:** 240 Volts
- Material:** Plastic (exterior), Stainless Steel (filter)
- Dimensions (L x W x H):** 22.6 x 17.1 x 24.8 cm
- Weight:** 1.6 Kilograms
- Special Features:** Anti-slip feet, Integrated on/off button, Overheat safety cut-out, Water level indicator, Anti-calc filter, Concealed heating element, Automatic power off, Cordless, 360° base, Lockable lid, Hinged lid.



9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Smeg website. You may also contact Smeg customer service directly for assistance.

Official Smeg Website: www.smeg.com

Related Documents - KLF03PGEU

	<p>Smeg KLF04 Variable Temperature Kettle Instruction Manual</p> <p>Comprehensive instruction manual for the Smeg KLF04 Variable Temperature Kettle, covering safety, usage, cleaning, and troubleshooting.</p>
---	---

	<p><u>SMEG WKF01RD Stove Top Kettle - Instruction Manual</u></p> <p>Official instruction manual for the SMEG WKF01RD stove top kettle, covering intended use, safety instructions, operation, cleaning, and maintenance.</p>
	<p><u>SMEG KLF03 Kettle: Instruction Manual and User Guide</u></p> <p>Comprehensive instruction manual for the SMEG KLF03 kettle, covering safety, usage, cleaning, maintenance, and troubleshooting. Features iconic design and innovative technical solutions.</p>
	<p><u>Smeg KLF04 Variable Temperature Kettle User Manual and Guide</u></p> <p>Comprehensive user manual for the Smeg KLF04 Variable Temperature Kettle, covering instructions, safety, operation, cleaning, maintenance, and troubleshooting. Learn how to use your Smeg kettle effectively and safely.</p>
	<p><u>Smeg KLF05 Kettle Instruction Manual - Safety, Usage, and Cleaning Guide</u></p> <p>Comprehensive instruction manual for the Smeg KLF05 Kettle. Learn about safe operation, first use, cleaning, descaling, and troubleshooting for your Smeg electric kettle.</p>
	<p><u>Smeg KLF04 Variable Temperature Kettle User Manual</u></p> <p>Comprehensive user manual for the Smeg KLF04 Variable Temperature Kettle, covering instructions, product description, usage, cleaning, maintenance, and troubleshooting.</p>