Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NutriChef PWIRBBQ60

NutriChef PWIRBBQ60 Smart Bluetooth BBQ Grill Thermometer

Model: PWIRBBQ60 | Brand: NutriChef

Introduction

The NutriChef PWIRBBQ60 Smart Bluetooth BBQ Grill Thermometer is designed to provide accurate and reliable temperature readings for your grilling and smoking needs. With its digital display, dual stainless steel probes, and wireless remote alert capabilities via a smartphone app, it offers a hassle-free way to monitor your food's temperature from a distance.



Image: The NutriChef PWIRBBQ60 thermometer unit with its two stainless steel probes, showcasing the digital display and compact design.

What's in the Box

- Smart BBQ Thermometer Unit
- (2) Temperature Probes
- AA Batteries (2)

Setup Guide

1. **Install Batteries:** Open the battery compartment on the back of the thermometer unit and insert the two AA batteries provided, ensuring correct polarity.



Image: A hand inserting AA batteries into the battery compartment located on the back of the NutriChef thermometer unit.

2. **Download the EasyBBQ App:** Search for "EasyBBQ" in the Apple App Store (for iOS devices) or Google Play Store (for Android devices) and download the application.
3. **Pair with Smartphone:**
    - Ensure Bluetooth is enabled on your smartphone.
    - Turn on the NutriChef thermometer unit.
    - Open the EasyBBQ app. The app should automatically detect and connect to the thermometer. Follow any on-screen prompts to complete the pairing process.
4. **Connect Probes:** Insert the stainless steel temperature probes into the designated ports on the thermometer unit. The unit supports dual probes for simultaneous monitoring.



Image: The NutriChef thermometer unit with both temperature probes connected, highlighting the device's 200-foot Bluetooth range and upgraded stainless steel probes.

Operating Instructions

1. **Insert Probes into Food:** Carefully insert the tip of each probe into the thickest part of the meat, avoiding bones. Ensure the probe is fully inserted to get an accurate internal temperature reading.



Image: The NutriChef thermometer displaying a temperature reading, with the EasyBBQ app available on Google Play and the App Store.

2. **Monitor Temperature:**
    - The digital LCD display on the thermometer unit will show the current temperature readings, cycling between probes.
    - For detailed monitoring, open the EasyBBQ app on your smartphone. The app displays real-time temperatures for each probe.
    - You can switch between Fahrenheit and Celsius units within the app settings.
3. **Set Target Temperatures and Alarms:**
    - The EasyBBQ app includes preset temperatures for various types of meat (e.g., beef, chicken, pork) and doneness levels. Select the appropriate preset for your cooking.
    - You can also customize target temperatures and create new presets for specific recipes.
    - Once the food reaches the set target temperature, the app will send push notifications and sound an alarm on your smartphone, alerting you that your food is done.
4. **Wireless Range:** The thermometer offers an outdoor wireless range of 200+ feet and an indoor range of 100+ feet, allowing you to monitor your cooking from a distance.

Maintenance

- **Probe Cleaning:** After each use, clean the stainless steel probes with warm, soapy water. Wipe them thoroughly dry before storage. Do not immerse the entire probe or the cable connection in water.
- **Unit Cleaning:** Wipe the thermometer unit with a damp cloth. Do not submerge the unit in water.
- **Storage:** Store the thermometer and probes in a dry place when not in use.
- **Battery Replacement:** Replace AA batteries when the display dims or the unit fails to power on.
- **Safety Precaution:** Avoid placing the probes directly over open flames, as this can damage them. The probes can withstand temperatures up to 482°F (250°C), and the stainless steel cable wire up to 716°F (380°C).

Troubleshooting

- **No Power/Display Off:**
  - Check if batteries are installed correctly and have sufficient charge. Replace if necessary.
  - Ensure the power button is pressed firmly.
- **App Connectivity Issues:**
  - Ensure Bluetooth is enabled on your smartphone and the thermometer unit is powered on and within range.
  - Restart both the app and the thermometer unit.
  - Try unpairing and re-pairing the device in your phone's Bluetooth settings and within the EasyBBQ app.
  - Ensure your smartphone's operating system is compatible (iOS 4s & later, Android 4.3 & later).
- **Inaccurate Temperature Readings:**
  - Ensure the probe is inserted correctly into the thickest part of the food, avoiding bones.
  - Check for any visible damage to the probe or cable. If a probe is damaged, it may need replacement.
  - Verify that the probe connector is clean and fully inserted into the thermometer unit's port.
- **No Alarm/Notifications:**
  - Check your smartphone's notification settings to ensure the EasyBBQ app has permission to send alerts.
  - Verify that target temperatures are correctly set within the app.
  - Ensure the phone is within the wireless range of the thermometer.

Specifications

Model Name	PWIRBBQ60
Brand	NutriChef
Max Probe Temperature	482°F (250°C)
Max Stainless Steel Cable Temperature	716°F (380°C)
Battery Operated	Requires (2) x AA Batteries
Bluetooth Support	Version 4.0 & Later
Smartphone Support	iPhones 4s, Android 4.3 & Later
Outdoor Wireless Range	200+ ft
Indoor Wireless Range	100+ ft

Temperature Probe Construction	Stainless Steel
Dimensions (L x W x H)	2.6" x 2.8" x 1.1"
Display Type	LCD
Response Time	0.5 seconds

Warranty Information

Warranty details for the NutriChef PWIRBBQ60 Smart Bluetooth BBQ Grill Thermometer are typically provided with your purchase or can be found on the official NutriChef website. Please refer to the documentation included in your product packaging for specific terms and conditions.

Support

For further assistance, technical support, or inquiries regarding your NutriChef PWIRBBQ60 thermometer, please visit the official NutriChef website or contact their customer service department. Contact information is usually available on the product packaging or their website.

© 2025 NutriChef. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07658YHCS

More documents and user manuals: **https://manuals.plus/**