

Squier SA-150

Squier by Fender SA-150 Dreadnought Acoustic Guitar User Manual

Model: SA-150 | Brand: Squier by Fender

1. INTRODUCTION AND OVERVIEW

The Squier by Fender SA-150 is a full-size steel-string acoustic guitar designed to offer a rich sound at an accessible price point. Its all-laminate construction, featuring a lindenwood top and mahogany back and sides, ensures durability for everyday use. The guitar boasts scalloped "X"-bracing, a mahogany neck, and a durable dark-stained maple fingerboard, contributing to both its aesthetic appeal and tonal quality. With its slim, easy-to-play neck and full-bodied dreadnought tone, the SA-150 is an excellent choice for aspiring guitarists.



Figure 1: Squier by Fender SA-150 Dreadnought Acoustic Guitar in Natural finish.

2. KEY FEATURES

- **Dreadnought Body:** This guitar's dreadnought body shape resonates with a bold and rich bass tone, ideal for various musical genres including country, folk, or bluegrass.
- **Durable Materials:** All-Laminate construction ensures longevity and consistent sound quality at an affordable price.
- **Rock Steady Tuners:** Chrome die-cast tuners provide stable tuning with optimal tension, resisting dust and grime.
- **2-Year Limited Warranty:** Fender guitars are built with unmatched quality. This guitar is warranted to be free from defects in materials and workmanship for two (2) years from the original purchase date.

**Traditional Dreadnought Body Shape
provides excellent tonal balance & projection**




Figure 2: Key structural features of the SA-150 Dreadnought Acoustic Guitar.

SCALLOPED "X" -BRACING, MAHOGANY NECK AND A DURABLE DARK-STAINED MAPLE FINGERBOARD



Figure 3: Detailed view of the soundhole, bridge, and fingerboard construction.

3. SETUP

1. **Unboxing:** Carefully remove the guitar from its packaging. Inspect for any visible damage during transit.
2. **Initial Inspection:** Check all components, including the neck, body, bridge, and tuners, for any loose parts or imperfections.
3. **Tuning:** The guitar comes with alloy steel strings. Use a reliable tuner (clip-on or app-based) to tune the strings to standard E-A-D-G-B-e tuning. Gently stretch new strings to help them settle and hold tune better.
4. **Comfort Adjustment:** Ensure the guitar is comfortable to hold and play. The slim neck is designed for ease of use, especially for beginners.

4. OPERATING YOUR GUITAR

The Squier SA-150 is a traditional acoustic guitar, producing sound through the vibration of its strings and the resonance of its hollow body. No external amplification is required for typical use. To play, hold the guitar

comfortably, ensuring your fretting hand can easily reach all frets on the mahogany neck and your strumming hand can freely move over the strings. Experiment with different strumming patterns and fingerpicking techniques to explore the guitar's full tonal range.

5. MAINTENANCE

- **Cleaning:** Wipe down the guitar body and neck with a soft, lint-free cloth after each use to remove sweat and oils. For a deeper clean, use guitar-specific cleaning products sparingly.
- **String Care:** Replace strings regularly, typically every 1-3 months depending on usage, to maintain optimal tone and playability. When replacing, change one string at a time to maintain neck tension.
- **Storage:** Store the guitar in a stable environment, away from extreme temperature changes or humidity fluctuations. A guitar case or gig bag is recommended for protection.
- **Tuner Maintenance:** The chrome die-cast tuners are designed for durability. Keep them clean and free of debris to ensure smooth operation.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Guitar won't stay in tune	New strings, improper string winding, environmental changes, worn tuners.	Stretch new strings thoroughly. Ensure strings are properly wound around tuning posts. Allow guitar to acclimate to environment. Check tuners for looseness.
Buzzing sound from strings	Improper fretting, low action, worn frets, loose hardware.	Ensure proper finger placement when fretting. Consult a professional for action adjustment or fret repair. Check for loose screws on bridge or tuners.
Dull or muted tone	Old strings, dirty fretboard, improper playing technique.	Replace strings. Clean fretboard. Practice proper strumming/picking technique.

7. SPECIFICATIONS

Attribute	Detail
Model Number	SA-150
Item Weight	6 pounds
Product Dimensions	25.5 x 6 x 42 inches
Body Material	Basswood
Top Material	Maple Wood
Back Material	Maple Wood
Neck Material Type	Mahogany

Attribute	Detail
Fretboard Material	Mahogany Wood
String Material	Alloy Steel
Number of Strings	6
Hand Orientation	Right
Color	Natural

8. WARRANTY AND SUPPORT

The Squier by Fender SA-150 Dreadnought Acoustic Guitar comes with a **2-Year Limited Warranty**. This warranty covers defects in materials and workmanship from the date of original purchase. For detailed warranty information, claims, or technical support, please refer to the official user manual or contact Fender customer service. For a complete guide and additional information, please download the official User Manual (PDF) [Download User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question