

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Nexus](#) /
- › [Nexus Revo Slim Rotating Prostate Massager Instruction Manual](#)

Nexus REVOSLIM

Nexus Revo Slim Rotating Prostate Massager Instruction Manual

Model: REVOSLIM

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your Nexus Revo Slim Rotating Prostate Massager. Please read this manual thoroughly before first use and retain it for future reference. The Nexus Revo Slim is designed for targeted stimulation, featuring a rotating head and multiple vibration modes.

2. IMPORTANT SAFETY INFORMATION

- **Read all instructions:** Familiarize yourself with all functions and safety precautions before operating the device.
- **Personal Use Only:** This device is intended for personal use.
- **Consult a Physician:** If you have any medical conditions or concerns, consult a healthcare professional before using this device. Discontinue use if you experience any pain or discomfort.
- **Lubrication:** Always use a water-based lubricant with this device. Oil-based lubricants can damage silicone materials.
- **Cleaning:** Clean the device thoroughly before and after each use as described in the Maintenance section.
- **Charging:** Use only the provided charging cable. Do not use the device while it is charging.
- **Waterproof:** The device is waterproof, allowing for easy cleaning and use in wet environments. However, avoid prolonged submersion in deep water.
- **Storage:** Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Damage:** Do not use the device if it appears damaged or if the silicone material is torn or compromised.

3. PRODUCT COMPONENTS

Your Nexus Revo Slim package includes the following items:

- Nexus Revo Slim Rotating Prostate Massager
- USB Charging Cable
- Instruction Manual (this document)



Image 3.1: The Nexus Revo Slim massager shown with its retail packaging.



Image 3.2: The Nexus Revo Slim device, highlighting the control panel at the base.

4. SETUP AND CHARGING

4.1 Initial Charge

Before first use, fully charge your Nexus Revo Slim. The device uses a Lithium Polymer battery.

1. Locate the charging port on the device. This is typically a small magnetic or covered port.
2. Connect the provided USB charging cable to the device's charging port.
3. Connect the other end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The indicator light on the device will illuminate or flash to show it is charging. Refer to the device's specific light indicators for charging status (e.g., solid light for fully charged, flashing for charging).
5. Allow the device to charge completely. Charging time may vary, but typically takes 2-4 hours for a full charge.
6. Once fully charged, disconnect the charging cable.

4.2 Cleaning Before First Use

Before using your Nexus Revo Slim for the first time, clean it thoroughly according to the instructions in the Maintenance section to ensure hygiene.

5. OPERATING INSTRUCTIONS

The Nexus Revo Slim features 6 stimulation modes and 2 shaft rotation speeds. Familiarize yourself with the controls before use.

5.1 Controls

The device typically has a power button and one or more function buttons to cycle through modes and speeds. Refer to Image 3.2 for button locations.

- **Power Button:** Press and hold for 2-3 seconds to turn the device ON or OFF.
- **Vibration Mode Button:** Short press to cycle through the 6 vibration modes.
- **Rotation Speed Button:** Short press to cycle through the 2 rotation speeds.

5.2 Usage

1. Ensure the device is fully charged and clean.
2. Apply a generous amount of water-based lubricant to the device and the area of application.
3. Press and hold the Power Button to turn the device ON.
4. Use the Vibration Mode Button to select your desired stimulation pattern.
5. Use the Rotation Speed Button to adjust the speed of the rotating head.
6. Gently introduce the device and explore the sensations. The slim design is suitable for beginners.
7. When finished, press and hold the Power Button to turn the device OFF.
8. Clean the device immediately after use.



Image 5.1: Angled view of the Nexus Revo Slim, showcasing its ergonomic shape.



Image 5.2: Close-up of the textured area designed for perineum stimulation.

6. MAINTENANCE

6.1 Cleaning

Proper cleaning ensures hygiene and prolongs the life of your device.

1. After each use, wash the device thoroughly with warm water and a mild, toy-safe soap.
2. Rinse completely to remove all soap residue.
3. Dry the device with a lint-free cloth or allow it to air dry completely before storing.
4. Do not use harsh chemicals, alcohol-based cleaners, or abrasive materials, as these can damage the silicone.

6.2 Storage

Store your Nexus Revo Slim in a clean, dry, and dust-free environment. Keep it away from extreme temperatures, direct sunlight, and other toys made of different materials to prevent potential reactions or damage to the silicone.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device does not vibrate or rotate.	Battery is low or depleted. Incorrect button press.	Ensure the device is fully charged. Press and hold the power button for 2-3 seconds to turn on. Short press function buttons to activate modes.
Device not charging.	Cable not properly connected. Faulty cable or power source.	Ensure the USB cable is securely connected to both the device and the power source. Try a different USB port or power adapter.
Reduced performance.	Low battery.	Recharge the device.

If you experience issues not listed here or if the suggested solutions do not resolve the problem, please contact customer support.

8. SPECIFICATIONS

- **Model:** REVOSLIM
- **Material:** Body-safe Silicone (over plastic core)
- **Dimensions:** Approximately 7.09 x 7.09 x 1.97 inches (L x W x H)
- **Weight:** Approximately 6.7 ounces
- **Battery:** Rechargeable Lithium Polymer
- **Charging:** USB Rechargeable
- **Modes:** 6 Vibration Modes, 2 Rotation Speeds
- **Waterproof:** Yes
- **Manufacturer:** Libertybelle Marketing Ltd dba Nexus

9. WARRANTY INFORMATION

For detailed warranty information, please refer to the warranty card included with your product or visit the official Nexus website. Warranty terms and conditions may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your Nexus Revo Slim, please contact the manufacturer or your retailer. You can typically find contact information on the product packaging or the official Nexus website.

Manufacturer: Libertybelle Marketing Ltd dba Nexus

For the most up-to-date support information, please visit: www.nexus-toys.com (example link, actual link may vary)



