

[Manuals.plus](#) /

> [TOMY](#) /

> TAKARA TOMY B-97 Beyblade Burst Starter Nightmare Longinus.Ds W Launcher Spinning Top User Manual

## TOMY B-97

# TAKARA TOMY B-97 Beyblade Burst Starter Nightmare Longinus.Ds W Launcher Spinning Top User Manual

Model: B-97 | Brand: TOMY

## INTRODUCTION

---

Welcome to the instruction manual for your TAKARA TOMY B-97 Beyblade Burst Starter Nightmare Longinus.Ds. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your spinning top. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

---

This product is intended for users aged 13-15 years as recommended by the manufacturer. Adhere to the following safety guidelines:

- Keep small parts away from young children to prevent choking hazards.
- Do not aim the spinning top at people or animals.
- Use only in designated Beyblade Burst stadiums to prevent damage or injury.
- Inspect the spinning top and launcher for damage before each use. Do not use if damaged.
- Avoid modifying the product, as this may compromise safety and performance.

## PACKAGE CONTENTS

---

Verify that all components are present in your package:

- 1x Nightmare Longinus.Ds Spinning Top (Layer, Disk, Driver)
- 1x W Launcher (Launcher and Ripcord)
- 1x Sticker Sheet (for customization)
- 1x Instruction Sheet (original language, refer to this manual for English instructions)



Image showing the complete TAKARA TOMY B-97 Beyblade Burst Starter Nightmare Longinus.Ds set, including the Nightmare Longinus.Ds spinning top and the W Launcher with its ripcord.

## ASSEMBLY AND SETUP

---

### 1. Attaching Stickers

Carefully apply the provided stickers to the Nightmare Longinus.Ds spinning top according to the visual guides on the sticker sheet or packaging. Use tweezers for precision if available.

### 2. Assembling the Spinning Top

The Nightmare Longinus.Ds spinning top consists of three main parts: the Layer (which includes the integrated Disk) and the Driver. Follow these steps to assemble:

1. Align the three tabs on the Driver with the corresponding slots on the underside of the Layer.
2. Push the Driver firmly into the Layer and twist clockwise until it locks securely into place. You should hear a distinct click.

**BEYBLADE**  
バトルスピリッツ



B-97 スターター  
**ナイトメアロンギヌス.Ds**

NIGHTMARE LONGINUS.Ds

ナイトメアロンギヌスレイヤーは左回転のレイヤーです。  
右回転用のランチャーではシュートすることが出来ません。

ナイトメアロンギヌスレイヤーには専用ディスクが  
内蔵されているため、他のディスクを取り付けることは出来ません。

NIGHTMARE LONGINUS  
LAYER

ナイトメアロンギヌス



破滅の楯ロンギヌスモチーフ。  
レイヤーにドラゴン型の専用ディスク  
が組み込まれており重くて厚い攻  
撃を相手に与えることができる異端  
なゴッドレイヤー。

※ナイトメアロンギヌスレイヤーはゴッドチップの付け替えは出来ません。



DESTROY  
DRIVER

デストロイ



Ds

ギザギザな軸先でスタジアムに  
食いつき、周囲のガードパーツに  
より体勢を崩しにくく暴れ続け  
ることのできるアタック系ドラ  
イバー。

パーツ組み替えで  
改造ができる!!



オススメ改造例

ナイトメアロンギヌス.B.Br

破壊的な攻撃力を持つナイトメアロンギヌスレイヤーにバンフレーム  
で連打性能もプラス。ペアリングドライバーで長く攻撃し続ける改造だ!

BEYBLADE SPEC



メタルドラゴンで  
相手を破壊せよ!!

バーストライミッシュが得意!!

相手を破壊せよ!!

メタルドラゴンで攻撃!!

ナイトメアロンギヌスレイヤーの特徴

ドラゴン型のディスクがレイヤーに内蔵されており、重厚な攻撃が可能。

さらにロックが  
進むたびドラ  
ゴンが移動し、  
攻撃力がアッ  
プするぞ!!

ベイロガー(別売り)動作確認済みスマートフォンはコチラ!!  
ベイロガー(別売り)をご利用の際は、事前に動作確認済み機種をご確認ください。動作確認済み機種は公式ホームページをご覧ください。

ベイブレードバースト公式ホームページ  
[beyblade.takaratomy.co.jp](http://beyblade.takaratomy.co.jp)



**警告 (けいこく)**

保護者の方へ 必ずお読みください。

●小部品があります。誤飲・窒息の危険がありますので、3才未満のお子様には絶対に与えないでください。

WARNING

- 警告：産品(玩具或兒童用品)内凡有小零件/小球體、為免兒童吞下導致窒息危險，請勿讓36個月以下兒童玩耍。
- 産品交兒童前，請先拆除或丢弃所有包裝，尤其膠袋，以免造成危險。
- 産品凡有線線、車輪或旋轉部份，小心纏結兒童頸部、毛髮或手指，以免造成纏結危險。
- 警告：産品凡有發射功能，請勿把産品向著眼部及面部，及對人體發射。
- 請留意産品的尖角及邊位，以免損傷。
- 請勿對産品及所包含之所有配件作任何改裝。請勿將産品給予非對象年齡之兒童玩耍及成人需在旁監護下使用。
- 請保留以上資料作日後參考。
- Warning: The product (toys or children's product) may contain small parts/small balls. Choking hazard. Not suitable for children under 36 months.
- Remove or dispose of all packaging (including polybags) safely before giving to children.
- Be careful of the potential entanglement hazard with neck, hairs, or fingers if there are strings, wires, wheels or rolling parts in the product.
- Warning: Do not aim at eyes or face and do not shoot towards human body if the product consists of shooting function.
- Play attention to the hazard of the edges and points.
- Do not modify this product or any of the included components. Do not give the product to children under target age. Let children play under parental supervision.
- Please retain the above information for future reference.

終わった後は、必ず保管しておいてください。  
は、絶対に顔を近づけたり、手で触れたりしないで  
お周りに注意して、腕やウィンドーが人に当たらない  
か、家具やテレビ等の家電製品、ガラス等がないこ  
ジウム(別売り)で遊んでください。また、遊ぶ際に  
巻きつけたりしないでください。血が通わなくなり  
スト同士で遊んでください。違うシリーズ(メタル

205020



4 904810 106777

ベいの最新情報は  
ココロで読めるぞ!

●たのしいタカトミーの情報はインターネットで <http://www.takaratomy.co.jp>

Diagram illustrating the components of the Beyblade Burst spinning top and the assembly process, showing how the

Layer, Disk, and Driver connect.

### 3. Preparing the W Launcher

Insert the ripcord into the W Launcher. Ensure the teeth of the ripcord engage properly with the gear inside the launcher. The ripcord should slide in smoothly and be held firmly.



Image of the W Launcher with the blue ripcord correctly inserted, ready for launching a Beyblade.

## OPERATION


---

### 1. Loading the Beyblade

Hold the W Launcher firmly. Attach the assembled Nightmare Longinus.Ds spinning top to the launcher by aligning the tabs on the Beyblade with the slots on the launcher. Twist the Beyblade counter-clockwise until it locks into place. Ensure the Beyblade is securely attached and the ripcord is fully inserted.

### 2. Launching the Beyblade

Hold the launcher over a Beyblade Burst stadium. Pull the ripcord swiftly and horizontally to launch the Beyblade into the stadium. The Nightmare Longinus.Ds is a **left-spin** Beyblade.



Top-down view of the Nightmare Longinus.Ds spinning top, showcasing its design and left-spin orientation.

### 3. Battle Rules

Beyblade Burst battles typically involve two Beyblades. The objective is to achieve a Burst Finish, Ring Out Finish, or Survivor Finish against your opponent. The first player to reach a predetermined number of points (e.g., 3 or 5) wins the battle.

- **Burst Finish:** 2 points (opponent's Beyblade bursts into pieces).
- **Ring Out Finish:** 1 point (opponent's Beyblade is knocked out of the stadium).
- **Survivor Finish:** 1 point (opponent's Beyblade stops spinning before yours).

### MAINTENANCE

---

To ensure the longevity and optimal performance of your Beyblade Burst Starter Nightmare Longinus.Ds, follow these maintenance guidelines:

- After each use, wipe the spinning top and launcher with a dry, soft cloth to remove dust and debris.
- Store the components in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid dropping the Beyblade or launcher, as this can cause damage to the plastic and internal mechanisms.
- Do not apply lubricants, solvents, or other chemicals to any parts, as this may degrade the plastic and affect performance.

## TROUBLESHOOTING

---

Refer to the table below for common issues and their recommended solutions:

Problem	Possible Cause	Solution
Beyblade does not launch properly	Ripcord not fully inserted or engaged. Beyblade not securely attached to launcher.	Ensure ripcord is fully inserted and its teeth are engaged. Twist Beyblade counter-clockwise until it clicks securely onto the launcher.
Beyblade bursts too easily	Loose assembly of Beyblade parts. High impact with stadium or opponent.	Ensure the Driver is twisted securely onto the Layer. Practice launching technique for smoother spins and reduced impact.
Launcher mechanism feels stiff	Debris inside launcher.	Gently shake the launcher to dislodge any debris. Do not attempt to disassemble the launcher.

If problems persist after attempting these solutions, please contact customer support.

## SPECIFICATIONS

---

- **Product Name:** TAKARA TOMY B-97 Beyblade Burst Starter Nightmare Longinus.Ds W Launcher Spinning Top
- **Model Number:** B-97
- **Brand:** TOMY (Takaratomy)
- **Product Dimensions:** Approximately 2 x 1 x 2 inches (spinning top)
- **Item Weight:** Approximately 4.2 ounces (complete set)
- **Recommended Age:** 13 - 15 years
- **Spin Direction:** Left-spin
- **UPC:** 4904810896036 / 4904810106777
- **Release Date:** July 26, 2018

## WARRANTY AND SUPPORT

---

This product is manufactured by Takaratomy. For specific warranty information, please refer to the product packaging or contact Takaratomy customer service directly.

For further assistance, inquiries, or to explore more about Beyblade Burst products, please visit the official Takaratomy Beyblade website or contact their customer support channels.

Official Takaratomy Beyblade website: [beyblade.takaratomy.co.jp](http://beyblade.takaratomy.co.jp)

For general inquiries, you may also refer to the TOMY Store on Amazon: [TOMY Store on Amazon](#)