

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Chicco](#) /
- › [Chicco Training Cup \(Model 00006921100000\) Instruction Manual](#)

Chicco 00006921100000

Chicco Training Cup (Model 00006921100000) Instruction Manual

For children 6+ months

INTRODUCTION

Thank you for choosing the Chicco Training Cup. This cup is designed to help your child transition from bottle feeding to independent drinking. It features an ergonomic semi-soft spout, a patented non-drip valve, and removable handles, making it suitable for children aged 6 months and older.

Please read this manual carefully before first use and keep it for future reference. Ensure all users are familiar with the instructions for safe and proper operation.



Figure 1: Chicco Training Cup, Fuchsia/Purple variant.

IMPORTANT SAFETY INFORMATION

- Always use this product with adult supervision.
- Before each use, inspect the product. Throw away at the first sign of damage or weakness.
- Always check fluid temperature before feeding.
- Continuous and prolonged sucking of fluids will cause tooth decay.
- Keep all components not in use out of children's reach.
- This product is BPA, latex, and PVC free.

PRODUCT COMPONENTS

The Chicco Training Cup consists of the following parts:

- Cup body
- Ergonomic semi-soft spout
- Lid/Cap

- Patented non-drip valve
- Removable non-slip handles

FACILE À NETTOYER



Figure 2: Disassembled Chicco Training Cup components for easy cleaning and assembly.

SETUP AND ASSEMBLY

1. **Initial Cleaning:** Before first use, disassemble all parts and wash them thoroughly according to the "Cleaning and Maintenance" section.
2. **Insert Valve:** Place the patented non-drip valve securely into the underside of the spout. Ensure it is seated correctly to prevent leaks.
3. **Attach Spout to Lid:** Screw the spout assembly onto the cup body until tight.
4. **Attach Handles (Optional):** Slide the removable non-slip handles onto the cup body. They can be removed as your child grows or for cleaning.

POIGNÉES PRATIQUES ET DÉTACHABLES



Figure 3: The removable valve allows for either leak-proof or free-flow drinking.

VALVE AMOVIBLE FACILE À NETTOYER



Figure 4: Detachable handles provide an easy grip for small hands and can be removed as needed.

OPERATING INSTRUCTIONS

1. **Filling the Cup:** Unscrew the lid assembly from the cup body. Fill the cup with your desired beverage (water, milk, juice). Do not overfill.
2. **Securing the Lid:** Screw the lid assembly back onto the cup body firmly to prevent leaks.
3. **Non-Drip Function:** With the valve inserted, the cup is designed to be spill-proof. Liquid will only flow when your child sips from the spout.
4. **Free-Flow Function (Optional):** For a free-flow drinking experience, remove the non-drip valve from the spout before assembly. This allows liquid to flow continuously when the cup is tilted.
5. **Ergonomic Spout:** The semi-soft, off-centric spout is designed to promote a natural neck position for your child while drinking.

IDÉAL POUR
APPRENDRE À BOIRE

6m+



Figure 5: The semi-soft, ergonomic spout supports proper drinking posture.

EMBOUT SEMI-SOUPLE, RÉSISTANT



**ERGONOMIQUE
POUR FAVORISER
LA POSTURE**



Figure 6: The anti-leak design prevents spills, making it ideal for active children.

CLEANING AND MAINTENANCE

Proper cleaning is essential for hygiene and product longevity.

1. **Disassembly:** Disassemble all parts of the cup: cup body, lid, spout, valve, and handles.
2. **Washing:** Wash all components thoroughly in warm, soapy water. Use a bottle brush for the interior of the cup and a small brush for the spout and valve to ensure all residue is removed.
3. **Dishwasher Safe:** All parts are dishwasher safe (top rack only).
4. **Rinsing:** Rinse all parts thoroughly with clean water.
5. **Drying:** Allow all parts to air dry completely before reassembling or storing to prevent mold and mildew.
6. **Sterilization:** The cup can be sterilized using common sterilization methods (e.g., steam sterilizer, boiling water). Follow the sterilizer manufacturer's instructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cup is leaking	Lid not screwed on tightly. Valve not inserted correctly or damaged. Components not assembled properly.	Ensure lid is securely tightened. Check that the valve is fully seated in the spout. Replace if damaged. Disassemble and reassemble all parts, ensuring they fit snugly.
Difficulty drinking from spout	Valve is inserted, and child is not accustomed to sip-activated flow. Spout or valve is clogged.	Encourage child to sip more firmly. Consider removing the valve for free-flow until they adapt. Clean the spout and valve thoroughly to remove any blockages.

PRODUCT SPECIFICATIONS

Brand	Chicco
Model Number	00006921100000
Color	Fuchsia / Purple
Capacity	200 Milliliters (6.8 Ounces)
Material	Silicone (spout), Plastic (cup body, lid, handles)
Special Feature	Leak Proof, Removable Handles
Care Instructions	Dishwasher Safe
Age Range	6+ Months
Product Dimensions	4.92"W x 5.51"H
Item Weight	3.52 ounces (0.1 Kilograms)

WARRANTY INFORMATION

This product is covered by the manufacturer's standard warranty. For specific details regarding warranty coverage, duration, and claims, please refer to the documentation included with your purchase or visit the official Chicco website.

CUSTOMER SUPPORT

For further assistance, questions, or concerns regarding your Chicco Training Cup, please contact Chicco customer service. You can typically find contact information on the official Chicco website or on the product packaging.

Online Resources: www.chicco.com

