

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

Pfister 9520070

Pfister 9520070 Battery Pack Instruction Manual

Model: 9520070 | Brand: Pfister

PRODUCT OVERVIEW

The Pfister 9520070 Battery Pack provides an alternative power source for Pfister Stellen React touchless faucets when a direct electrical outlet is not available under the sink. This unit ensures continued electronic faucet functionality, offering a convenient and reliable power solution.

It is specifically designed for use with Pfister Stellen React touchless faucet models LG529-ESAB, LG529-ESAC, and LG529-ESAS.



Figure 1: Front view of the Pfister 9520070 Battery Pack. This image displays the compact design and the power cable connection.

SETUP AND INSTALLATION

This battery pack requires four (4) AA batteries for operation (batteries are not included). For optimal performance and longevity, the use of quality AA alkaline batteries is recommended.

Battery Installation

1. Open the battery compartment on the Pfister 9520070 Battery Pack.
2. Insert four (4) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.

3. Securely close the battery compartment.



Figure 2: Rear view of the battery pack with the compartment open, showing the four AA battery slots.

Connecting to Faucet

The battery pack is designed for self-installation. Connect the power cable from the battery pack to the corresponding port on your Pfister Stellen React touchless faucet. The unit can be mounted using adhesive strips on its back or by screwing it into place, depending on your preference and installation environment.

Ensure the connection is secure to provide consistent power to the faucet's electronic components.

OPERATING INSTRUCTIONS

Once properly installed and connected, the Pfister 9520070 Battery Pack will power the electronic functions of your compatible Pfister Stellen React touchless faucet. The faucet will operate as designed, utilizing the battery power for its sensor and automatic water flow features.

The battery pack is designed to power normal electronic faucet function for up to two years, depending on the quality of the AA batteries used and the frequency of faucet usage.

MAINTENANCE

Battery Replacement

When the batteries require replacement, the low battery indicator light on your Pfister Stellen React faucet will begin to pulse. This indicates that the battery pack's power is low and new batteries are needed.

1. Disconnect the battery pack from the faucet.
2. Open the battery compartment and remove the old batteries.
3. Insert four (4) new, quality AA alkaline batteries, observing correct polarity.
4. Securely close the compartment and reconnect the battery pack to the faucet.

Regularly check the battery pack for any signs of corrosion or damage. If corrosion is present, clean the contacts thoroughly before inserting new batteries. If the unit is damaged, replacement may be necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Faucet not responding or intermittent operation.	Low or depleted batteries.	Replace all four (4) AA batteries with new, quality alkaline batteries.
Low battery indicator light pulsing.	Batteries are nearing depletion.	Replace all four (4) AA batteries promptly to ensure continuous operation.
No power to faucet after battery replacement.	Incorrect battery polarity or loose connection.	Verify batteries are inserted with correct polarity. Ensure the power cable is securely connected to both the battery pack and the faucet.

SPECIFICATIONS

- **Manufacturer:** Pfister
- **Part Number:** 952-007
- **Item Model Number:** 9520070
- **Item Weight:** 3.2 ounces
- **Product Dimensions:** 3.74 x 2.17 x 3.74 inches
- **Country of Origin:** China
- **Power Source:** Battery powered

- **Voltage:** 1.5 Volts (per battery)
- **Batteries Required:** Yes, 4 AA batteries
- **Batteries Included:** No
- **Battery Cell Type:** Alkaline recommended
- **Included Components:** Battery pack
- **Installation Method:** Self install
- **Usage:** Inside

WARRANTY AND SUPPORT

Pfister products are designed for durability and reliability. This product is covered by a Limited Lifetime Warranty. For detailed warranty information or technical support, please refer to the official Pfister website or contact Pfister customer service directly.




Figure 3: Pfister Limited Lifetime Warranty emblem.

© 2024 Pfister. All rights reserved.

Related Documents

A thumbnail image of a technical document titled 'Pfister Mystique GT529-MD Single Control Kitchen Faucet Installation and Care Guide'. The document features a photograph of the faucet and various text sections. A large 'SAMPLE COPY' watermark is overlaid on the image.	<p>Pfister Mystique GT529-MD Single Control Kitchen Faucet Installation and Care Guide</p> <p>Comprehensive guide for the Pfister Mystique GT529-MD single control kitchen faucet, covering installation, operation, maintenance, and warranty information in English, Spanish, and French.</p>
---	---



[Pfister R89-1WR / LG89-XWR Tub & Shower Trim Quick Installation Guide](#)

Concise, SEO-optimized installation guide for Pfister R89-1WR and LG89-XWR Tub & Shower Trim kits. Features step-by-step instructions, required tools, parts list, safety warnings, and multilingual support.



[Pfister Bronson Toilet Paper Holder Installation Guide BPH-BS1](#)

Installation guide for the Pfister Bronson™ Toilet Paper Holder (Model BPH-BS1). Provides step-by-step instructions for mounting brackets and attaching the holder, including required tools, parts list, safety warnings, cleaning advice, and warranty information.