

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Diversey](#) /
- › [Diversey Glance HC RTD Glass & Multi-Surface Cleaner, 5L User Manual](#)

Diversey 93165337

Diversey Glance HC RTD Glass & Multi-Surface Cleaner, 5L User Manual

Model: 93165337

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of the Diversey Glance HC RTD Glass & Multi-Surface Cleaner, 5L. This product is a ready-to-dispense (RTD) solution designed for cleaning glass and various hard surfaces, ensuring a streak-free finish.



Image 1: Diversey Glance HC RTD Glass & Multi-Surface Cleaner 5L bottle. The translucent bottle contains a blue liquid and is fitted with a white and yellow sprayer mechanism. The product label is visible, detailing the brand, product name, and safety information.

2. SAFETY INFORMATION

WARNING: This product is corrosive and harmful if swallowed. Always read and follow all instructions and warnings on the product label before use. Keep out of reach of children and pets.

- **Eye Protection:** Wear appropriate eye protection (e.g., safety glasses) to prevent contact with eyes.
- **Skin Protection:** Wear chemical-resistant gloves to prevent skin contact.
- **Ventilation:** Use in a well-ventilated area.
- **Ingestion:** Do not ingest. If swallowed, do NOT induce vomiting. Immediately call a poison control center or doctor.
- **First Aid:** In case of contact with eyes or skin, rinse immediately with plenty of water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical attention if irritation persists.
- **Storage:** Store in a cool, dry place, away from direct sunlight and incompatible materials. Keep container tightly closed.

3. PRODUCT COMPONENTS

The Diversey Glance HC RTD Glass & Multi-Surface Cleaner, 5L, typically includes:

- 5-Liter bottle of Glance HC RTD cleaning solution.
- Integrated sprayer/dispensing mechanism (as shown in Image 1).

4. SETUP AND PREPARATION

This product is Ready-To-Dispense (RTD) and does not require dilution. The sprayer mechanism is designed for direct application.

1. **Inspect Product:** Before first use, inspect the bottle and sprayer for any signs of damage or leaks.
2. **Prepare Sprayer:** Ensure the sprayer nozzle is securely attached and oriented correctly for spraying. Some models may have a lock/unlock mechanism; ensure it is in the 'unlocked' or 'spray' position.
3. **Wear Protective Gear:** Always put on appropriate personal protective equipment (PPE), including safety glasses and chemical-resistant gloves, before handling the product.

5. OPERATING INSTRUCTIONS

General Cleaning

1. **Surface Preparation:** Remove any loose dirt or debris from the surface to be cleaned.
2. **Apply Cleaner:** Hold the sprayer approximately 6-8 inches (15-20 cm) from the surface and spray a fine mist evenly over the area. Avoid over-saturating the surface.
3. **Wipe Surface:** For best results, wipe immediately with a clean, dry, lint-free cloth or paper towel. For glass, use a squeegee for a streak-free finish.
4. **Repeat if Necessary:** For heavily soiled areas, a second application may be required.

Best Practices for Streak-Free Results

- Use a fresh, clean cloth for each cleaning task to prevent transferring dirt or residue.

- Avoid cleaning in direct sunlight or on hot surfaces, as this can cause the cleaner to dry too quickly and leave streaks.
- For large glass surfaces, work in small sections.

6. STORAGE AND MAINTENANCE

Storage

- Store the product in its original container, tightly closed, in a cool, dry, well-ventilated area.
- Keep away from incompatible materials, food, and drink.
- Protect from freezing and extreme heat.

Sprayer Maintenance

- After each use, ensure the sprayer nozzle is clean and free of any dried residue.
- If the sprayer becomes clogged, rinse the nozzle under warm water. Do not use sharp objects to clear the nozzle, as this may damage it.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Streaks or haze on surface	Over-application of product; dirty wiping cloth; cleaning in direct sunlight.	Use less product; use a clean, lint-free cloth; avoid cleaning in direct sunlight.
Sprayer not dispensing product	Nozzle clogged; sprayer mechanism locked; bottle empty.	Rinse nozzle with warm water; unlock sprayer; replace bottle if empty.
Product not cleaning effectively	Heavy soil requiring more contact time or agitation.	Apply product, allow a short dwell time (do not let dry), then wipe. Repeat if necessary.

8. SPECIFICATIONS

Attribute	Detail
Brand	Diversey
Model Number	93165337
Item Form	Liquid
Specific Uses	Glass, Multi-Surface
Item Volume	5 Liters
Unit Count	169.07 Fluid Ounces
Manufacturer	DIVERSEY

9. DISPOSAL INFORMATION

Dispose of contents and container in accordance with local, regional, national, and international regulations. Do not dispose of unused product down the drain or into natural waterways. Consult local waste management authorities for proper disposal methods for chemical products.

10. CONTACT AND SUPPORT

For further assistance, product information, or safety data sheets (SDS), please visit the official Diversey website or contact their customer support. Refer to the product label for specific contact details or batch information.

Diversey Official Website: www.diversey.com