

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Philips](#) /

› [Philips VisaPure Mini Facial Cleanser - Rotary Technology - BSC111/06 User Manual](#)

Philips BSC111/06

Philips VisaPure Mini Facial Cleanser

MODEL: BSC111/06

User Manual

INTRODUCTION

The Philips VisaPure Mini Facial Cleanser, model BSC111/06, is a compact and user-friendly device designed for daily facial cleansing. Featuring rotary technology, it effectively removes impurities to promote soft and radiant skin. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your device.



Image 1: The Philips VisaPure Mini Facial Cleanser.

IMPORTANT SAFETY INFORMATION

Please read this user manual carefully before you use the appliance and save it for future reference. Always follow the basic safety precautions listed below.

- Do not use the appliance on irritated or damaged skin.
- Consult your doctor before use if you have severe skin conditions or are undergoing medical treatment.
- Keep the appliance out of reach of children.
- The appliance is 100% waterproof and safe for use in the shower. However, do not immerse the charging adapter in water.
- Only use the original Philips charging adapter provided with the device.

WHAT'S IN THE Box

Upon opening the package, ensure all components are present and in good condition:

- 1 x Philips VisaPure Mini Facial Cleanser (BSC111/06)
- 1 x Normal Cleansing Brush Head
- 1 x Charging Cable / Adapter



Image 2: Example of various Philips VisaPure brush heads. The device comes with one standard brush head.

GETTING STARTED (SETUP)

Initial Charging

Before first use, fully charge your Philips VisaPure Mini Facial Cleanser. A full charge provides cordless power for approximately 45 uses or 22 days when used twice daily.

1. Connect the charging cable to the device and plug the adapter into a wall socket.
2. The charging indicator light will illuminate to show the device is charging.
3. Allow the device to charge completely before its first use.



Image 3: The facial cleanser connected to its charger.


Attaching the Brush Head

To attach a brush head, align the brush head with the pin on the device and press it down firmly until it clicks into place.

OPERATING INSTRUCTIONS

Follow these steps for an effective facial cleansing routine:


- 1. Prepare your skin:** Cleanse your hands and face with water.
- 2. Apply cleanser:** Apply a small amount of your preferred facial cleanser directly to your skin or onto the wet brush head.
- 3. Activate device:** Press the power button to turn on the Philips VisaPure Mini Facial Cleanser.
- 4. Cleanse:** Gently move the brush in circular motions over your face. The rotary technology quickly and gently removes impurities, providing a deep cleanse.
- 5. Rinse:** After cleansing, thoroughly rinse your face with water.
- 6. Dry and continue:** Pat your face dry and proceed with your usual skincare routine.



6x betere reiniging

Klaar in 1 minuut*

Image 4: Using the facial cleanser in the shower. The device is 100% waterproof.



6x betere reiniging

De rotatietechnologie en de 17.000 zijdezachte borstelharen van de normale reinigingsborstel zorgen voor 6x betere reiniging, voor een zachte en stralende huid.

Zacht voor de huid

De VisaPure-minigezichtsreiniger pakt onzuiverheden aan, maar is zacht voor de huid. De dunne borstelhaartjes glijden zachtjes over de huid. Kan twee keer per dag worden gebruikt.

Oplaadbaar

Als het apparaat volledig is opgeladen, kun je het 20 keer snoerloos gebruiken, oftewel 10 dagen als je het twee keer per dag gebruikt.

Image 5: Demonstrating the application and results of using the facial cleanser.

MAINTENANCE AND CLEANING

Proper maintenance ensures optimal performance and hygiene of your device.

Cleaning the Device

- After each use, rinse the device under warm running water.
- Use mild soap if necessary to clean the handle.
- Wipe the device dry with a soft cloth.

Cleaning the Brush Head

The velvety soft bristles are made of special fine nylon, making them easy to clean and ensuring they stay fresh longer.

- Remove the brush head from the device.
- Rinse the brush head thoroughly under warm running water.
- Gently rub the bristles to remove any residue.
- Allow the brush head to air dry completely before reattaching or storing.



Image 6: Close-up of the soft bristles designed for gentle cleansing.

Replacing Brush Heads

For optimal performance and hygiene, it is recommended to replace the brush head every three months, or sooner if the bristles show signs of wear.

TROUBLESHOOTING

If you encounter any issues with your Philips VisaPure Mini Facial Cleanser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
Brush head does not rotate.	Brush head not properly attached or obstructed.	Ensure the brush head is securely attached. Check for any debris obstructing movement.
Skin irritation after use.	Excessive pressure or unsuitable cleanser.	Apply less pressure during use. Ensure your cleanser is suitable for your skin type. If irritation persists, discontinue use and consult a dermatologist.

If the problem persists after trying these solutions, please contact Philips customer support.

SPECIFICATIONS

- **Model Number:** BSC111/06
- **Brand:** Philips
- **Color:** Pink
- **Power Source:** Battery (Rechargeable)
- **Battery Type:** 1 Lithium-metal battery (included)
- **Material:** Nylon (for brush bristles)
- **Product Dimensions (L x W x H):** 46 x 49 x 130 mm (4.6 x 4.93 x 13 cm)
- **Weight:** 251 g
- **Waterproof:** Yes, 100% water-resistant
- **Product Benefits:** Cleansing, radiant skin
- **Skin Type Recommendation:** Suitable for sensitive skin
- **Care Instructions:** Wash with warm water and mild soap

WARRANTY AND SUPPORT

Philips offers a standard manufacturer's warranty for this product. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For further assistance, product information, or to purchase replacement parts (such as brush heads), please visit the official Philips website or contact Philips customer support in your region. You can often find contact details and FAQs on the Philips support pages.

Online Support: www.philips.com/support