

Quorum International 3063-15-65

Quorum 3063-15-65 Transitional Three Light Ceiling Mount

Instruction Manual

Brand: Quorum International | Model: 3063-15-65

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage.

- **WARNING:** Risk of electric shock. Disconnect power at the main circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use only UL/cUL listed wire connectors.
- This fixture is rated for Damp locations. Do not install in areas where it will be directly exposed to water.
- Do not exceed the maximum wattage specified for the bulbs.
- Always wear safety glasses during installation.

PACKAGE CONTENTS

Carefully unpack your new fixture and lay out all parts on a clear area. Ensure all items listed below are present before discarding packaging materials.

- Mounting Bracket
- Fixture Body
- Glass Shade
- Finial
- Mounting Hardware (screws, wire nuts)
- Instruction Manual (this document)



Image: The Quorum 3063-15-65 ceiling mount fixture, showcasing its satin nickel finish and satin opal glass shade.

SPECIFICATIONS

Model Number	3063-15-65
Brand	Quorum International
Dimensions (H x W)	6.75 inches x 15.50 inches
Material	Metal
Finish	Satin Nickel / Silver
Number of Lights	3
Voltage	120 Volts
Max Wattage per Bulb	60 Watts
Mounting Type	Ceiling Mount
Safety Rating	Damp Location Listed

SETUP AND INSTALLATION

Tools Required (Not Included):

- Phillips Head Screwdriver
- Flat Head Screwdriver

- Wire Strippers
- Electrical Tape
- Safety Glasses

Installation Steps:

1. **Turn Off Power:** Before starting, ensure the power to the circuit you are working on is completely disconnected at the main circuit breaker or fuse box.
2. **Prepare Mounting Bracket:** Attach the mounting bracket to the junction box in the ceiling using the screws provided. Ensure it is securely fastened.
3. **Make Electrical Connections:**
 - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
 - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box using a wire nut.
 - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box (or to the green ground screw on the mounting bracket) using a wire nut.
 - Carefully tuck all wires into the junction box.
4. **Secure Fixture Body:** Align the fixture body with the mounting bracket and secure it in place using the provided screws or nuts.
5. **Install Bulbs and Glass Shade:**
 - Screw in three (3) bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
 - Carefully place the glass shade onto the fixture body.
 - Secure the glass shade in place with the finial, tightening it gently until snug. Do not overtighten.
6. **Restore Power:** Once installation is complete, restore power at the main circuit breaker or fuse box.



Image: The Quorum 3063-15-65 fixture installed in a home setting, demonstrating its transitional style and light output.

OPERATING INSTRUCTIONS

The Quorum 3063-15-65 ceiling mount operates via a standard wall switch connected to its electrical circuit. Once installed and power is restored, simply toggle the wall switch to turn the light fixture ON or OFF.

MAINTENANCE

Cleaning:

- Always disconnect power before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, polishes, or solvents as they may damage the finish.
- Clean the glass shade with a mild glass cleaner and a soft cloth.

Bulb Replacement:

- Turn off power at the circuit breaker before replacing bulbs.
- Allow bulbs to cool completely before touching them.
- Unscrew the finial and carefully remove the glass shade.
- Unscrew the old bulbs and replace them with new ones. Ensure new bulbs do not exceed 60 watts each.
- Reinstall the glass shade and secure it with the finial.
- Restore power.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose wire connections.	Turn off power. Check all wire connections and tighten if necessary.
	Faulty bulb(s).	Replace bulb(s) with new ones (max 60W each).
Light flickers.	Loose bulb.	Turn off power. Tighten bulb securely in socket.
	Incorrect dimmer switch.	Ensure dimmer switch is compatible with the bulbs used.

If the problem persists after trying these solutions, consult a qualified electrician.

WARRANTY AND SUPPORT

This Quorum International product comes with a Limited Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the manufacturer's official website or contact their customer support directly.

For technical assistance or further inquiries, please visit the Quorum International website or contact their customer service department. Contact information is typically available on the manufacturer's official website or product packaging.

Manufacturer: Quorum

Model Number: 3063-15-65

UPC: 190808095657

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question