Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sensky WTG-095

Sensky 3-in-1 Motion Sensor Night Light

MODEL: WTG-095 USER MANUAL

Introduction

Thank you for choosing the Sensky 3-in-1 Motion Sensor Night Light. This versatile device combines a motion-activated night light, a rechargeable flashlight, and an emergency light into one compact unit. Designed for convenience and safety, it provides illumination in various situations, from guiding you in the dark to serving as a portable light source or automatically activating during power outages.

Please read this manual carefully to ensure proper use, optimal performance, and longevity of your device.



Image: The Sensky 3-in-1 Motion Sensor Night Light, illustrating its primary functions as a night light and a detachable flashlight.

Key Features

- **Motion Night Light:** Automatically illuminates in dark or low-light conditions when movement is detected within 0-3 meters. Automatically turns off after 25 seconds of inactivity.
- **3-in-1 Multifunction:** Operates as a motion sensor night light, a rechargeable flashlight, and an emergency light. Easily switch modes by pressing the button.
- **Practical & Efficient:** Activates automatically during power outages, providing essential light for safe navigation. Offers soft and warm lighting.
- **Auto Stop Load:** Features a built-in 500mAh lithium polymer battery. The device automatically charges when inserted into the base and stops charging once fully loaded.
- **Removable Design & Multiple Application:** The night light can be separated from its charging base, making it portable for use in hallways, bathrooms, bedrooms, kitchens, living rooms, nurseries, baby rooms, or any area requiring additional light.



Image: Detailed view of the product components, highlighting the flashlight, night light, power button, charging base, and motion sensor.

Setup

1. **Unpack:** Carefully remove the night light and charging base from its packaging.
2. **Plug In:** Insert the charging base into a standard AC110V 60Hz wall outlet. Ensure it is securely plugged in.
3. **Initial Charge:** Place the night light unit onto the charging base. The device will begin charging automatically. It is recommended to fully charge the device before first use. The charging process will stop automatically once the battery is full.
4. **Placement:** For optimal motion detection, install the unit at a height of approximately 1.5 meters (5 feet).



Image: The night light unit separated from its charging base, demonstrating its removable and portable design.

Operating Modes

The Sensky 3-in-1 Motion Sensor Night Light offers three distinct operating modes:

- **Motion Sensor Night Light Mode:** When the unit is plugged into its charging base, it functions as a motion-activated night light. In dark or low-light conditions, it will automatically turn on when motion is detected within a 0-3 meter range. The light will remain on as long as motion is detected and will turn off approximately 25 seconds after the last detected movement.
- **Rechargeable Flashlight Mode:** Detach the night light unit from its charging base. Press the power button on the side of the unit to activate the top LED, turning it into a portable flashlight. Press the button again to turn it off.
- **Emergency Light Mode:** In the event of a power outage, the night light unit, if placed in its charging base and connected to a powered outlet, will automatically illuminate to provide emergency lighting. This feature ensures visibility during unexpected power interruptions.



Image: Visual representation of the PIR motion sensor's 60-degree detection angle and 3-meter range.

Your browser does not support the video tag.

Video: Demonstration of the Sensky 3-in-1 Motion Sensor Night Light in action, showcasing its various functions.

Maintenance

- **Battery Care:** To prolong battery life, ensure the device is recharged when its brightness significantly diminishes. Avoid completely draining the battery frequently.
- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** If storing the device for an extended period, ensure it is fully charged and store it in a cool, dry place.

Troubleshooting

- **Light not turning on in motion sensor mode:**
  - Ensure the unit is securely plugged into the charging base and the outlet has power.
  - Verify that the ambient light is low enough for the sensor to activate. The sensor will not activate in bright conditions.

- Check for obstructions blocking the motion sensor.
- The thermal infrared detection distance may be reduced in high temperatures or environments with strong interference.

- **Flashlight not working:**
  - Ensure the unit is detached from the charging base.
  - Press the power button firmly.
  - The battery may be low. Place the unit back on the charging base to recharge.
- **Emergency light not activating during power outage:**
  - Ensure the unit is properly seated in the charging base and the base is plugged into a live outlet.
  - Confirm the battery is charged.

Specifications




Image: Technical drawing with precise dimensions of the Sensky night light and its charging base.

Feature	Detail
Model Number	WTG-095
Power Source	AC110V 60Hz (Charging Base), Battery Powered (Unit)
Battery	3.7V 500mAh Lithium Polymer
Product Dimensions (D x W x H)	2.28"D x 2.76"W x 4.49"H (58mm x 70mm x 114mm)
Item Weight	141 g
Light Source Type	LED
LED Configuration	Side: 9*3528LED (Warm White 2800-3000K), Top: 1*2835LED (Cool White 6000-6500K)
Light Intensity	Side: Approx. 25lm, Top: Approx. 30lm
Motion Sensor Type	PIR (Passive Infrared)
Detection Distance	0-3 meters
Time-Delay (Auto-off)	25 seconds ± 5 seconds
Material	Plastic (Base Material: Polymer)
Indoor/Outdoor Usage	Indoor

Warranty and Support

Sensky products are manufactured with quality and performance in mind. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official Sensky website. Please retain your proof of purchase for warranty purposes.

© 2023 Sensky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076FNBDZQ

More documents and user manuals: **https://manuals.plus/**