

[Manuals.plus](#) /

› [Finishing Touch Flawless](#) /

› Finishing Touch Flawless Legs Women's Hair Remover User Manual

Finishing Touch Flawless FTFLESSLG

Finishing Touch Flawless Legs User Manual

Model: FTFLESSLG | Brand: Finishing Touch Flawless

PRODUCT OVERVIEW

The Finishing Touch Flawless Legs is an innovative, instant, and painless leg hair remover designed for women. Its ergonomic, palm-perfect design ensures maximum comfort and control, providing a smooth finish without the common irritation associated with traditional razors or waxing. Equipped with four 18-karat gold-plated heads, this hypoallergenic device is gentle on all skin types. Bright LED lights illuminate the skin, ensuring no spot is missed. Powered by a rechargeable lithium-ion battery, it offers convenient hair removal anytime, anywhere, without the need for soap, water, or lotion.



Figure 1: Finishing Touch Flawless Legs device with its ergonomic design.

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance:

- Always keep the shaver away from water and do not use it while charging.
- After each use, clean the shaver thoroughly and allow it to dry completely before storing.
- Avoid applying excessive pressure while using the shaver to prevent nicks or cuts.
- If you experience any discomfort or irritation, discontinue use immediately and consult a healthcare professional.
- Do not reach for the unit if it has fallen into water while charging. Unplug immediately from outlet.
- The power cord and the accessories connected to it are not for immersion or for use in showers.
- Do not use while bathing or in a shower.
- Always unplug product from the electrical outlet/adaptor after charging.
- Do not place or store product where it is able to fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Unplug this product before cleaning.

- The battery used in this product may present a fire or chemical burn hazard if mistreated.
- Do not disassemble, heat above 200°F or incinerate.

PACKAGE CONTENTS

Your Finishing Touch Flawless Legs package includes:

- Finishing Touch Flawless Legs Unit
- Charging Cable & AC Adapter
- Pouch
- Cleaning Brush
- Protective Cover



Figure 2: All items included in the Finishing Touch Flawless Legs package.

GETTING STARTED (CHARGING)

Before first use, ensure the unit is fully charged. The unit may be used while charging.

1. Plug the small end of the charging cable into the unit and the USB end into the AC Adapter.
2. Plug the AC Adapter into a wall outlet.
3. The indicator light will turn RED when charging.
4. The light will turn GREEN when fully charged (approximately 1 hour).



1. Turn unit on



2. Move in circular motions
up & down legs



3. Empty hair
& recharge

FINISHING TOUCH
FLAWLESS™

Figure 3: Device charging with red indicator light.

How to Use

Your skin may need time to adjust to the unit. Initially, you may not achieve as close a shave as expected. This is normal and with time, it will improve. Give yourself at least 2 or more weeks to become accustomed to your Flawless Legs.

1. Ensure your skin is clean and completely dry with no cream or cosmetic residue.
2. Remove the protective cover from the shaver heads.
3. Push the Power Button on the top of the unit to turn it ON. The LED lights will automatically turn on.
4. Gently press the head of the unit flat against your skin. Proceed by making small circular movements to remove unwanted hair. Do

NOT apply excessive pressure.

5. For best results, pull skin tight when removing hair.

6. It is normal for the head to become warm with use.

**Superior control –
no nicks, cuts, or
irritation**



Emma Roberts for Finishing Touch Flawless

Figure 4: Step-by-step guide for operating the device.



Rechargeable

Figure 5: The device's palm-perfect design allows for comfortable and controlled use.

Before

After



FINISHING TOUCH

FLAWLESS™

Figure 6: Visual comparison of skin before and after using the Flawless Legs shaver.

MAINTENANCE & CARE

Cleaning

After each use, clean the shaver thoroughly and allow it to dry completely before storing. The device is designed to collect hair within its heads, minimizing mess.

Head Replacement

We recommend replacing the head of your Legs unit every 3 to 6 months to maintain optimal performance. You can get a complete replacement head with the four individual floating heads with 18-karat plating.

Replaceable Heads Available



Figure 7: The device features replaceable heads for long-term use.



Legs Replacement Head

We recommend replacing the head of your Legs unit every 3 to 6 months. You can get a complete replacement head – with the four individual floating heads with 18-karat plating!

Figure 8: Instructions for replacing the shaver head.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted.	Charge the unit for approximately 1 hour until the indicator light turns green.
Hair is not being removed effectively.	Shaver heads are clogged with hair or worn out. Incorrect usage technique.	Clean the shaver heads after each use. Replace heads every 3-6 months. Ensure skin is dry and taut, use small circular motions without excessive pressure.
Skin irritation or redness occurs.	Excessive pressure applied. Skin not dry or clean. Individual skin sensitivity.	Use gentle pressure. Ensure skin is clean and dry. If irritation persists, discontinue use.

SPECIFICATIONS

Feature	Detail
Brand	Finishing Touch Flawless
Model Name	20754502038897
Item Model Number	FTFLESSLG
Power Source	Battery Powered (Rechargeable Lithium-ion)
Heads	Four 18 Karat Gold-Plated Floating Heads

Feature	Detail
Special Features	Built-in LED Lights, Ergonomic Handle, Hypoallergenic
Recommended Uses	Leg Hair Removal
Product Dimensions	7.25 x 3.5 x 8.75 inches; 3.14 ounces
Batteries	1 AA batteries required (included)
UPC	022600601050

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official Finishing Touch Flawless website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question