

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lenoxx](#) /
- › [Lenoxx Air Fresh Air Cooler PCL701\\_127 User Manual](#)

## Lenoxx PCL701\_127

# Lenoxx Air Fresh Air Cooler PCL701\_127 User Manual

Model: PCL701\_127 | Brand: Lenoxx

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug the appliance from the power outlet before cleaning, filling, or performing any maintenance.
- Keep the appliance out of reach of children and pets.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not block air inlets or outlets. Ensure adequate space around the unit for proper airflow.
- Use only clean water in the water tank. Do not add any chemicals or additives other than the provided cooling gel.
- Do not touch the fan blades when the appliance is operating.
- This appliance is for indoor household use only.

## 2. PRODUCT OVERVIEW

The Lenoxx Air Fresh Air Cooler PCL701\_127 is a versatile 4-in-1 appliance designed to enhance your indoor comfort. It functions as an air cooler, humidifier, fan, and air filter, providing a comprehensive solution for various environmental needs. It features three speed settings for customized airflow and a 5-liter water tank capacity for extended humidification.

### 2.1 Key Features

- **4-in-1 Functionality:** Cools, Humidifies, Ventilates, and Filters air.
- **3 Speed Settings:** Low, Medium, High for personalized comfort.
- **5-Liter Water Tank:** Large capacity for continuous operation.
- **Cooling Gel Included:** Enhances cooling performance.
- **Portable Design:** Equipped with wheels for easy movement.

### 2.2 Package Contents

Upon unpacking, ensure all the following components are present:

- 1x Lennox Air Fresh Air Cooler PCL701\_127
- 1x Cooling Gel Pack
- 1x Washable Foam Filter (pre-installed)
- 1x Washable Cloth Dust Bag (pre-installed)
- User Manual (this document)



Figure 1: Front view of the Lennox Air Fresh Air Cooler PCL701\_127. This image shows the main unit with its control panel at the top, air vents, and the transparent water tank at the bottom. The unit is white with dark grey accents.

### 3. SETUP AND ASSEMBLY

#### 3.1 Unpacking

1. Carefully remove the air cooler from its packaging.

2. Remove all packing materials, including any protective films or tapes.
3. Inspect the unit for any signs of damage. If damaged, do not operate and contact customer support.

## 3.2 Placement

Place the air cooler on a firm, level surface. Ensure there is at least 20 cm (8 inches) of clear space around the back and sides of the unit for proper air circulation.

## 3.3 Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Locate the water tank access point, usually at the bottom or back of the unit.
3. Carefully pull out or open the water tank.
4. Fill the tank with clean, cool tap water. Do not exceed the "MAX" fill line (5-liter capacity).
5. If using the cooling gel pack, place it directly into the water tank. Ensure it is fully submerged.
6. Securely close or reinsert the water tank.

**Note:** For optimal cooling, use cold water or add the frozen cooling gel pack to the water tank.

## 3.4 Power Connection

Plug the power cord into a standard 110 Volt AC electrical outlet. Ensure the outlet is properly grounded.

# 4. OPERATING INSTRUCTIONS

---

The control panel is located on the top of the unit. Familiarize yourself with the buttons before operation.

## 4.1 Power On/Off

- Press the **POWER** button once to turn the unit on.
- Press the **POWER** button again to turn the unit off.

## 4.2 Speed Settings

Press the **SPEED** button repeatedly to cycle through the three fan speeds: Low, Medium, and High. The indicator light will show the selected speed.

## 4.3 Mode Selection (Cooling/Humidifying)

To activate the cooling and humidifying function, ensure the water tank is filled. Press the **COOL/HUMIDIFY** button. The unit will begin to draw water from the tank to cool and humidify the air. Press again to deactivate this function, and the unit will operate as a fan only.

## 4.4 Oscillation

Press the **SWING** or **OSCILLATION** button (button name may vary) to activate the automatic oscillation feature, which distributes air more widely. Press again to stop oscillation.

# 5. MAINTENANCE AND CLEANING

---

Regular maintenance ensures optimal performance and extends the lifespan of your air cooler. Always unplug the unit before cleaning.

## 5.1 Cleaning the Water Tank

1. Unplug the air cooler.
2. Remove the water tank.
3. Empty any remaining water.
4. Clean the tank with a soft cloth and mild detergent. Rinse thoroughly with clean water.
5. Allow the tank to air dry completely before reinserting.
6. Clean the water tank at least once a week, or more frequently if used continuously.

## 5.2 Cleaning the Filters

The unit includes a washable foam filter and a washable cloth dust bag. These should be cleaned regularly to maintain air quality and efficiency.

1. Unplug the air cooler.
2. Locate and carefully remove the foam filter and cloth dust bag, typically found at the back of the unit.
3. Rinse both filters under running water until clean. For stubborn dirt, use a soft brush and mild soap.
4. Allow both filters to air dry completely before reinserting them into the unit. Do not use the unit with wet filters.
5. Clean filters every two weeks or as needed, depending on usage and air quality.

## 5.3 Exterior Cleaning

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## 6. TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

| Problem                | Possible Cause  | Solution  |
|------------------------|---|---|
| Unit does not turn on. | No power supply.<br>Power button not pressed.   | Check if the power cord is securely plugged into a 110V outlet.<br>Press the POWER button firmly.                                     |
| No cooling effect.     | Water tank is empty.<br>Cooling/Humidify function not activated.<br>Cooling gel not used or not frozen. | Fill the water tank with cold water.<br>Press the COOL/HUMIDIFY button.<br>Ensure cooling gel is frozen and placed in the water tank. |
| Weak airflow.          | Air filters are dirty.<br>Air inlets/outlets are blocked.   | Clean the foam filter and cloth dust bag.<br>Ensure there is clear space around the unit.   |
| Water leakage.         | Water tank not properly seated.<br>Overfilled water tank.<br>Unit is tilted.                            | Ensure the water tank is securely closed and inserted.<br>Do not fill past the "MAX" line.<br>Place the unit on a level surface.      |
| Unusual noise.         | Unit not on a level surface.<br>Obstruction in fan.   | Place the unit on a stable, level surface.<br>Unplug and check for any foreign objects near the fan blades.                           |

## 7. SPECIFICATIONS

| Feature                        | Detail  |
|--------------------------------|---|
| Model Number                   | PCL701_127  |
| Brand                          | Lenoxx  |
| Color                          | White   |
| Material                       | Plastic   |
| Product Dimensions (L x W x H) | 29.5 x 25.5 x 54.5 cm (11.6 x 10.0 x 21.5 inches) |
| Product Weight                 | 4.64 kg (10.23 lbs)                               |
| Water Tank Capacity            | 5 Liters  |
| Voltage                        | 110 Volts   |
| Energy Efficiency Label (ENCE) | A   |
| Certification                  | BRA HO 15/04108                                   |

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

This Lenoxx Air Fresh Air Cooler PCL701\_127 comes with a **12-month warranty** provided by the supplier. This warranty covers manufacturing defects and material faults under normal use conditions from the date of purchase. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, neglect, unauthorized repairs, accidents, or normal wear and tear.

### 8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Lenoxx Air Fresh Air Cooler, please contact your retailer or the official Lenoxx customer support channel. Refer to the contact information provided with your purchase documentation or visit the official Lenoxx website for support details.