Connect It CI-786

Connect It CI-786 Flat Screen Wall Mount
INSTRUCTION MANUAL

Introduction

Thank you for choosing the Connect It CI-786 Flat Screen Wall Mount. This manual provides essential information for the safe and correct installation, operation, and maintenance of your new wall mount. Please read these instructions thoroughly before installation and retain them for future reference.

Important Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity of 50 kg (110 lbs). Overloading can result in serious injury or damage to equipment.
- **Screen Size:** This mount is designed for flat screens between 94 cm (37 inches) and 178 cm (70 inches).
- **Wall Type:** Ensure the mounting surface can safely support the combined weight of the mount and your display. Consult a professional if unsure.
- **Installation:** Follow all installation steps carefully. Improper installation can lead to equipment failure and personal injury.
- **Children:** Keep children away during installation. Small parts may be a choking hazard.

Setup and Installation

Before you begin, ensure you have all necessary tools and components. It is recommended that two people perform the installation.

1. Verify Package Contents

Check that all parts listed in the product packaging are present and undamaged. If any parts are missing or damaged, contact customer support.

2. Prepare the Wall Mount

Familiarize yourself with the components of the wall mount. The image below shows the assembled mount structure.

Image 1: Connect It CI-786 Wall Mount. This image displays the main components of the wall mount, including the wall plate, articulating arms, and TV mounting brackets, ready for installation.

3. Determine Mounting Location and VESA Compatibility

Select a suitable location on your wall. Ensure the wall is capable of supporting the weight. Check your TV's VESA pattern (the four holes on the back of your TV). This mount supports VESA patterns from 200x200 mm to 600x400 mm.

Image 2: Dimensional Diagram of Connect It CI-786 Wall Mount. This diagram illustrates the key dimensions of the mount, including VESA compatibility (min 200x200mm, max 600x400mm), wall distance (min 62mm, max 475mm), and rotational/tilt angles.

4. Mount the Wall Plate

1. Mark the desired drilling points on the wall using the wall plate as a template.
2. Drill pilot holes. Use appropriate drill bits for your wall type (wood stud, concrete, brick).
3. Secure the wall plate to the wall using the provided screws and anchors. Ensure it is level and firmly attached.

5. Attach TV Brackets to Display

1. Carefully place your TV face down on a soft, clean surface.
2. Attach the vertical TV brackets to the back of your display using the appropriate screws that match your TV's VESA pattern. Do not overtighten.

6. Hang Display on Wall Mount

1. With assistance, carefully lift the display and hook the TV brackets onto the wall plate.
2. Secure the TV to the mount using the locking mechanisms or screws as per the detailed instructions in the full manual.

Operating Instructions

The Connect It CI-786 wall mount offers various adjustment options for optimal viewing.

- **Rotation:** The mount allows for a 360-degree rotation. Gently adjust the screen to your desired angle.
- **Tilt:** The screen can be tilted up to 3 degrees. Loosen the tilt adjustment screws, set the desired angle, and retighten.
- **Swivel:** The articulating arms allow the TV to swivel horizontally. Gently pull or push the screen to achieve the desired viewing angle.
- **Wall Distance:** The mount can extend from a minimum of 6.2 cm (2.4 inches) to a maximum of 47.5 cm (18.7 inches) from the wall.

Maintenance

- **Cleaning:** Wipe the mount with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Periodic Checks:** Periodically check all screws and connections to ensure they remain tight and secure.
- **Damage:** If any part of the mount appears damaged, discontinue use and contact customer support.

Troubleshooting

Problem	Possible Cause	Solution
TV is not level	Wall plate not level during installation.	Adjust the leveling screws on the TV brackets if available, or re-install the wall plate ensuring it is level.
Mount feels loose	Screws are not fully tightened or wall anchors are insufficient.	Check and tighten all mounting screws. Ensure appropriate anchors were used for your wall type.
Difficulty adjusting movement	Adjustment screws are too tight.	Loosen the relevant adjustment screws slightly to allow for movement, then retighten to secure position.

Specifications

Model: CI-786

Material: Alloy Steel

Color: Black

Compatible Devices: TV

Mounting Type: Wall Mount

Movement Type: Rotational, Swivel, Tilt

Max Weight Capacity: 50 kg (110 lbs)

Min Screen Size Compatibility: 94 cm (37 inches)

Max Screen Size Compatibility: 178 cm (70 inches)

VESA Compatibility: 200x200 mm to 600x400 mm

Rotation Angle: 360 degrees

Max Tilt Angle: 3 degrees

Distance to Wall (Min): 6.2 cm (2.4 inches)

Distance to Wall (Max): 47.5 cm (18.7 inches)

Product Dimensions: 23 x 26.2 x 23 cm (folded); 6.23 kg

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Connect It website. Do not attempt to repair the product yourself.

Related Documents - CI-786

	[Connect IT CMH-9100-BK Wheeled Mount for Flat Screen - User Manual and Assembly Guide](#) Comprehensive user manual and assembly guide for the Connect IT CMH-9100-BK wheeled mount for flat screens. Features include specifications, warnings, package contents, and step-by-step assembly instructions.
	[Connect IT CI-71/CI-1258 User Manual: Large Font LED Keyboard](#) User manual for the Connect IT CI-71/CI-1258 keyboard, featuring large font size, LED backlight, and Plug & Play installation. Includes specifications, installation, overview, and troubleshooting.
	[CONNECT IT CI-58 Keyboard User Manual - Setup and Specifications](#) Official user manual for the CONNECT IT CI-58 keyboard. Provides setup instructions, technical specifications, compatibility information, and disposal guidelines for home and professional use.
	[Connect IT CI-1139 Wi-Fi USB Adapter User Manual and Specifications](#) User manual and technical specifications for the Connect IT CI-1139 Wi-Fi USB Adapter, including installation, connection, and disposal information.
	[Connect IT CMO-2600-BK Ergonomic Optical Mouse User Manual](#) User manual for the Connect IT CMO-2600-BK ergonomic optical mouse, covering specifications, overview, installation, and troubleshooting.

USER MANUAL
BENUTZERHANDBUCH
UŽIVATELSKÝ MANUÁL
POUŽÍVATEĽSKÝ MANUÁL
HASZNÁLATI ÚTMUTATÓ

SELFIE LED LIGHT WITH REMOTE CONTROL
LED-SELFIE-LICHT MIT FERNBEDIENUNG
SELFIE LED SVĚTLO NA DÁLKOVÉ OVLÁDÁNÍ
SELFIE LED SVETLO NA DIAĽKOVÉ OVLÁDANIE
SELFIE LED LÁMPA TÁVIRÁNYÍTÁSSAL

CLI-2000-SM

connect IT

[Connect IT CLI-2000-SM Selfie LED Light with Remote Control User Manual](#)
Comprehensive user manual for the Connect IT CLI-2000-SM Selfie LED Light with Remote
Control, detailing technical specifications, package contents, operation, and disposal information.