De'Longhi Voir descriptif

De'Longhi Oven Heating Element Instruction Manual

Model: Voir descriptif

1. Introduction

This manual provides essential information for the installation, operation, and maintenance of your De'Longhi lower oven heating element. Please read these instructions carefully before installation and use to ensure proper function and safety. This original De'Longhi product is a 1000W, 225V lower heating element designed for Sfornatutto ovens and other compatible De'Longhi models.

2. Safety Information

WARNING: Always disconnect the appliance from the power supply before performing any installation, maintenance, or repair work.

- Installation should only be performed by a qualified technician.
- Ensure the replacement part is compatible with your specific oven model. Refer to the identification plate, usually located under the appliance, for product details.
- Handle the heating element with care to avoid damage.
- Do not operate the oven if the heating element is damaged or improperly installed.
- Keep children and pets away from the appliance during installation and operation.

3. Setup and Installation

This section outlines the general steps for replacing the lower oven heating element. Specific steps may vary depending on your oven model. Always consult your oven's primary service manual for detailed instructions.

1. **Disconnect Power:** Turn off the circuit breaker supplying power to your oven. Verify that the power is off before proceeding.
2. **Access the Element:** Open the oven door. Depending on your model, you may need to remove the oven racks or the bottom panel to access the lower heating element.
3. **Remove Old Element:** Carefully disconnect the electrical wires from the terminals of the old heating element. Note their positions for reinstallation. Unscrew any mounting screws holding the element in place and gently pull it out.

4. **Install New Element:** Insert the new De'Longhi heating element into position. Secure it with the mounting screws. Reconnect the electrical wires to the corresponding terminals. Ensure connections are secure.
5. **Reassemble:** Replace any panels or racks that were removed.
6. **Restore Power:** Turn the circuit breaker back on.



Figure 1: De'Longhi Lower Oven Heating Element. This image displays the heating element, characterized by its robust, rust-resistant construction and the electrical terminals at each end, ready for installation in a compatible oven.

4. Operating Instructions

Once correctly installed, the heating element operates automatically as part of your oven's heating system. When you select a baking or roasting function and set a temperature, the oven's thermostat will activate the lower heating element to reach and maintain the desired temperature.

- Ensure the oven door is properly closed during operation to maintain temperature and efficiency.
- Avoid placing objects directly on the heating element.

5. Maintenance and Care

This heating element is designed to be rust-resistant, ensuring durability and longevity. Regular maintenance of your oven will help prolong the life of the heating element.

- **Cleaning:** Ensure the oven is completely cool and disconnected from power before cleaning. Wipe down any spills or food residue in the oven cavity regularly. Avoid using abrasive cleaners directly on the heating element.
- **Inspection:** Periodically inspect the heating element for any visible signs of damage, such as cracks, bulges, or discoloration. If any damage is observed, the element should be replaced.

6. Troubleshooting

If your oven is not heating properly after replacing the element, consider the following:

- **No Heat:** Check if the oven is receiving power. Verify the circuit breaker is on. Ensure the heating element's electrical connections are secure and correctly wired.
- **Uneven Heating:** This could indicate an issue with the element itself or other oven components like the thermostat. Re-check the element's installation.
- **Compatibility:** Double-check that the heating element is the correct part for your specific oven model. Refer to the compatibility list or your oven's identification plate.
- **Professional Assistance:** If problems persist, it is recommended to contact a qualified appliance repair technician.

7. Specifications

Attribute	Value
Brand	De'Longhi
Model Number	Voir descriptif
Product Dimensions	1 x 1 x 1 cm; 180 g
Capacity	1 Gram
Power/Wattage	1000 watts
Special Features	Rust-resistant
First Available Date	February 21, 2020

8. Compatible Models

This heating element is compatible with various De'Longhi oven models, including but not limited to:
Please check your oven's identification plate for exact model number and cross-reference with this list. If your model is not listed, please contact De'Longhi customer support for compatibility verification.

- Emo 191 X 20B X19STceEx: LEX: R X19ST X19SBG X18SG X18S X 19STCE Ex: LEX:R X 19SB X 19LUXce Ex: LEx:R X 18SECE X 18S W91LUXceEx:LEx:R W91LUX W91 LUX EX: BR/BL W81SEX91BBOX91BBOX91BBOX91BBOX91B 22 Bo 20 19V BO 18 BO 12 BC 9 CROMO BC 19V CHROMO B09EX: LEX: R B07 95FLC 95FL 93FL 92LUX Ex: L Ex: R GET 92LUX Ex: BR/BL 92ELITE Ex: L Ex: R GET 92ELITE Ex: BR/BL 91STEX: LEx: R 30091ST 011850000000000000000000003 0118963002 0118930013 0118930010 0118930008 0118930007 0118930005 0118930004 0118930002 0118930000 0118914001 0118913002 0118913000 0118910005 0118910004 0118504010 0118504009 0118504007

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your original De'Longhi oven or visit the official De'Longhi website. Keep your purchase receipt as proof of purchase.
For technical assistance or to inquire about specific model compatibility, please contact De'Longhi customer service.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question