

HOREVO 16-0003-00096-24W

HOREVO 15-inch Dimmable LED Music Ceiling Light with Bluetooth Speaker

Model: 16-0003-00096-24W

Brand: HOREVO

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your HOREVO 15-inch Dimmable LED Music Ceiling Light with Bluetooth Speaker. This product combines efficient LED lighting with an integrated Bluetooth speaker, offering adjustable brightness, multiple color options, and music playback capabilities controlled via a remote or a smartphone application.



Image 1.1: HOREVO 15-inch Dimmable LED Music Ceiling Light with included remote control.

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, or injury to persons, read and follow all instructions carefully.

- Always turn off the power at the circuit breaker or fuse box before beginning installation.
- Installation should be performed by a qualified, licensed electrician to ensure proper wiring and safety.
- Do not modify the product in any way not described in this manual.
- Ensure the voltage supply matches the product's requirements (110 Volts).
- Keep the product away from water and moisture. This product is not water-resistant.

3. PACKAGE CONTENTS

Verify that all components are present before installation:

- HOREVO 15-inch Dimmable LED Music Ceiling Light
- Remote Control
- Mounting Hardware (screws, anchors)
- Instruction Manual (this document)

4. SPECIFICATIONS

Feature	Detail
Brand	HOREVO
Model Number	16-0003-00096-24W
Dimensions	15.7"L x 15.7"W x 3.5"H (400mm diameter)
Weight	2 Pounds
Power Source	Corded Electric
Voltage	110 Volts
Wattage	24 Watts
Light Source Type	LED
Brightness	1600 Lumens
Color Temperature	Adjustable (Warm White to Cool White, 3000K-6500K)
Material	Plastic
Control Method	Remote Control, Smartphone App (Bluetooth)
Special Features	Dimmable, Color Changing (RGB), Integrated Bluetooth Speaker, Timer Function



Image 4.1: Product dimensions diagram.

5. INSTALLATION

It is highly recommended that this ceiling lamp be installed by a licensed electrician to ensure safety and proper functionality.

5.1 Pre-Installation Steps

1. **Power Off:** Before starting any electrical work, ensure the power supply to the installation area is turned off at the main circuit breaker.
2. **Unpack:** Carefully remove all components from the packaging and inspect for any damage.
3. **Identify Wires:** In your ceiling, identify the live (hot) and neutral wires. The product typically uses brown for live and blue for neutral. Connect these to your household's corresponding wires (e.g., brown to black/red, blue to white). If unsure, consult a professional electrician.

5.2 Mounting the Light Fixture

1. Attach the mounting bracket to the ceiling junction box using the provided screws.
2. Connect the electrical wires from the fixture to the household wires according to local electrical codes. Secure connections with wire nuts.
3. Carefully push the wired connections into the junction box.
4. Align the light fixture with the mounting bracket and secure it in place.



Image 5.1: HOREVO ceiling light installed.

6. OPERATING INSTRUCTIONS

6.1 Initial Power On

After installation, restore power at the circuit breaker. The light should turn on.

6.2 Remote Control Operation

The included remote control allows for basic light functions:

- **On/Off:** Press the power button to turn the light on or off.
- **Brightness Adjustment:** Use the dimmer buttons to increase or decrease light intensity.
- **Color Temperature:** Switch between warm white and cool white light.
- **Color Change:** Select various static colors or activate color-changing modes.



Image 6.1: Demonstrating warm white and cool white light settings.

6.3 Smartphone App Control

For advanced features, download the companion app:

1. **Download App:** Scan the QR code provided in the product packaging or search for "i-lamp", "ilight", or "ilightpro" in your smartphone's app store (Google Play for Android, APP Store for iOS).
2. **Bluetooth Connection:**
 - Ensure Bluetooth is enabled on your smartphone.

- Open the downloaded app.
- The app will search for the device named "ilamp". Select it to connect.

3. **Light Customization:** Once connected, you can:

- Adjust brightness and choose from over 300 colors.
- Select various lighting modes.
- Activate "Rhythm" mode for color changes synchronized with music.

4. **Timer Function:** Set schedules for automatic on/off times, useful as an alarm clock.




Image 6.2: Smartphone app interface for light control.



Image 6.3: Light displaying multiple color options.

6.4 Bluetooth Speaker Functionality

The integrated speaker allows for audio playback:

1. **Connect to Speaker:** From your smartphone or tablet's Bluetooth settings, search for and connect to the device named "ilamp". This connects your device to the speaker, similar to a standard portable Bluetooth speaker.
2. **Play Music:** Once connected, you can play audio from your device through the ceiling light's speaker.

Note:

- Only one Bluetooth device can be connected to the speaker at a time.
- The speaker functionality is separate from the light control app's Bluetooth connection. You may need to connect to "ilamp" in your phone's Bluetooth settings specifically for audio playback.



Image 6.4: Light with music playback feature.

7. MAINTENANCE

To maintain the appearance and functionality of your HOREVO ceiling light:

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** This fixture uses integrated LED components and does not require traditional bulb replacement.

8. TROUBLESHOOTING

8.1 Light Not Turning On

- Check the circuit breaker to ensure power is supplied to the fixture.
- Verify that the wall switch is in the ON position.
- Ensure all electrical connections are secure. If unsure, consult a licensed electrician.

8.2 Remote Control Not Responding

- Check the remote control's battery and replace if necessary.
- **Re-sync Remote:** If the remote loses synchronization, turn the ceiling light OFF and then ON using the wall switch. Immediately press the button located in the center of the circular control on the remote.

8.3 Bluetooth Connection Issues

- **Cannot Find Device:** If you cannot find "ilamp" in your phone's Bluetooth settings, turn off Bluetooth on your phone. Then, turn off the light using the wall switch and wait 10 seconds before turning it back on. Re-enable Bluetooth on your phone and search for "ilamp" again.
- **Connection Lost:** If the connection is frequently lost, ensure your phone is within range of the light. Power cycling the light and your phone's Bluetooth can often resolve this.

8.4 Speaker Audio Quality

- The integrated speaker is designed for casual audio playback. For high-fidelity audio, external sound systems may be preferred.
- Ensure the volume on both your connected device and the light (if adjustable via app) is set appropriately.

9. WARRANTY AND SUPPORT

This HOREVO product is covered by a manufacturer-and-seller-combination warranty. For specific details regarding warranty coverage, duration, or to obtain technical support, please contact the seller or HOREVO customer service directly.

Please retain your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

