Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Nerf /
- > Nerf Nitro Bullseye Blast Stunt Set Instruction Manual

Nerf E1556

Nerf Nitro Bullseye Blast Stunt Set Instruction Manual

Model: E1556

1. Introduction

Welcome to the world of Nerf Nitro! This manual provides essential information for the safe and proper use of your Nerf Nitro Bullseye Blast Stunt Set. Please read all instructions carefully before assembly and play.

The Nerf Nitro Bullseye Blast Stunt Set allows users to launch foam cars for stunt challenges. This set is designed for active play and includes components for setting up exciting car-launching activities.

2. SAFETY INFORMATION

- Adult Supervision Recommended: Always ensure adult supervision during play.
- **Eye Protection:** Always wear eye protection when playing with Nerf products to prevent eye injuries. (Eye protection not included).
- Use Only Official Nerf Nitro Foam Cars: Do not use modified cars or other objects with the launcher. Use of
 unofficial projectiles may cause injury or damage.
- Avoid Aiming at Eyes or Face: Never aim the launcher at people's eyes or face.
- Clear Play Area: Ensure the play area is clear of obstacles and other people to prevent accidents.
- Choking Hazard: Small parts may be generated. Not for children under 3 years.
- Age Recommendation: Recommended for ages 5 years and up.

3. WHAT'S IN THE BOX

Your Nerf Nitro Bullseye Blast Stunt Set includes the following components:

• 1x Blaster (Car Launcher)

- 1x Foam Car
- 1x Stunt Set (Ramp and Target Assembly)



Figure 3.1: Packaging of the Nerf Nitro Bullseye Blast Stunt Set, showing the included foam car and stunt components.

This image displays the product packaging, highlighting the main components: the stunt set with its large circular target, a launching ramp, and a foam car. The packaging also indicates the Nerf Nitro branding and age recommendation.

4. SETUP

Follow these steps to assemble your Nerf Nitro Bullseye Blast Stunt Set:

- 1. Unpack Components: Carefully remove all parts from the packaging.
- 2. **Assemble the Stunt Ramp:** Connect the ramp sections as indicated by the arrows or grooves on the plastic pieces. Ensure they snap securely into place.
- 3. Attach the Target: Secure the circular target to the designated slots on the ramp assembly. The target should

stand upright and be stable.

4. **Prepare the Launcher:** Ensure the car launcher (blaster) is ready for use. No batteries are required for this manual launcher.



Figure 4.1: Fully assembled Nerf Nitro Bullseye Blast Stunt Set, showing the launcher, ramp, and target.

This image illustrates the complete stunt set, featuring a yellow foam car, a blue launching ramp, and a large grey circular target with a flame design. Two small bullseye targets are also visible on the ramp, positioned before the main target.

5. OPERATING INSTRUCTIONS

To operate your Nerf Nitro Bullseye Blast Stunt Set:

- 1. Load the Foam Car: Place one Nerf Nitro foam car into the launcher. Ensure it is seated correctly.
- 2. Prime the Launcher: Pull back the priming mechanism on the launcher until it locks into place.
- 3. Aim: Position the launcher in front of the ramp, aiming the foam car towards the target.
- 4. Launch: Press the trigger to launch the foam car up the ramp and towards the target.
- 5. **Reset:** Retrieve the foam car and reset the target if it was hit. Repeat for more stunt action.



Figure 5.1: A yellow foam car is shown in mid-air, having just launched off the blue ramp and is about to hit one of the small bullseye targets on the stunt set.

This image captures the dynamic moment of a foam car hitting a target, demonstrating the core play pattern of the stunt set. The car is yellow with purple wheels, and the target is a small red and yellow bullseye.

6. MAINTENANCE

- Cleaning: Wipe down the stunt set and foam cars with a damp cloth as needed. Do not immerse in water.
- Storage: Store the set in a cool, dry place away from direct sunlight when not in use.
- **Inspection:** Periodically inspect all components for wear or damage. Discontinue use if any part is broken or compromised.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Foam car not launching or launching weakly.	Launcher not fully primed. Car not seated correctly. Damaged foam car.	Ensure the priming mechanism is pulled back until it clicks. Re-seat the foam car. Use a new, undamaged foam car.
Target not falling when hit.	Target not properly assembled or reset.	Check that the target is securely attached and fully reset to its upright position.
Foam car veers off course.	Improper aiming. Damaged foam car. Uneven launch surface.	Adjust aiming. Use a new foam car. Ensure the launcher and ramp are on a flat, stable surface.

8. SPECIFICATIONS

• Model Number: E1556

• Product Dimensions: 1.63 x 9.25 x 7.75 inches

• Item Weight: 10.9 ounces

• Manufacturer Recommended Age: 5 years and up

• Manufacturer: Hasbro

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the official Nerf or Hasbro website, or contact their customer service directly. Specific warranty details may vary by region and purchase location.

No specific warranty or support contact information was provided with this product manual.

10. PRODUCT VIDEOS

No official product videos directly demonstrating the Nerf Nitro Bullseye Blast Stunt Set were found in the provided data.

© 2023 Nerf / Hasbro. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.



NERF Digital Target User Guide: Setup, Games, and Instructions

Comprehensive user guide for the NERF Digital Target (model 11588). Learn how to set up, play, and master the different game modes like Point Counter, Speed Breaker, and Accuracy Blast. Includes battery information, safety warnings, and features.



Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions

Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.



Nerf Strike 'N Score Digital Target Game - Instructions and How to Play

Official instructions for the Nerf Strike 'N Score Digital Target Game by Wilder Toys Inc. Learn how to set up, play different game modes like Overtime, Red vs Blue, Perfect 100, and Tag Team, and battery information.



Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions

Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.



Nerf N-Strike Elite Strongarm Blaster: User Guide

Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.



Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions

A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.