

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Transformers](#) /

› [Transformers Optimus Prime Cyberverse Ultimate Class Action Figure \(Model E2067\) Instruction Manual](#)

## Transformers E2067

# Transformers Optimus Prime Cyberverse Ultimate Class Action Figure (Model E2067) Instruction Manual

Brand: Transformers | Model: E2067

## INTRODUCTION AND OVERVIEW

This manual provides essential information for the Transformers Optimus Prime Cyberverse Ultimate Class Action Figure. This 11.5-inch figure is designed for engaging play with its unique features and transformation capabilities.

- **11.5-Inch Action Figure:** Ultimate Class Optimus Prime figure stands 11.5 inches tall, similar in scale to Transformers Titan Changers action figures.
- **Repeatable Attack Move:** Optimus Prime performs his signature Matrix Mega Shot action attack move in both vehicle and robot mode. Convert the figure to activate the move! The fun attack move can be repeated through easy reactivation steps.
- **2-In-1 Toy:** Transformers conversion for kids ages 6 years old and up! Convert the figure from red and blue robot to truck mode in 11 steps.
- **Transformers G1 Inspired Cyberverse Character:** Optimus Prime robot toy inspired by the noble Autobot leader from the Transformers Cyberverse cartoon, as seen on Cartoon Network and YouTube.
- **TV-Show-Inspired:** Transformers Robots are giant battling bots from the Planet Cybertron. Each Transformers robot has a signature ability known as an action attack move that activates in battle!

## SAFETY INFORMATION

**Warning: Choking Hazard - Small parts may be generated. Not for children under 3 years.**

## SETUP

1. Carefully remove the Optimus Prime figure from its packaging.
2. Ensure all components are present: Optimus Prime figure.
3. Familiarize yourself with the figure's articulation points before attempting transformation.

---

## OPERATING INSTRUCTIONS

### Transformation from Robot to Truck Mode

1. Follow the included assembly instructions to transform the figure from robot to truck mode. This process involves 11 steps.
2. Ensure all parts click securely into place for a stable vehicle mode.

### Activating Matrix Mega Shot Action Attack

1. To activate the Matrix Mega Shot action attack move, convert the figure to vehicle mode.
2. Repeat the conversion step to reactivate the attack move.

---

## PRODUCT FEATURES

- **Figure Height:** Approximately 11.5 inches (29.2 cm) in robot mode.
- **Transformation:** 2-in-1 conversion between robot and truck mode in 11 steps.
- **Action Attack:** Signature Matrix Mega Shot attack, activated by conversion.
- **Articulation:** Limited articulation in legs (no knee joints), waist twist for transformation, and arm movement. Head rotation is slightly inhibited by the back plate.
- **Weaponry:** Figure does not include a separate weapon, but 5mm compatible accessories from other figures may fit.

---

## MEDIA

### Product Images



Optimus Prime Cyberverse Ultimate Class Action Figure in Robot Mode.



Optimus Prime Cyberverse Ultimate Class Action Figure with 10-inch height measurement.



Close-up of Optimus Prime Cyberverse Ultimate Class Action Figure in Robot Mode, highlighting the Matrix Mega Shot feature.



Optimus Prime Cyberverse Ultimate Class Action Figure in Robot Mode, front view.

## Official Product Videos

Video: Transformers Toys Optimus Prime Cyberverse Ultimate Class Action Figure - Repeatable Matrix Mega Shot Action Attack Move. This video demonstrates the figure's features and action attack.

Video: Transformers Cyberverse Rocket Roar Grimlock and Matrix Mega Shot Optimus Prime from Hasbro. This video showcases the Matrix Mega Shot Optimus Prime figure.

Video: Transformers Cyberverse Action Attackers Optimus Prime, Bumblebee, and Megatron from Hasbro. This video features the Action Attackers Optimus Prime figure.

## MAINTENANCE

To clean the figure, wipe with a dry cloth. Avoid harsh chemicals or abrasive materials. Store in a cool, dry place away from direct sunlight to prevent material degradation.

---

## TROUBLESHOOTING

- **Difficulty Transforming:** Ensure all joints are properly aligned before attempting to move parts. Refer to the transformation steps provided in this manual.
- **Loose Parts:** If parts become loose during play, gently reattach them. Avoid excessive force during transformation or play to prevent damage.

---

## SPECIFICATIONS

- **Product Dimensions:** 2.94 x 9 x 12 inches
- **Item Weight:** 1 pounds
- **ASIN:** B076KRYQ1M
- **Item Model Number:** E2067
- **Manufacturer Recommended Age:** 6 years and up
- **Release Date:** July 25, 2018
- **Manufacturer:** Hasbro

---

## WHAT'S IN THE BOX

- Optimus Prime figure
- Instructions

---

## WARRANTY AND SUPPORT

For warranty information or product support, please contact Hasbro customer service. Visit the official Transformers website for additional resources and contact details.

---