

[Manuals.plus](#) /

› [Equip](#) /

› Equip Outdoors Hammock Mosquito Net User Manual

Equip 97044

Equip Outdoors Hammock Mosquito Net User Manual

Model: 97044

1. PRODUCT OVERVIEW

The Equip Outdoors Hammock Mosquito Net is designed to provide 360-degree protection from insects while enjoying your camping or travel hammock. Crafted from no-see polyester mesh, it ensures a comfortable and bug-free experience without obstructing your view of the outdoors. This lightweight and portable accessory is an essential addition to your outdoor gear.

Key Features:

- **Easy to Use:** Encloses most one-person camping hammocks with an upgraded front zip closure for convenient access.
- **Full Protection:** Offers complete security from all bugs and mosquitoes.
- **Lightweight:** Breathable and weighs only 11.2 ounces, ensuring portability.
- **Portable:** Compacts into a small stuff sack for easy transport and storage.
- **Durable:** Constructed for longevity and excellent quality.



The Equip Outdoors Hammock Mosquito Net provides a bug-free outdoor experience.

2. SETUP INSTRUCTIONS

Follow these steps to properly set up your Equip Outdoors Hammock Mosquito Net:

1. Unpack the mosquito net from its stuff sack.
2. Drape the net over your existing one-person camping hammock. Ensure the hammock is already securely set up between two anchor points.
3. Align the opening of the mosquito net with the entry point of your hammock.
4. Secure the ends of the mosquito net around the suspension lines or ends of your hammock. The net is designed to enclose the hammock completely.
5. Use the integrated drawstrings or attachment points to cinch the net snugly around the hammock's suspension system, preventing gaps where insects could enter.
6. Ensure the front zip closure is easily accessible for entry and exit.



Detail of the hammock mosquito net's secure closure mechanism.

Your browser does not support the video tag.

Official video demonstrating the setup and use of the Equip Hammock Bug Net.

3. OPERATING INSTRUCTIONS

Once the mosquito net is set up, operating it is straightforward:

- To enter the hammock, locate the front zip closure and carefully unzip it.
- Enter the hammock, ensuring not to snag the mesh.
- Once inside, zip the closure completely to seal yourself within the protective mesh.
- To exit, simply reverse the process: unzip, exit carefully, and re-zip if you wish to keep the hammock protected while unoccupied.



Enjoying a bug-free rest inside the hammock with the mosquito net fully enclosed.

4. MAINTENANCE

Proper care will extend the life of your Equip Outdoors Hammock Mosquito Net:

- **Cleaning:** Hand wash the net with mild soap and cool water. Do not use harsh detergents or bleach, as these can damage the mesh fabric. Rinse thoroughly.
- **Drying:** Air dry completely in a shaded area. Do not tumble dry or expose to direct sunlight for prolonged periods, which can degrade the polyester.
- **Storage:** Ensure the net is completely dry before folding and storing it in its stuff sack. Store in a cool, dry place away from direct sunlight and sharp objects.
- **Inspection:** Regularly inspect the mesh for any small tears or holes. Minor damage can often be repaired with a mesh repair kit to prevent further tearing.

5. TROUBLESHOOTING

If you encounter any issues with your hammock mosquito net, consider the following:

- **Insects entering the net:** Check all attachment points and the zipper for any gaps. Ensure the net is fully cinched around the hammock's suspension. Inspect the mesh for any unnoticed tears.
- **Zipper snagging:** Operate the zipper slowly and carefully. If it snags, gently pull the fabric away from the zipper teeth. Avoid forcing the zipper.
- **Difficulty packing:** Ensure the net is completely dry and fold it neatly before attempting to place it back into the stuff sack. Start by folding it lengthwise, then roll it tightly from one end.

6. SPECIFICATIONS

Feature	Detail
Brand	Equip
Model Number	97044
Material	Polyester
Color	Gray
Item Weight	11.2 ounces
Product Dimensions (L x W)	112"L x 53"W
UPC	883698970448
Included Components	Hammock Bug Net

7. WARRANTY AND SUPPORT

The Equip Outdoors Hammock Mosquito Net comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any product-related inquiries, please contact Equip customer service through the official [Equip Store on Amazon](#) or refer to the contact information provided with your purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B076M92NDC>

More documents and user manuals: <https://manuals.plus/>