

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Sanyo](#) /

> [Sanyo 6233002590 RCS-6HVPUS4E Air Conditioner Remote Control User Manual](#)

Sanyo RCS-6HVPUS4E

Sanyo 6233002590 RCS-6HVPUS4E Air Conditioner Remote Control User Manual

Model: RCS-6HVPUS4E

INTRODUCTION

This user manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Sanyo 6233002590 RCS-6HVPUS4E Air Conditioner Remote Control. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Sanyo 6233002590 RCS-6HVPUS4E is an original replacement remote control designed specifically for compatible Sanyo air conditioning units. It provides full control over various functions of your air conditioner, including power, temperature, mode, fan speed, and timer settings.

Components

- Sanyo 6233002590 RCS-6HVPUS4E Remote Control Unit
- Wall Mounting Cradle



Figure 1: The Sanyo RCS-6HVPUS4E remote control unit shown alongside its dedicated wall mounting cradle. The cradle features a label with a note regarding optimal placement.



Before fixing this mounting cradle on the wall, check that the remote control unit can operate normally from that position.

AIR CONDITIONER



LED CLEAN

ON·I/OFF·O

1HR.
⊖

TEMP.



QUIET

MODE

FAN SPEED

NIGHT SETBACK

FLAP

HIGH POWER

ON ⊕ TIMER OFF ⊖



CANCEL

CLOCK

SENSOR °C ↔ °F 12H ↔ 24H

ADR ACL

7FLZ A 8121



Figure 2: The Sanyo RCS-6HVPUS4E remote control with its lower battery compartment cover slid open, revealing additional control buttons.

SETUP

Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install or replace batteries:

1. Slide open the battery compartment cover located on the back of the remote control.
2. Insert two fresh, leak-proof AAA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.
4. After replacing batteries, press the small "ACL" (Reset) button using a pointed object (e.g., a pen tip) to reset the remote control.





Figure 3: The rear view of the Sanyo RCS-6HVPUS4E remote control, showing the battery compartment and printed instructions for battery replacement and the reset button.

Mounting the Cradle

The included wall mounting cradle allows for convenient storage of your remote control. Before permanently fixing the cradle to a wall, it is recommended to test the remote control's operation from the desired mounting position to ensure proper signal transmission to the air conditioning unit. Use appropriate screws (not included) to secure the cradle to a wall surface. Ensure the cradle is mounted in a location that provides a clear line of sight to the air conditioning unit for optimal infrared signal transmission.

OPERATING INSTRUCTIONS

This section details the primary functions and buttons of the Sanyo RCS-6HVPUS4E remote control.

Basic Operation

- **ON/OFF/O Button:** Press this button to turn the air conditioner unit on or off.
- **TEMP. Buttons (▲ / ▼):** Use the up (▲) and down (▼) arrow buttons to adjust the desired temperature setting.

Advanced Functions (Under Sliding Cover)

Slide down the lower cover of the remote control to access additional function buttons.

- **MODE Button:** Cycles through various operating modes such as Cool, Heat, Dry, Fan, and Auto.
- **FAN SPEED Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).

- **QUIET Button:** Activates a quiet operation mode, reducing fan noise.
- **NIGHT SETBACK Button:** Engages a mode that automatically adjusts temperature during sleep for energy saving and comfort.
- **FLAP Button:** Controls the vertical swing of the air conditioner's louver.
- **HIGH POWER Button:** Activates a powerful cooling/heating mode for rapid temperature change.
- **TIMER ON/OFF Buttons:** Set the timer for the air conditioner to turn on or off automatically.
- **CANCEL Button:** Cancels active timer settings.
- **CLOCK Button:** Sets the current time on the remote control's display.
- **LED CLEAN Button:** Activates a function to clean the air conditioner's internal LED components (refer to your air conditioner's manual for details).
- **1HR. Button:** Likely a quick timer setting for 1 hour.

MAINTENANCE

Battery Replacement

Refer to the "Battery Installation" section under Setup for detailed instructions on replacing batteries. Always use fresh, leak-proof AAA alkaline batteries to prevent damage to the remote control.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's finish or internal components.

TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control does not respond.	Dead or low batteries. Incorrect battery polarity. Remote control not aimed at AC unit. Obstruction between remote and AC unit.	Replace batteries with new AAA alkaline batteries. Ensure batteries are inserted with correct polarity. Aim the remote directly at the air conditioner's receiver. Remove any obstructions.
Display is dim or blank.	Low batteries.	Replace batteries.
Functions are not working correctly after battery replacement.	Remote control needs to be reset.	Press the "ACL" (Reset) button on the back of the remote control.

SPECIFICATIONS

Feature	Detail
Brand	Remote Control Transmitter (Sanyo compatible)

Feature	Detail
Manufacturer	Remote Control Transmitter
Model	RCS-6HVPUS4E
Part Number	B076MCDX32
Compatible Devices	Air Conditioner
Batteries Included	No
Batteries Required	No (Requires 2x AAA alkaline batteries)
Connection Type	Infrared
Item Number	RCS-6HVPUS4E
ASIN	B076MCDX32
Guaranteed software updates until	Unknown
First Available Date	17 July 2018
Product Discontinued	No
Maximum Range	10 Meters

COMPATIBLE AIR CONDITIONER MODELS

This remote control is compatible with the following Sanyo air conditioner models:

- SAP-KRV126EHE
- SAP-KR127EHAX
- SAP-KR97EHEAX
- SAP-CR9AEH
- SAP-KRV126EH
- SAP-KRV96EHE

It is specifically designed for use with units requiring the RCS-6HVPUS4E remote control.

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Sanyo 6233002590 RCS-6HVPUS4E remote control, please refer to the documentation provided with your original air conditioning unit or contact the manufacturer/seller directly. Keep your purchase receipt as proof of purchase for any warranty claims.