



Manuals.plus /

› [Seatcraft](#) /

› [Seatcraft Anthem Home Theater Seating \(Model 88-2216\) - User Manual](#)

Seatcraft 88-2216

Seatcraft Anthem Home Theater Seating (Model 88-2216) - User Manual

Brand: Seatcraft | Model: 88-2216

[Instructions](#) [Introduction](#) [Maintenance](#) [Safety Information](#) [Troubleshooting](#) [Setup](#) [Specifications](#) [Operating](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Seatcraft Anthem Home Theater Seating. Designed for comfort and functionality, this Italian leather power recline sofa features a fold-down table, powered headrests, arm storage, USB charging, and illuminated cup holders.



Figure 1: Seatcraft Anthem Home Theater Seating in black Italian leather, featuring a fold-down table, illuminated cup holders, and power recline.

2. SAFETY INFORMATION

- All foam and upholstered surfaces meet flammability standards.
- Keep away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks during operation of reclining mechanisms.
- Ensure power cords are not pinched or damaged.
- Do not stand on the footrest when extended.

3. SETUP AND ASSEMBLY

The Seatcraft Anthem seating is designed for simple assembly, typically taking 30 minutes or less. It is recommended to have two people for assembly due to the weight of the components.

3.1 Unpacking

- Carefully remove all components from the packaging.
- Inspect all parts for any damage. Contact customer support immediately if any damage is found.
- Ensure all parts listed in the packing list are present.

3.2 Assembly Steps

1. Connect the backrests to the seat bases. Ensure they click securely into place.
2. Connect any electrical cables between the seat sections.
3. Plug the power cord into a grounded electrical outlet.




Figure 2: Assembly diagram and dimensions for the Seatcraft Anthem Sofa. Note the minimum doorway width of 28 inches for entry.

4. OPERATING INSTRUCTIONS

4.1 Power Recline and Headrest Adjustment

Each seating position is equipped with a control panel, typically located on the inner side of the armrest. This panel allows for independent adjustment of the power recline and powered headrest.

- To recline: Press and hold the recline button (usually on the left) to extend the footrest and recline the backrest. Release when desired position is reached.
- To adjust headrest: Press and hold the headrest button (usually on the right) to move the headrest forward or backward. Release when desired position is reached.
- Home button: Press the central "Home" button to return both the recline and headrest to their default, upright positions.




Figure 3: Power Recline Control Guide. The control panel includes buttons for powered recline, powered headrest, a home button, and a USB charging port.

Your browser does not support the video tag.

Video 1: Demonstration of the Comfort View Adjustable Powered Headrests, showing how to adjust the headrest for optimal viewing comfort.

4.2 Fold-Down Table

The central seat of the sofa features a fold-down table. To deploy, gently pull the top of the backrest forward until it lays flat. The table includes integrated cup holders and a pop-up power panel.

4.3 USB Charging and Power Outlets

- **USB Ports:** Located on the control panel of each armrest and within the fold-down table's power panel.
- **Power Outlets:** The fold-down table's power panel includes 110V outlets for additional devices.
- **Wireless Charging Pad:** A wireless charging pad is integrated into the fold-down table. Place compatible devices on the pad for charging. The charging indicator light will change color (e.g., blue to green) to confirm charging.



Figure 4: USB charging port and wireless charging pad on the fold-down table, with an illuminated cup holder.

4.4 Illuminated Cup Holders and Ambient Lighting

- Cup Holders: Each armrest features an illuminated cup holder.
- Ambient Base Lights: The seating features ambient LED lighting along the base. These lights can be turned on or off via a switch on the control panel.



Figure 5: Ambient blue LED lighting along the base of the Seatcraft Anthem sofa, enhancing the home theater experience.

4.5 Arm Storage

Lift the armrest covers to access hidden storage compartments, ideal for remote controls, magazines, or other small items.

5. MAINTENANCE

5.1 Leather Care

- Regularly dust with a soft, dry cloth.
- For spills, blot immediately with a clean, absorbent cloth. Do not rub.
- Use a specialized leather cleaner and conditioner periodically, following the product's instructions.
- Avoid direct sunlight and heat sources to prevent drying and cracking of the leather.



SEATCRAFT ITALIAN LEATHER

Perfect balance of old-world craftsmanship
& modern-day technology



Eco
Friendly



Family & Pet
Friendly



Consistency
& Stability



Classic
Aesthetic

Figure 6: Italian leather upholstery, emphasizing the material's quality and texture.

5.2 General Cleaning

- Vacuum crevices and under cushions regularly to remove debris.
- Wipe down non-leather surfaces with a damp cloth and mild soap, then dry thoroughly.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power recline/headrest not working.	Power cord unplugged or loose connection.	Check all power connections, ensure the cord is securely plugged into the wall outlet and the sofa.
USB ports not charging.	Sofa not powered, or device not compatible.	Ensure the sofa is powered. Try a different USB cable or device.
Ambient lights not turning on.	Light switch off, or power issue.	Check the ambient light switch on the control panel. Verify main power connection.

If issues persist, please contact Seatcraft customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Seatcraft
Model Name	Anthem
Item Model Number	88-2216
Color	Black
Product Dimensions	43"D x 86"W x 43.5"H
Size	Sofa with Fold-Down Table
Back Style	Solid Back
Special Features	Adjustable, Durability, Wireless Charging
Unit Count	1 Count
Recommended Uses	Theater
Maximum Weight Recommendation	350 Pounds
Pattern	Solid
Finish Type	Leather
Room Type	Living Room
Age Range	Adult
Included Components	Cushion
Shape	Rectangular
Arm Style	Padded
Surface Recommendation	Hard Floor
Seat Back Interior Height	27.5 Inches
Indoor/Outdoor Usage	Indoor

Feature	Detail
Furniture Finish	Leather
Seat Height	43.5 Inches
Seat Depth	43 inches
Fill Material	Foam
Arm Height	25.5 Inches
Reclining Position Count	3
Is Customizable	No
UPC	815876026128
Form Factor	Recliner
Fabric Type	Leather
Upholstery Fabric Type	Leather
Item Weight	335 pounds
Date First Available	October 20, 2017

8. WARRANTY AND SUPPORT

8.1 Protection Plans

- Optional 3-Year Protection Plan available.
- Complete Protect plan also available, covering eligible past and future purchases.

8.2 Customer Support

For any inquiries, technical assistance, or warranty claims, please contact Seatcraft customer support. Refer to your purchase documentation for specific contact details.

This product is sold and fulfilled by Seatcraft. Returns are accepted until January 31, 2026.