

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SAMSUNG](#) /

› [Samsung Galaxy Tab A SM-T580 10.1-Inch Tablet User Manual](#)

SAMSUNG SM-T580

Samsung Galaxy Tab A 10.1-Inch Tablet User Manual

MODEL: SM-T580

Introduction

Welcome to the user manual for your new Samsung Galaxy Tab A 10.1-inch tablet. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.

What's in the Box

Upon opening your Samsung Galaxy Tab A package, you should find the following items:

- Samsung Galaxy Tab A 10.1-inch Tablet
- Bonus 32GB microSD Card
- Travel Adapter
- Micro USB Cable
- Quick Start Guide

Product Overview



Figure 1: Front view of the Samsung Galaxy Tab A 10.1-inch tablet, highlighting its display and sleek design.

The Samsung Galaxy Tab A SM-T580 features a 10.1-inch touchscreen display, providing a clear and vibrant viewing experience. It is equipped with an 8MP rear camera for capturing photos and videos. The tablet runs on Android OS and is powered by an Exynos 7870 Octa-Core processor, ensuring smooth performance for various applications. Its slim profile and lightweight design make it portable and comfortable to hold.

Setup

- 1. Initial Power On:** Press and hold the power button located on the side of the tablet until the Samsung logo appears.
- 2. Language Selection:** Upon first boot, you will be prompted to select your preferred language. Carefully choose English or your desired language to proceed. *(Note: Some international versions may default to other languages, requiring careful selection during initial setup.)*
- 3. Wi-Fi Connection:** Select your Wi-Fi network from the list and enter the password to connect to the internet. A stable internet connection is required for initial setup and software updates.
- 4. Google Account Sign-in:** Follow the on-screen prompts to sign in with your existing Google account or create a new one. This is essential for accessing the Google Play Store and other Google services.
- 5. MicroSD Card Installation:** Locate the microSD card slot on the side of the tablet. Gently insert the provided 32GB microSD card into the slot until it clicks into place. This expands your tablet's storage capacity.
- 6. Complete Setup:** Continue following the remaining on-screen instructions to finalize the setup process, including setting up security features and restoring data if applicable.

Operating Instructions

Basic Navigation

- **Home Button:** Press the physical home button below the screen to return to the home screen from any application.
- **Recent Apps Button:** Tap the left capacitive button to view recently opened applications.
- **Back Button:** Tap the right capacitive button to go back to the previous screen or step within an application.
- **Touchscreen Sensitivity:** The tablet's touchscreen is highly sensitive. Use light touches for navigation and interaction. Avoid excessive pressure.

Camera Usage

To use the camera, open the Camera application from your home screen or app drawer. Tap the shutter button to take a photo. You can switch between the front and rear cameras using the camera switch icon on the screen.

Connectivity

- **Wi-Fi:** Access Wi-Fi settings from the Quick Settings panel or the main Settings menu to connect to available networks. The tablet supports Wi-Fi 802.11 a/b/g/n/ac (2.4GHz + 5.0GHz).
- **Bluetooth:** Enable Bluetooth in settings to pair with compatible devices such as headphones, speakers, or keyboards.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive materials or harsh chemicals.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Charge the tablet using only the provided original charger and cable. It is recommended to keep the battery level between 20% and 80% for optimal longevity.
- **Software Updates:** Regularly check for and install software updates to ensure your tablet has the latest features and security patches.
- **Storage Management:** Periodically clear unnecessary files and uninstall unused applications to free up storage space and maintain performance.

Troubleshooting

Tablet does not power on:

Ensure the tablet is sufficiently charged. Connect it to the charger and wait a few minutes before attempting to power it on again.

Screen is unresponsive or slow:

Restart the tablet. If the issue persists, ensure your screen is clean and free of debris. Avoid using excessive force on the screen.

Accidental button presses in landscape mode:

The capacitive buttons (Home, Recent Apps, Back) are located on the short edge. When using the tablet in landscape orientation, be mindful of your grip to avoid inadvertently pressing these buttons. Adjusting your holding position can help prevent this.

Auto sleep/wake feature is too sensitive:

If your tablet frequently goes to sleep when using a smart cover, it may be due to the cover's magnet. Consider using a cover without a magnetic auto sleep/wake feature if this becomes problematic, as there is no direct

setting to disable this sensitivity.

Initial setup language is incorrect (e.g., Korean):

During the initial setup, carefully look for the language selection option, usually represented by a globe icon or a dropdown menu. Select English or your desired language before proceeding with other setup steps.

Specifications

Feature	Detail
Screen Size	10.1 Inches
Screen Resolution	1920x1080
Processor	Exynos 7870 Octa-Core (1.6GHz)
RAM	2 GB SDRAM DDR3
Internal Storage	16 GB SSD
Expandable Storage	Supports up to 200GB (via microSD card)
Operating System	Android 6.0 Marshmallow
Rear Camera Resolution	8 MP
Battery Type	7,300mAh Lithium-Ion Battery
Average Battery Life	13 Hours
Internet Connectivity	Wi-Fi 802.11 a/b/g/n/ac (2.4GHz + 5.0GHz)
Bluetooth Enabled	Yes
Input/Output	microUSB
Color	Black
Item Weight	1.16 pounds
Product Dimensions (LxWxH)	10.0" x 6.11" x 0.32"

Warranty and Support

Your Samsung Galaxy Tab A SM-T580 comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official Samsung support website. Additional protection plans may be available for purchase to extend coverage.

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Samsung Customer Support. You can find contact information on the Samsung website or in your Quick Start Guide.

Online Resources:

- [Samsung Official Support Website](#)
- [Visit the Samsung Store on Amazon](#)

Related Documents - SM-T580

	<p><u>Посібник користувача Samsung SM-T580</u></p> <p>Повний посібник користувача для планшета Samsung Galaxy Tab A 2016 (SM-T580), що охоплює налаштування, основні функції, програми та поради з використання.</p>
	<p><u>מדריך למשתמש Samsung Galaxy Tab (SM-X400, SM-X406B, SM-X520, SM-X526B, SM-X620, SM-X626B, SM-X820, SM-X826B, SM-X920, SM-X926B)</u></p> <p>הכל הוראות הפעלה, הדרות, תכונות, מדריך מקיף למשתמש עבור טאבלטים SM-X400, SM-X406B, SM-X520, SM-X526B, SM-X620, SM-X626B, SM-X820, SM-X826B, SM-X920, SM-X926B.</p>
	<p><u>Guida per l'utente Samsung Galaxy Tab Active 5</u></p> <p>Manuale completo per il tablet Samsung Galaxy Tab Active 5 (modelli SM-X300, SM-X306B, SM-X350, SM-X356B). Scopri come configurare, utilizzare e gestire il tuo dispositivo, incluse impostazioni, funzionalità, consigli di sicurezza e risoluzione dei problemi.</p>
	<p><u>Samsung Galaxy Tab A (Kids Edition) Quick Reference Guide</u></p> <p>This quick reference guide for the Samsung Galaxy Tab A and Tab A Kids Edition (SM-T290) covers setup, device features, customization, Samsung Care support, and the Galaxy Store. Learn how to personalize your tablet and access essential features.</p>
	<p><u>Samsung Galaxy Tab Active2: Rugged, Workflow-Ready Tablet</u></p> <p>Discover the Samsung Galaxy Tab Active2, a rugged, IP68-certified, and MIL-STD-810G compliant tablet designed for demanding work environments. Featuring an S Pen, enhanced touch modes, high-resolution cameras, and robust security with Samsung Knox, it's ideal for field service, logistics, and more.</p>
	<p><u>Samsung Galaxy Tab S11 & S11 Ultra Quick Start Guide and Terms & Conditions</u></p> <p>Concise guide to setting up your Samsung Galaxy Tab S11 and Tab S11 Ultra, including essential terms and conditions, legal information, and device specifications.</p>