

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Infanti](#) /

> [Infanti TRACK-FIT Car Seat Instruction Manual, Model 231NHB619BKG](#)

Infanti 231NHB619BKG

Infanti TRACK-FIT Car Seat Instruction Manual

Model: 231NHB619BKG

1. INTRODUCTION

This manual provides essential information for the correct installation, safe operation, and proper maintenance of your Infanti TRACK-FIT Car Seat. Please read all instructions carefully before using the car seat to ensure the maximum safety and comfort for your child. Keep this manual in a safe place for future reference.

2. SAFETY GUIDELINES

- **European Safety Standards:** This car seat complies with European safety standards, ensuring high levels of protection.
- **Weight Range:** Suitable for children weighing from 9 kg to 36 kg.
- **Proper Installation:** Always ensure the car seat is installed correctly and securely in your vehicle using the vehicle's seat belt system. An improperly installed car seat can compromise child safety.
- **Harness Use:** For children within the 9-18 kg weight range, always use the integrated 5-point harness system.
- **Booster Use:** For children within the 15-36 kg weight range, the car seat can be converted into a booster seat, using the vehicle's 3-point seat belt to secure the child.
- **Child Supervision:** Never leave a child unattended in the car seat.
- **Damage Inspection:** Regularly inspect the car seat for any signs of wear or damage. Discontinue use if any damage is found.

3. PRODUCT OVERVIEW

The Infanti TRACK-FIT Car Seat is designed for versatility and safety, adapting to your child's growth. Key components include:

- **Adjustable 5-Point Harness:** Secures your child firmly in the car seat.
- **Adjustable Head Support:** Provides additional comfort and protection for your child's head and neck.
- **Detachable Backrest:** Allows the car seat to convert into a booster seat for older children.
- **Washable and Removable Cover:** Facilitates easy cleaning and maintenance.



Figure 1: Infanti TRACK-FIT Car Seat in its full configuration, suitable for younger children.

4. SETUP AND INSTALLATION

4.1. Car Seat Mode (9-18 kg)

For children weighing between 9 kg and 18 kg, use the car seat with the backrest and the integrated 5-point harness.

1. **Position the Car Seat:** Place the car seat on the vehicle's rear seat, ensuring it is stable and flush against the vehicle's seat back.
2. **Route the Vehicle Seat Belt:** Follow the car seat's designated belt path indicators (usually red for forward-facing) to route the vehicle's 3-point seat belt through the car seat.

3. **Secure the Seat Belt:** Buckle the vehicle's seat belt and pull it tight to remove all slack. The car seat should not move more than 1 inch (2.5 cm) from side to side or front to back at the belt path.
4. **Adjust Head Support:** Adjust the head support to the appropriate height for your child, ensuring their shoulders are aligned with the harness slots.

4.2. Booster Seat Mode (15-36 kg)

For older children weighing between 15 kg and 36 kg, the car seat can be converted into a booster seat by removing the backrest. The child will then be secured using the vehicle's 3-point seat belt.

1. **Remove the 5-Point Harness:** Detach and store the 5-point harness system according to the instructions provided on the car seat label or in the full manual.
2. **Detach the Backrest:** Carefully unclip or unlatch the backrest from the booster base. Refer to the specific mechanisms on your car seat for proper removal.
3. **Position the Booster:** Place the booster base on the vehicle's rear seat.
4. **Secure the Child:** Seat your child in the booster. Route the vehicle's 3-point seat belt across your child's shoulder and lap. Ensure the shoulder belt lies across the middle of the shoulder and chest, and the lap belt is low on the hips, touching the thighs.



Figure 2: Infanti TRACK-FIT Car Seat converted to a booster seat, showing the base without the backrest.

5. OPERATING INSTRUCTIONS

5.1. Securing Your Child (Car Seat Mode)

1. Place your child in the car seat.
2. Bring the 5-point harness straps over your child's shoulders and buckle them into the central buckle.
3. Pull the harness adjustment strap to tighten the harness until it is snug against your child's body. You should not be able to pinch any excess webbing at your child's shoulder.
4. Ensure the chest clip is positioned at armpit level.

5.2. Adjusting the Head Support

The head support can be adjusted to accommodate your child's height. Locate the adjustment lever or button, usually at the top or back of the headrest. Press or squeeze the lever/button and slide the head support up or down until it is at the correct height, ensuring the shoulder straps are at or slightly above your child's shoulders when in car seat mode.

6. MAINTENANCE

6.1. Cleaning the Cover

The car seat features a washable and removable cover for easy cleaning.

1. **Remove the Cover:** Carefully detach the fabric cover from the car seat frame. Refer to the specific attachment points on your model.
2. **Washing Instructions:** Machine wash the cover in cold water on a delicate cycle with mild detergent. Do not use bleach.
3. **Drying:** Air dry the cover. Do not tumble dry or iron.
4. **Reattach the Cover:** Once completely dry, reattach the cover to the car seat frame, ensuring all straps and buckles are correctly positioned.

6.2. Cleaning the Harness and Buckle

Wipe the harness straps and buckle with a damp cloth and mild soap. Do not immerse the buckle in water or use harsh cleaning agents, as this may affect its performance.

7. TROUBLESHOOTING

- **Car Seat Not Firmly Secured:** If the car seat moves more than 1 inch (2.5 cm) at the belt path, re-read the installation instructions carefully. Ensure the vehicle's seat belt is pulled as tight as possible, removing all slack. You may need to press down firmly on the car seat while tightening the belt.
- **Harness Too Loose:** Ensure the harness adjustment strap is pulled firmly. Check that the harness straps are not twisted and are routed correctly through the appropriate shoulder slots.
- **Difficulty Adjusting Head Support:** Ensure no fabric or debris is obstructing the adjustment mechanism. Apply firm but gentle pressure while operating the adjustment lever/button.
- **Buckle Sticking:** Clean the buckle with a damp cloth. Avoid lubricants or oils. If the buckle continues to stick, contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	231NHB619BKG
Minimum Weight Recommendation	9 Kilograms
Maximum Weight Recommendation	36 Kilograms
Product Dimensions	48 x 54.5 x 65.5 cm
Product Weight	5.55 kg
Installation Type	Vehicle Seat Belt
Color	Gris (Grey)

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Infanti website. For technical support, spare parts, or any other inquiries, please contact Infanti customer service through their official channels.