NETGEAR D2200D

NETGEAR D2200D ADSL Modem/Wireless Combo User Manual

Model: D2200D
Brand: NETGEAR

1. Introduction

The NETGEAR D2200D is a single WAN 802.11n ADSL gateway platform designed to provide a highly cost-effective solution with NETGEAR's renowned quality, reliability, ease-of-use, and best-in-class performance. This device allows users to experience fast N300 speeds, consistent and reliable connections, and an easy-to-manage network.
Key features include:

- Compatible with Frontier ADSL Service (not VDSL).
- Fast WiFi N300 speeds for reliable video streaming.
- Integrated 4-Port Wireless Router.
- 4 Gigabit Ethernet Ports.
- 1 DSL Phone Port.
- Power On/Off Button.




Figure 1: Front view of the NETGEAR D2200D modem, showing indicator lights for Power, Wireless, USB, DSL, and Internet.

2. Setup Guide

2.1 Package Contents

Before you begin, ensure your package contains the following items:

- NETGEAR D2200D Modem/Wireless Combo

- Ethernet Cable
- DSL Cable
- Power Adapter
- Quick Start Guide (if included)

2.2 Connecting Your Modem

1. **Connect to DSL Line:** Plug one end of the DSL cable into the DSL port on the back of the D2200D modem and the other end into your wall's DSL jack.
2. **Connect to Power:** Connect the power adapter to the modem's power port and then plug the adapter into an electrical outlet. Press the Power On/Off button if necessary.
3. **Connect to Computer (Optional):** For a wired connection, connect one end of the Ethernet cable to any of the Gigabit Ethernet ports on the modem and the other end to your computer's Ethernet port.
4. **Wait for Lights:** Allow a few minutes for the modem to power on and establish a connection. The Power, DSL, and Internet indicator lights on the front of the modem should turn solid green. The Wireless light should also be solid green.



Figure 2: Side view of the NETGEAR D2200D, highlighting the indicator lights and their typical solid green status when connected.

2.3 Initial Configuration (Wireless)

To connect wirelessly:

1. Locate the Wi-Fi Network Name (SSID) and Password (Network Key) on the label on the bottom or back of your

D2200D modem.

2. On your wireless device (laptop, smartphone, tablet), search for available Wi-Fi networks.
3. Select the SSID that matches your modem's label.
4. Enter the Wi-Fi password when prompted.
5. Once connected, open a web browser and try to access a website to confirm internet connectivity.

The D2200D supports Push 'N' Connect (WPS) for one-touch setup with compatible devices.

3. Operating Your Modem/Router

3.1 Indicator Lights

Understanding the indicator lights on the front of your D2200D can help you monitor its status:

- **Power:** Solid green indicates the modem is powered on. Blinking indicates a startup sequence.
- **Wireless:** Solid green indicates the wireless function is enabled. Blinking indicates wireless activity.
- **USB:** Not applicable for standard operation, typically for future features or specific configurations.
- **DSL:** Solid green indicates a stable DSL connection. Blinking indicates the modem is trying to establish a DSL connection. Off means no DSL signal.
- **Internet:** Solid green indicates successful internet access. Blinking indicates internet activity. Off means no internet connection.

3.2 Accessing the Router Settings

To manage advanced settings, such as Wi-Fi name, password, or port forwarding, you can access the router's web interface:

1. Ensure your computer is connected to the D2200D (wired or wirelessly).
2. Open a web browser (e.g., Chrome, Firefox, Edge).
3. In the address bar, type the default gateway IP address (commonly192.168.1.1 or routerlogin.net) and press Enter.
4. Enter the default username (usually *admin*) and password (usually *password* or *admin*). These details are often found on the modem's label.
5. Follow the on-screen prompts to configure your settings.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your D2200D modem/router:

- **Placement:** Place the modem in a well-ventilated area, away from direct sunlight, heat sources, and obstructions that could block airflow.
- **Cleaning:** Gently wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- **Firmware Updates:** Periodically check the NETGEAR support website for firmware updates. Keeping your firmware up-to-date can improve performance, add features, and enhance security. Note that for Frontier-branded devices, firmware updates may be managed by Frontier.
- **Restarting:** If you experience slow speeds or connectivity issues, try restarting the modem by unplugging the power adapter for 10 seconds and then plugging it back in.

5. Troubleshooting

This section addresses common issues you might encounter with your D2200D modem/router.

Problem	Possible Cause	Solution
No Power Light	Power adapter not connected; power outlet faulty.	Ensure power adapter is securely connected to modem and a working electrical outlet. Press the Power On/Off button.
DSL Light Blinking or Off	No DSL signal; faulty DSL cable; service issue.	Check DSL cable connections. Ensure DSL service is active. Contact your Internet Service Provider (ISP) if the issue persists.
Internet Light Off	No internet connection from ISP; modem not authenticated.	Ensure DSL light is solid green. Restart the modem. Verify account details with your ISP.
Cannot Connect to Wi-Fi	Incorrect Wi-Fi password; Wi-Fi disabled; device too far.	Verify Wi-Fi password. Ensure Wireless light is solid green. Move closer to the modem. Try restarting the modem.
Slow Internet Speeds	Network congestion; interference; outdated firmware.	Restart modem and connected devices. Check for other devices consuming bandwidth. Consider firmware update if available.
Firmware Update Issues (Specific to Frontier)	Firmware updates are controlled by Frontier for this specific model.	If you are a Frontier customer, firmware updates are typically pushed by Frontier. If you are not a Frontier customer, this device may not receive updates and might have compatibility issues with other ISPs. Contact Frontier support for firmware-related inquiries if you are a Frontier customer.

For further assistance, refer to the contact information provided on your device or contact your Internet Service Provider.

6. Specifications

Feature	Description
Model Number	D2200D
Wireless Standard	802.11n (N300 speeds)
ADSL Compatibility	ADSL/ADSL2+ Service Only (Compatible with Frontier ADSL Service)
Ethernet Ports	4 x Gigabit Ethernet Ports
DSL Port	1 x DSL Phone Port
Security Features	WPS (Wi-Fi Protected Setup) for one-touch setup

Feature	Description
Dimensions	7.4 x 5.28 x 3.31 inches
Weight	1.04 Pounds
Manufacturer	Netgear
First Available Date	October 21, 2017



Figure 3: Diagram illustrating the NETGEAR D2200D's role in a whole home system, connecting ADSL internet to various devices via 802.11n WiFi.

7. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or visit the official NETGEAR support website. Warranty terms may vary based on region and retailer.

For technical support, troubleshooting, and additional resources, please visit the NETGEAR Support website. If your device was provided by Frontier, please contact Frontier Technical Support directly as indicated on the device label or their official support channels.

© 2024 NETGEAR. All rights reserved. Information subject to change without notice.