

[Manuals.plus](#) /

› [Superer](#) /

› UL Listed AC Charger User Manual for Acer Aspire N15W4 E11 ES1-111M ES1-731 ES1-732 ES1-111M-C40S ES17 ZYL ZHK Laptop Adapter

Superer ADP190342L

UL Listed AC Charger User Manual

Model: ADP190342L | Brand: Superer

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Superer UL Listed AC Charger. Please read this manual thoroughly before using the product and retain it for future reference.

IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Use only with compatible devices as specified.
- Do not expose the charger to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the charger to strong impacts.
- Do not disassemble or attempt to repair the charger yourself. Refer to qualified service personnel.
- Ensure proper ventilation around the charger during use.
- Unplug the charger from the power outlet when not in use or during electrical storms.

UL CERTIFIED AND LISTED



Up to UL's nationally
recognized standards for high-level electronic safety

Superer	Safety Certifications
✓	UL Listed - passed UL safety tests for high-level electronic safety.
✓	FCC approved - meets regulated limits for ionizing radiation.
✓	CE marking - meets EU safety, health and environmental protection requirements.

Image Description: This image displays the UL Listed certification logo, indicating compliance with nationally recognized standards for high-level electronic safety. It also shows FCC and CE certifications, confirming the product meets regulated limits for ionizing radiation and EU safety, health, and environmental protection requirements.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Superer AC Adapter
- 1 x Power Cord



Image Description: A top-down view of the Superer AC charger, featuring the main adapter unit, the DC output cable with a right-angle round connector, and a separate AC input power cord. The components are neatly arranged on a white surface.

SETUP INSTRUCTIONS

Follow these steps to set up your AC charger:

1. **Connect the Power Cord:** Insert the AC power cord into the input port of the AC adapter. Ensure it is firmly seated.
2. **Connect to Power Outlet:** Plug the other end of the AC power cord into a standard wall outlet or surge protector.
3. **Connect to Laptop:** Insert the DC output connector (round tip) from the AC adapter into the charging port of your compatible Acer laptop. Ensure the connection is secure.

Charging Port

Check the shape of your charging port before purchase.




Image Description: This image illustrates the correct charging port type for the adapter. It shows a close-up of a laptop's charging port, highlighting that a "Round Tip" connector is compatible (green checkmark) while a "USB-C" connector is not (red cross).



Consistent Power Supply

Provide consistent & stable power for your laptop.

Image Description: The AC charger is shown connected to a laptop on a desk, with the power cord plugged into a power strip. This demonstrates a typical setup for providing consistent power to the laptop.

OPERATING INSTRUCTIONS

Once connected, the charger will automatically begin supplying power to your laptop and charging its battery. The LED indicator on the adapter will illuminate when power is being supplied.

Compatibility

This charger is designed for specific Acer laptop models requiring 19V output. Please verify your laptop's power requirements before use.



Compatibility

19V	2.37A	45W	✓
19V	3.42A	65W	✓
19V	4.74A	90W	✗

Image Description: A compatibility chart indicating that the charger supports 19V, 2.37A, 45W (green checkmark), but not 19V, 3.42A, 65W or 19V, 4.74A, 90W (red cross). This highlights the specific power output capabilities of the charger.

CARE AND MAINTENANCE

- Keep the charger clean by wiping it with a soft, dry cloth.
- Store the charger in a cool, dry place when not in use.
- Avoid wrapping the cables too tightly to prevent damage to the internal wires.
- Regularly inspect the cables and connectors for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Charger not powering laptop.	Loose connection, incompatible device, faulty outlet.	Ensure all connections are secure. Verify laptop model compatibility. Try a different power outlet.
Laptop not charging.	Laptop battery issue, charger not fully connected.	Check if the charger's LED indicator is on. Ensure the DC connector is fully inserted into the laptop's charging port. Test with another compatible charger if available.
Charger feels hot.	Normal operation, poor ventilation, excessive load.	A slight warmth is normal. Ensure adequate airflow around the charger. If excessively hot, disconnect immediately and contact support.

SPECIFICATIONS

Feature	Detail
Brand	Superer
Model Number	ADP190342L
Input Voltage	110 Volts
Output Voltage	19V
Output Amperage	2.37 Amps
Output Wattage	45W
Connector Type	Round Connector
Dimensions (LxWxH)	4.21 x 1.85 x 1.22 inches
Item Weight	11.2 ounces
Special Feature	Overcharge Protection



Size: 4*1.7*1.13in
Item Dimension

Image Description: This image shows the compact size of the AC adapter, with text indicating its dimensions as 4*1.7*1.13 inches (approximately 4.21 x 1.85 x 1.22 inches), emphasizing its portability.

WARRANTY AND SUPPORT

Superer provides customer support for this product. For any issues or inquiries, please refer to the following:

- **Replacement Service:** Available within 12 months of purchase.

- **Refund Policy:** Full refund available within 30 days of purchase.
- **Contact Support:** For quick feedback and assistance, please visit the [Superer Store on Amazon](#) or contact their customer service directly.

Positive Customer Support

Refund Within 30 Days of Purchase
and Replace Service Within 12 Months



12

Replace Service Within 12 Months

Worry-free after sales



Replace Service
Within 12 Months



Refund Within
30 Days of Purchase



Quick feedback
to any problems

Image Description: This graphic highlights Superer's customer support policies, including a "Replace Service Within 12 Months" and "Refund Within 30 Days of Purchase," along with a promise for "Quick feedback to any problems."

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B076PDJ5WQ>

More documents and user manuals: <https://manuals.plus/>