

## KORG PA700

# Korg PA700 61-Key Arranger Keyboard and Bundle User Manual

Model: PA700

## 1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Korg PA700 61-Key Arranger Keyboard bundle. This bundle includes the Korg PA700 keyboard, an adjustable X-style keyboard bench, and an adjustable double X keyboard stand. Please read this manual thoroughly before using the product to ensure proper and safe operation.

The Korg PA700 features KORG's advanced EDS-X (Enhanced Definition Synthesis-eXpanded) sound engine, offering over 1,700 ready-to-play sounds. It includes a capacitive TouchView display for intuitive control and 2x25 Watt amplifiers driving two loudspeakers in a bass-reflex enclosure for a rich sound experience. The instrument also provides 148 studio-quality effect types for sound customization.

## 2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Korg PA700 61-Key Arranger Keyboard
- Adjustable X Style Keyboard Bench
- Adjustable Double X Keyboard Stand
- Power Cable
- Music Rest



Figure 2.1: Overview of the Korg PA700 Arranger Keyboard, adjustable bench, and double X stand included in the bundle.

## 3. SETUP INSTRUCTIONS

---

### 3.1 Assembling the Keyboard Stand

1. Unfold the adjustable double X keyboard stand.
2. Adjust the height to your preferred playing position using the locking mechanism. Ensure the stand is stable before placing the keyboard.



Figure 3.1: The adjustable double X keyboard stand, ready for assembly and height adjustment.

### 3.2 Assembling the Keyboard Bench

1. Unfold the adjustable X-style keyboard bench.
2. Ensure all legs are securely locked into place for stability.



Figure 3.2: The adjustable X-style keyboard bench in its unfolded, ready-to-use state.

### 3.3 Connecting the Korg PA700 Keyboard

1. Place the Korg PA700 keyboard securely on the assembled stand.
2. Insert the power cable into the AC IN port on the rear panel of the keyboard.
3. Connect the other end of the power cable to a suitable power outlet.
4. If using external audio equipment, connect audio cables to the appropriate output jacks (e.g., L/MONO, R) on the rear panel.
5. For headphones, connect to the headphone jack on the front left side of the keyboard.



Figure 3.3: The rear panel of the Korg PA700, showing various input and output ports including AC IN, audio outputs, and USB connections.

## 4. OPERATING INSTRUCTIONS

### 4.1 Powering On/Off

- To power on, press the POWER button located on the left side of the keyboard.
- To power off, press and hold the POWER button until the unit shuts down.

### 4.2 Navigating the TouchView Display

The Korg PA700 features a capacitive TouchView display. Interact with the display by touching icons and menus directly with your finger. The redesigned graphical interface is designed for ease of use and readability.



Figure 4.1: Top view of the Korg PA700, highlighting the central TouchView display and surrounding control panel.

### 4.3 Sound Selection and Customization

The PA700 includes over 1,700 ready-to-play sounds, powered by the EDS-X sound engine. These include a wide range of instruments from classic keyboards to orchestral sounds. Use the TouchView display to browse and select sounds.

### 4.4 Using Studio-Quality Effects

The keyboard offers 148 effect types. For accompaniment tracks, two insert effects and two master effects can be applied. For real-time keyboard tracks, one insert effect and two master effects are available. Access and adjust these effects through the TouchView display's effect section.



Figure 4.2: Angled view of the Korg PA700, showing the keyboard, control panel, and an installed music rest.

## 5. MAINTENANCE

---

### 5.1 Cleaning

- Use a soft, dry cloth to clean the surface of the keyboard, stand, and bench.
- For stubborn dirt, slightly dampen the cloth with water and a mild, non-abrasive cleaner, then wipe dry immediately.
- Avoid using abrasive cleaners, solvents, or waxes, as these can damage the finish.

### 5.2 Storage

- Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for extended periods, cover the keyboard to protect it from dust.

## 6. TROUBLESHOOTING

---

### 6.1 No Power

- Ensure the power cable is securely connected to both the keyboard and a working power outlet.
- Check if the power outlet is functional by plugging in another device.

### 6.2 No Sound

- Verify that the master volume knob is turned up.
- If using headphones, ensure they are properly plugged in and test with another audio source.
- If using external speakers, check their power and connections.



### 6.3 Display Not Responding

- Try restarting the keyboard by powering it off and on again.
- Ensure your fingers are clean and dry when interacting with the TouchView display.

### 7. SPECIFICATIONS







Feature	Specification
Model Name	PA700
Brand	KORG
Number of Keys	61
Instrument Type	Electronic Keyboard (Arranger)
Sound Engine	EDS-X (Enhanced Definition Synthesis-eXpanded)
Sounds	Over 1,700 ready-to-play sounds
Effects	148 types (2 Insert/2 Master for accompaniment, 1 Insert/2 Master for real-time)
Amplifiers	2 x 25 Watt
Speakers	2 loudspeakers in bass-reflex enclosure
Display	Capacitive TouchView display
Connectivity Technology	Auxiliary, 3.5mm Jack (Headphone)
Power Source	Corded Electric
Item Weight	30.8 pounds (Keyboard only)
Product Dimensions	9.1 x 9.1 x 9.1 inches (Packaging/Shipping dimensions, actual keyboard dimensions may vary)
Color	Black, Wine Red
UPC	657379010538

### 8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Korg website or contact Korg customer service directly. Specific warranty terms may vary by region and retailer.

You can find more information and support resources by visiting the official KORG store online [KORG Official Store](#).

Related Documents - PA700

	<p><a href="#">KORG Pa700 &amp; Pa700 ORIENTAL User Manual</a></p> <p>Comprehensive user manual for the KORG Pa700 and Pa700 ORIENTAL professional arranger keyboards. This guide provides detailed instructions on instrument setup, interface navigation, sound editing, style customization, song playback, and advanced features for musicians.</p>
	<p><a href="#">Korg Pa50 Professional Arranger User Manual</a></p> <p>A comprehensive user manual for the Korg Pa50 Professional Arranger keyboard, detailing its features, operations, and functions for live performance and music creation.</p>
	<p><a href="#">KORG Pa4X Professional Arranger User Manual</a></p> <p>Comprehensive user manual for the KORG Pa4X Professional Arranger keyboard, covering setup, features, sound editing, performance, and more. Learn to master your KORG Pa4X.</p>
	<p><a href="#">KORG TRITON Le Service Manual</a></p> <p>This service manual provides detailed technical information for the KORG TRITON Le synthesizer keyboard, including structural diagrams, block diagrams, circuit diagrams, diagnostic procedures, and comprehensive parts lists for maintenance and repair.</p>
	<p><a href="#">KORG Pa80 Professional Arranger User's Manual</a></p> <p>Comprehensive user's manual for the KORG Pa80 professional arranger keyboard, detailing its features, operations, tutorials, MIDI capabilities, and system settings for musicians.</p>
	<p><a href="#">KORG Pa300 Professional Arranger User Manual: Features, Operation, and Safety</a></p> <p>This user manual provides comprehensive information on the KORG Pa300 professional arranger keyboard, covering its features, operation, safety instructions, and technical specifications. Learn how to use sounds, styles, songs, and more.</p>