

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HoneyGuaridan](#) /

› [HoneyGuaridan W25 Smart Automatic Pet Water Fountain Dispenser User Manual](#)

HoneyGuaridan W25

HoneyGuaridan W25 Smart Automatic Pet Water Fountain Dispenser User Manual

INTRODUCTION

The HoneyGuaridan W25 Smart Automatic Pet Water Fountain Dispenser is designed to encourage your pets to drink more water, which is essential for their vital organ function and overall health. This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your new pet water fountain.

On average, pets should drink one ounce of water per pound of weight daily. The W25 model offers convenience and ensures your pet stays hydrated with its intelligent features.

PACKAGE CONTENTS

- HoneyGuaridan W25 Automatic Pet Water Fountain Dispenser ×1
- Charger ×1
- User Manual ×1

PRODUCT OVERVIEW

The HoneyGuaridan W25 features a compact and patented design, ensuring fresh water circulation for your pets. It includes LED indicators for different operating modes and water level status.



Image: HoneyGuardan W25 Smart Automatic Pet Water Fountain Dispenser. This image displays the complete assembled unit with water circulating.

LED Indicators

The fountain utilizes LED lights to indicate its current operating mode and status:

- **Green light:** Continuous working mode
- **Blue light:** Infrared induction mode (Smart mode)
- **Red light:** Water deficiency state
- **White light:** Intermittent working mode

4 LED lights show 4 different operating modes

- Green light – Continue-working mode
- Blue light – Smart mode
- Red light – Water deficiency state
- White light – Intermittent working mode



○ White light



● Green light



● Blue light



● Red light

Image: LED indicators for operating modes. This diagram illustrates the different LED colors and their corresponding operational states.

Dimensions



Image: Product dimensions. This image shows the physical measurements of the fountain.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all components from the packaging.
2. **Prepare Filter:** Before first use, soak the carbon filter in clean water for 3 minutes. This removes any fine powder and ensures optimal filtration.

Pyroelectric Infrared Sensor

Sector Field 1 meter length of two sides Central Zone 1.5 meters
Automatically startup the circulation of water for 2 minutes
when pets get close to water fountain.



Image: Activated carbon filter. This image illustrates the multi-layer design of the filter.

3. **Assemble Fountain:** Follow the assembly instructions provided in the quick start guide (if included) or refer to the product diagrams to correctly assemble the pump, filter, and top tray. Ensure all parts are securely fitted.
4. **Fill with Water:** Fill the reservoir with clean water. Do not exceed the maximum fill line. The fountain has a 2.5L (88oz) capacity.
5. **Connect Power:** Plug the charger into a power outlet and connect it to the fountain.
6. **Initial Operation:** For the first few days, it is recommended to operate the fountain in **Continuous Mode** to help your pet become accustomed to it. Monitor your pet's water intake to prevent dehydration.

OPERATING MODES

The HoneyGuardan W25 offers three distinct working modes, selectable by pressing the power button.

1. Continuous Mode (Green Light)

- **Description:** The water fountain continuously dispenses water 24 hours a day.
- **Usage:** Ideal for initial introduction to attract pets to drink. Also suitable for pets who prefer constant water flow.

2. Infrared Induction Mode (Blue Light)

- **Description:** The water fountain dispenses water only when the infrared sensor detects your pet within 1.5 meters. Water circulation lasts for 2 minutes after detection.
- **Usage:** Recommended once your pet is accustomed to the fountain. This mode conserves energy and reduces continuous noise, especially at night.

Act now !

Only the current inventory have 3 extra fillters



The diagram shows a cross-section of a water filter. Above the filter, there is a cloud of various contaminants represented by small blue squares, grey circles, and blue circles. Three large black arrows point downwards from this cloud towards the top surface of the filter. The filter itself is a circular disc with a white top layer and a dark grey bottom layer. Below the filter, three large blue arrows point downwards, indicating the flow of filtered water.

Imported coconut shell activated carbon filter
Tremendously reducing the heavy metal contaminants and odors ,
removing the bad taste of water.

Soak the filter for 3 mins to remove fine powder before using

Image: Pyroelectric Infrared Sensor. This diagram shows how the sensor detects a pet's presence.

3. Intermittence Mode (White Light)

- **Description:** The water fountain circulates water for 30 minutes, then shuts off for 30 minutes, repeating this cycle.
- **Usage:** An energy-efficient option that provides periodic fresh water, suitable for pets with established drinking habits.

HONEYGUARDIAN

Suitable for All Cats and Small & Medium-sized Dogs



HONEYGUARIDAN

Suitable for All Cats and Small & Medium-sized Dogs



Images: Pets using the fountain. These images show a cat and a small dog drinking from the HoneyGuardan W25 fountain.

MAINTENANCE

Regular cleaning and filter replacement are crucial for the longevity of your fountain and your pet's health.

Cleaning the Fountain

1. **Disassembly:** Unplug the fountain and carefully disassemble all parts, including the pump, filter tray, and top cover.
2. **Wash Components:** Wash all components (except the pump and charger) with water and a mild cleanser. Rinse thoroughly to remove any soap residue.
3. **Clean Pump:** The pump should be cleaned regularly to prevent mineral buildup and ensure proper function. Refer to the pump's specific cleaning instructions if available.
4. **Reassemble:** Ensure all parts are completely dry before reassembling the fountain.

Filter Replacement

- Replace the carbon filters every 2 to 3 weeks to maintain water quality and ensure the water pump works efficiently.

- Always soak new filters in water for 3 minutes before installation.

TROUBLESHOOTING

- **Fountain Not Dispensing Water:**

- Check if the power adapter is securely plugged in.
- Ensure there is sufficient water in the reservoir. If water is low, the red LED will illuminate, and the fountain will stop working. Refill water to the appropriate level.
- Clean the pump. Debris or mineral buildup can obstruct water flow.
- Verify the operating mode. In Infrared Induction Mode, water only flows when a pet is detected.

- **Unusual Noise from Pump:**

- This often indicates low water level. Refill the reservoir.
- Clean the pump. Hair or debris can cause the pump to vibrate or make noise.

- **Water Quality Issues (e.g., odor, cloudiness):**

- Replace the carbon filter.
- Thoroughly clean all fountain components.

- **Infrared Sensor Not Activating:**

- Ensure the fountain is in Infrared Induction Mode (blue LED).
- Check for obstructions blocking the sensor.
- Verify the pet is within the 1.5-meter detection range.

SPECIFICATIONS

Feature	Specification
Brand	HoneyGuardian
Model	W25
Capacity	2.5 Liters (88 oz)
Material	Polypropylene (PP)
Product Dimensions (L x W x H)	10.3 x 7.8 x 6.5 inches (approximate)
Item Weight	2.44 pounds
Infrared Sensor Range	Up to 1.5 meters
Working Modes	Continuous, Infrared Induction, Intermittence

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the HoneyGuardian customer service directly. Details are typically available on the manufacturer's official website or through your retailer.

© 2023 HoneyGuardian. All rights reserved.