

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Tucano](#) /
- › Tucano Mini Speaker MA-MINI-BK User Manual

Tucano MA-MINI-BK

Tucano Mini Speaker MA-MINI-BK User Manual

Model: MA-MINI-BK

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Tucano Mini Speaker MA-MINI-BK. Please read this manual thoroughly before using the device and retain it for future reference.

2. PRODUCT OVERVIEW

The Tucano Mini Speaker MA-MINI-BK is a compact and portable audio device designed for high-quality sound on the go. Constructed from anodized aluminum, it offers durability and a sleek design.



Figure 1: Tucano Mini Speaker MA-MINI-BK. This image displays the compact, cylindrical black speaker with its top speaker grille and the Tucano logo on the side. A micro-USB port is visible at the bottom.

Key Features:

- **Material:** Anodized aluminum for durability and premium feel.
- **Audio Output:** 3W speaker for clear sound.
- **Battery:** Integrated 300 mAh battery.
- **Playback Time:** Up to 3 hours of continuous audio at maximum volume.
- **Charging:** Fast charging via Micro-USB (1A input).

3. SETUP AND CHARGING

Initial Charging:

1. Locate the Micro-USB charging port on the speaker.
2. Connect the provided Micro-USB cable to the speaker's charging port.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.

4. The charging indicator light (if present) will illuminate.
5. Allow 1-2 hours for a full charge. The indicator light may change or turn off once fully charged.

Note: For optimal battery life, fully charge the speaker before first use.

4. OPERATING INSTRUCTIONS

Power On/Off:

- To power on the speaker, press and hold the power button (refer to device for exact location).
- To power off, press and hold the power button again until the indicator light turns off.

Bluetooth Pairing:

The Tucano Mini Speaker is designed for wireless audio streaming. Follow these steps to pair it with your device:

1. Ensure the speaker is powered on and within close proximity to your Bluetooth-enabled device (e.g., smartphone, tablet).
2. The speaker should automatically enter pairing mode, indicated by a flashing LED light.
3. On your device, navigate to the Bluetooth settings.
4. Scan for available devices. You should see "Tucano Mini Speaker" or a similar name appear in the list.
5. Select the speaker from the list to initiate pairing.
6. Once successfully paired, the speaker's LED indicator will typically stop flashing and remain solid.

Note: If prompted for a password, enter "0000".

Audio Playback:

Once paired, you can play audio from your connected device. Control volume and track selection directly from your paired device.

5. SPECIFICATIONS

Feature	Detail
Brand	Tucano
Model	MA-MINI-BK
Material	Anodized Aluminum
Speaker Output	3W
Battery Capacity	300 mAh
Continuous Playback Time	Up to 3 hours (at max volume)
Charging Input	1A via Micro-USB
Charging Time	1-2 hours
Connectivity	Bluetooth (for audio), Micro-USB (for charging)

Mounting Type	Tabletop Stand
Color	Black

6. TROUBLESHOOTING

No Power:

- Ensure the speaker is fully charged. Connect it to a power source using the Micro-USB cable.
- Verify that the power button is pressed and held correctly to turn on the device.

No Sound:

- Check if the speaker is successfully paired with your device via Bluetooth.
- Ensure the volume on both the speaker and your connected device is turned up.
- Confirm that the audio source on your device is playing.
- Try unpairing and re-pairing the speaker with your device.

Bluetooth Disconnection:

- Ensure the speaker and your device are within the effective Bluetooth range (typically 10 meters or 33 feet) and there are no significant obstructions.
- Check for interference from other wireless devices.
- Restart both the speaker and your Bluetooth device.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Tucano website. Keep your proof of purchase for warranty claims.

For further assistance, contact Tucano customer service.