

Manuals.plus /

› Nikai /

› Nikai 32-inch HD LED TV NTV3200LED7-FL User Manual

## Nikai NTV3200LED7-FL

# Nikai 32-inch HD LED TV User Manual

Model: NTV3200LED7-FL

Brand: Nikai

## 1. INTRODUCTION

Thank you for purchasing the Nikai 32-inch HD LED TV, model NTV3200LED7-FL. This manual provides essential information for setting up, operating, and maintaining your television. Please read it thoroughly before use and keep it for future reference.

This 32-inch HD LED TV features a 1366 x 768 resolution, offering clear visuals. It includes multiple connectivity options such as HDMI, USB, VGA, and an RF antenna input. Enjoy UHB film playback and connect your headphones via the 3.5mm audio output.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Power Supply:** Use only the specified power supply. Ensure the voltage matches your local power grid.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow to prevent overheating.
- **Liquids:** Keep the TV away from water, moisture, and any liquid spills. Do not place objects filled with liquids on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Avoid liquid cleaners or aerosol sprays.
- **Placement:** Place the TV on a stable, level surface. If wall-mounting, ensure the wall mount is securely installed and can support the TV's weight.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.
- **Servicing:** Do not attempt to service the TV yourself. Refer all servicing to qualified personnel.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Nikai 32-inch HD LED TV
- Remote Control
- TV Stand (2 pieces)
- Wall Mount Bracket
- Power Cable
- User Manual (this document)

*Note: Batteries for the remote control (AA size) are not included.*

## 4. SETUP

---

### 4.1 Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or servicing.

### 4.2 Stand Installation

If placing the TV on a table, attach the included stand pieces to the bottom of the TV using the provided screws. Ensure they are securely fastened.

### 4.3 Wall Mounting

The TV supports VESA mounting standard 100 x 100 mm. A wall mount bracket is included. For detailed wall mounting instructions, refer to the separate wall mount guide or consult a professional installer. Ensure the wall can support the TV's weight (5.3 kg) and the bracket.

### 4.4 Power Connection

Connect the power cable to the TV's power input and then to a suitable wall outlet (AC 100-240V, 50-60Hz).

### 4.5 Initial Power On

Press the power button on the remote control or the TV to turn it on. Follow the on-screen prompts for initial setup, including language selection and channel scanning.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power On/Off

Press the **POWER** button on the remote control to turn the TV on or off.

### 5.2 Input Source Selection

Press the **SOURCE** button on the remote control to cycle through available input sources (HDMI1, HDMI2, AV, VGA, USB, TV Tuner).

### 5.3 Menu Navigation

Press the **MENU** button to access the main menu. Use the arrow keys (**UP/DOWN/LEFT/RIGHT**) to navigate and **ENTER** to confirm selections. Common menu options include:

- **Picture:** Adjust brightness, contrast, color, sharpness, picture mode (e.g., Personal, Standard, Dynamic).

- **Sound:** Adjust volume, bass, treble, sound mode.
- **Channel:** Scan for channels, edit channels.
- **Time:** Set sleep timer, clock.
- **Setup:** Language, parental controls, factory reset.

## 5.4 Channel Tuning

In the **Channel** menu, select "Auto Scan" to automatically search and store available channels from the RF antenna input.

## 5.5 Media Playback (USB)

Insert a USB drive into the USB port. Select the USB input source. The TV will display a media browser, allowing you to select and play supported video (UHD film playback), audio, or image files.

## 6. CONNECTIONS

---

The Nikai NTV3200LED7-FL TV offers various ports for connecting external devices:



Rear view of the TV with ports including HDMI, USB, VGA, and RF antenna.



Side view of the TV, highlighting accessible ports.

- **HDMI Ports (x2):** Connect high-definition devices such as Blu-ray players, gaming consoles, or set-top boxes.
- **USB Ports (x2):** Connect USB storage devices for media playback (photos, music, videos).
- **VGA Input:** Connect a computer or laptop.
- **RF Antenna Input:** Connect an antenna for receiving broadcast television signals.
- **AV Input (Composite):** Connect older devices using RCA cables (yellow for video, red/white for audio).
- **3.5mm Headphone Jack:** Connect headphones for private listening.

## 7. REMOTE CONTROL

---

The included remote control allows you to operate all functions of your TV. Insert two AA batteries (not included) into the battery compartment, ensuring correct polarity.



Nikai TV Remote Control

Key functions include:

- **Power Button:** Turns the TV on or off.
- **Number Buttons:** Direct channel selection.
- **Volume Up/Down:** Adjusts the volume level.
- **Channel Up/Down:** Changes channels sequentially.
- **Source Button:** Selects input source.
- **Menu Button:** Accesses the main menu.
- **Navigation (Arrow) Buttons:** Moves cursor in menus.
- **Enter Button:** Confirms selections.
- **Exit Button:** Exits menus.
- **Sleep Timer:** Sets a timer for the TV to turn off automatically.
- **Child Lock:** Activates parental control features.

## 8. MAINTENANCE

---

### 8.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Do not spray liquid directly onto the screen.

### 8.2 Cleaning the Cabinet

Wipe the TV cabinet with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.

### 8.3 Storage

If storing the TV for an extended period, unplug it and cover it to protect it from dust. Store in a cool, dry place.

## 9. TROUBLESHOOTING

---

Before contacting support, try the following solutions for common issues:

Problem	Possible Solution
No power	Check if the power cable is securely connected to the TV and the wall outlet. Ensure the outlet is working. Press the power button on the remote or TV.
No picture, but sound is present	Check the input source. Ensure the external device (e.g., DVD player) is turned on and connected correctly.
No sound, but picture is present	Check the volume level. Ensure the TV is not muted. Check audio cables if using external speakers.
Remote control not working	Check and replace batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor picture quality	Adjust picture settings (brightness, contrast, sharpness). Check antenna connection for broadcast TV. Ensure the source device is outputting a high-quality signal.

## 10. SPECIFICATIONS

---

Here are the detailed specifications for the Nikai 32-inch HD LED TV NTV3200LED7-FL:

Feature	Detail
Brand	Nikai
Model Name	NE32LED
Model Number	NTV3272LED9
Year of Manufacture	2024
Screen Size	32 Inches

Feature	Detail
Display Technology	LED
Resolution	1080 Pixels (HD Ready 1366 x 768)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Image Contrast Ratio	1200:1
Maximum Screen Brightness	230 cd/m <sup>2</sup>
Viewing Angle	178 Degrees
Response Time	8 Milliseconds
Screen Backlight Technology	LED (Edge-lit, Adjustable)
HDR Format Support	HDR10+
Image Quality Enhancement Technology	HDR10+, Dolby Vision
Connectivity Technology	HDMI, USB
Hardware Interface	HDMI, USB
Total HDMI Ports	2
Total USB Ports	2 (USB 2.0)
Audio Output Mode	Stereo
Speaker Description	16 Watt
Maximum Speaker Output Power	16 Watt
Surround Sound Channel Configuration	2.1
Integrated Surround Sound Format	Possible 2.1 channel PCM
Wattage	16 Watt
Line Voltage	AC 100-240 Volts, 50-60 Hz
Power Efficiency	Reduced power consumption for energy efficiency
Wireless Communication Technology	Wi-Fi
Supported Internet Services	Netflix, YouTube
Screen Mirroring Technology	Possible Apple AirPlay, Google Cast (Chromecast)
Control Method	Remote
Remote Control Technology	Bluetooth
Remote Control Battery Size Required	AA
Remote Battery Quantity Required	1

Feature	Detail
Product Dimensions (Depth x Width x Height)	83 x 177 x 59 cm
Item Weight	5.3 Kilograms
Color	Black
Mounting Type	Tabletop
VESA Mounting Standard	100 x 100 mm
Parental Control Technology	Built-in device controls
Water Resistance Level	Not Water Resistant
Memory Storage Capacity	8 Gigabytes

## 11. WARRANTY AND SUPPORT

This product comes with a **2-year manufacturer's warranty** from the date of purchase. For warranty claims, technical support, or service inquiries, please contact the manufacturer or its authorized service agent. You may also contact Amazon for further details regarding your purchase and warranty support.

For additional assistance, refer to the official product demonstration video:

Your browser does not support the video tag.

Official product demonstration video for the Nikai 32-inch HD LED TV, highlighting key features and connectivity.