

## ONN 43235-31565

# ONN Streaming Device TV Mount

Model: 43235-31565

## INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your ONN Streaming Device TV Mount. This mount is designed to securely hold streaming devices on top of flat-screen televisions, optimizing remote control aiming and assisting with cable organization.

## SAFETY INFORMATION

- Ensure the television is stable and securely placed before installing the mount.
- Do not overload the mount. It is designed for lightweight streaming devices.
- Keep small parts away from children to prevent choking hazards.
- Verify that the mount is properly seated and stable on the television before placing a device on it.

## PACKAGE CONTENTS

Please check the package for the following items:

- ONN Streaming Device TV Mount (1 unit)

If any items are missing or damaged, please contact customer support.

## SETUP AND INSTALLATION

The ONN Streaming Device TV Mount offers a simple, tool-free installation process.

1. **Positioning the Mount:** Carefully place the ONN Streaming Device TV Mount on top of your flat-screen television. The front lip of the mount should rest against the front edge of the TV, and the adjustable rear arm should extend down the back of the TV.



Image: The ONN Streaming Device TV Mount positioned on the upper edge of a television, showing its adjustable design.

2. **Adjusting for Stability:** Gently press down on the top platform of the mount. The rear arm will pivot and press against the back of your television, securing the mount in place. The protective rubber on the contact points prevents scratches to your TV.
3. **Placing Your Device:** Once the mount is stable, place your streaming device (e.g., Apple TV, Roku) onto the top platform. Ensure the device is centered and stable.
4. **Cable Management:** Utilize the integrated cable management features to route your device's power and HDMI cables neatly behind the television, reducing clutter.

The installation process typically takes less than 10 seconds and requires no tools.

## OPERATING INSTRUCTIONS

---

After installation, the mount functions as a stable platform for your streaming device. Ensure your device is placed securely on the mount. The elevated position helps maintain a clear line of sight for remote controls, improving responsiveness.

## MAINTENANCE

---

To maintain your ONN Streaming Device TV Mount:

- **Cleaning:** Wipe the mount with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish or rubber components.
- **Inspection:** Periodically check that the mount remains securely attached to your television and that the rubber padding is intact.

## TROUBLESHOOTING

---

**Issue: Mount does not fit securely on the TV.**

**Solution:** Ensure your television is a flat-screen model. The mount is designed to grip the top edge. Adjust the rear arm by pressing down on the top platform to ensure it clamps firmly against the back of the TV. If your TV's thickness is outside the mount's adjustable range, it may not be compatible.

**Issue: Streaming device does not fit on the mount.**

**Solution:** This mount is designed for compact streaming devices such as Apple TV or Roku. Larger streaming boxes may not fit on the platform. Verify the dimensions of your device against the mount's platform size.

**Issue: Remote control signal is still poor.**

**Solution:** Ensure the streaming device's IR receiver (if applicable) is not obstructed by the mount or other objects. The mount's design aims to elevate the device for better line of sight, but external factors can still interfere.

## SPECIFICATIONS

Brand	ONN
Model Number	43235-31565
Product Dimensions	6 x 2 x 5 inches
Item Weight	5.4 ounces
Material	Rubber (contact points)
Color	Black
Mounting Type	TV Top Mount
Movement Type	Fixed
Compatible Devices	Streaming devices (e.g., Apple TV, Roku) on flat-screen televisions
UPC	681131131971

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for warranty claims.