

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lenovo](#) /

› [Lenovo Flex 5 15.6 inch 2-in-1 Laptop User Manual \(Model 81CA000CUS\)](#)

Lenovo 81CA000CUS

Lenovo Flex 5 15.6 inch 2-in-1 Touchscreen Laptop User Manual

Model: 81CA000CUS

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo Flex 5 15.6 inch 2-in-1 Touchscreen Laptop. This device, model 81CA000CUS, combines the power of a traditional laptop with the versatility of a tablet, featuring an Intel Core i7-8550U processor, 16GB DDR4 RAM, a 512GB PCIe Solid State Drive, a 15.6-inch Full HD touchscreen display, and NVIDIA GeForce MX130 graphics. An active stylus is included for enhanced interaction.



Image: The Lenovo Flex 5 15.6 inch 2-in-1 Touchscreen Laptop, illustrating its convertible design.

SETUP

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the following items are present:

- Lenovo Flex 5 2-in-1 Touchscreen Laptop
- Active Stylus
- Power Adapter and Cable
- Documentation (this manual, warranty information)

2. Connecting the Power Adapter

Connect the power adapter to the laptop's power input port and then plug it into a wall outlet. It is recommended to fully charge the battery before initial use.

3. Initial Power-On and Windows Setup

Press the power button located on the side or keyboard deck. The laptop will guide you through the initial Windows 10 Home setup process. Follow the on-screen instructions to configure language, region, network settings, and user accounts.

4. Active Stylus Pairing

The active stylus may require initial pairing via Bluetooth. Refer to the Windows settings for Bluetooth devices to connect the stylus if it does not automatically pair upon first use.

OPERATING INSTRUCTIONS

1. Power On/Off and Sleep Mode

- **Power On:** Press the power button.
- **Power Off:** Click the Start button, then Power > Shut down.
- **Sleep Mode:** Close the lid or click the Start button, then Power > Sleep.

2. Using the 2-in-1 Functionality

The Flex 5 can be used in multiple modes:

- **Laptop Mode:** Standard laptop configuration for typing and productivity.
- **Tent Mode:** Fold the display back to stand the laptop in a "tent" shape, ideal for presentations or watching videos.
- **Stand Mode:** Fold the display back with the keyboard facing down, providing a stable stand for touchscreen interaction.
- **Tablet Mode:** Fold the display completely back against the base, converting the device into a tablet for touch-based applications.

3. Keyboard, Touchpad, and Touchscreen

- **Backlit Keyboard:** Adjust backlight intensity using function keys.
- **Touchpad:** Supports multi-touch gestures for navigation.
- **Touchscreen:** Use finger gestures for navigation, zooming, and interaction.

4. Ports and Connections

The laptop features various ports for connecting peripherals:

- 1x USB 3.0 Type C port
- 2x USB 3.0 ports
- 1x HDMI port for external displays
- 1x Media Card Reader (for SD cards)
- 1x Combination Audio Jack (for headphones/microphone)

5. Wireless Connectivity

The device supports 802.11 Wireless-AC for high-speed internet access and Bluetooth 4.1 for connecting wireless accessories like headphones or mice.

6. Fingerprint Reader

Utilize the integrated fingerprint reader for secure and convenient login via Windows Hello.

MAINTENANCE

1. Cleaning the Device

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Chassis:** Wipe with a soft, dry cloth. For stubborn marks, use a slightly damp cloth.
- **Keyboard:** Use compressed air to remove dust and debris from between keys.

2. Battery Care

To prolong battery life, avoid extreme temperatures and do not leave the laptop fully charged or fully discharged for extended periods. Periodically allow the battery to discharge to about 20% before recharging.

3. Software Updates

Regularly check for and install Windows updates and driver updates from the Lenovo support website to ensure optimal performance and security.

4. Storage Management

Periodically review and delete unnecessary files to maintain sufficient free space on the 512GB PCIe Solid State Drive for optimal system responsiveness.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Lenovo Flex 5 laptop.

1. Laptop Does Not Power On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Verify the power outlet is functional by plugging in another device.
- Try holding the power button for 10-15 seconds to perform a hard reset.

2. Display Issues (No Image, Flickering)

- Adjust screen brightness using the function keys.
- Connect an external monitor via HDMI to check if the issue is with the laptop's internal display.
- Restart the laptop.

3. Wi-Fi or Bluetooth Connectivity Problems

- Ensure Wi-Fi and Bluetooth are enabled in Windows settings.
- Restart your router/modem.
- Update wireless drivers from the Lenovo support website.

4. Active Stylus Not Responding

- Check the stylus battery.
- Ensure the stylus is properly paired via Bluetooth in Windows settings.
- Restart the laptop.

5. System Slowdown

- Close unnecessary applications running in the background.
- Check for and install any pending Windows updates.
- Run a disk cleanup.
- Scan for malware.

SPECIFICATIONS

Feature	Detail
Model Name	Lenovo Flex 5 15.6 inch
Model Number	81CA000CUS
Processor	Intel Core i7-8550U (1.8GHz)
RAM	16GB DDR4 2400MHz
Storage	512GB PCIe Solid State Drive (SSD)
Display	15.6" Touchscreen LED-backlit IPS FHD (1920 x 1080)
Graphics	2GB NVIDIA GeForce MX130
Operating System	Microsoft Windows 10 Home (64 bit)
Wireless Connectivity	802.11 Wireless-AC, Bluetooth 4.1
Ports	1x USB 3.0 Type C, 2x USB 3.0, 1x HDMI, 1x Media Card Reader, 1x Combination Audio Jack
Keyboard	Backlit Keyboard with Fingerprint Reader
Dimensions (LxWxH)	12.9 x 9 x 0.8 inches
Weight	6.55 pounds
Battery	1 Lithium Ion battery (included)

WARRANTY AND SUPPORT

Your Lenovo Flex 5 laptop is covered by a standard limited warranty. For detailed warranty terms and conditions, please refer to the warranty document included with your product or visit the official Lenovo support website. For technical assistance, driver downloads, or service requests, please visit the Lenovo Support website at support.lenovo.com. Have your product's serial number ready when contacting support.