

## De'Longhi PM1400N

# De'Longhi Simac Pastamatic 1400 PM1400N Magnum Pro Mixing Bowl User Manual

Model: PM1400N

[Product Overview](#)[Compatibility](#)[Setup](#)[Operating Instructions](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Warranty & Support](#)

## 1. PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient use of your De'Longhi Simac Pastamatic 1400 PM1400N Magnum Pro Mixing Bowl. This original Simac mixing bowl is designed as a replacement or accessory for compatible Pastamatic kneading machines. It has a capacity suitable for processing up to 1.4 kg of ingredients.



Image 1.1: The Simac Pastamatic 1400 PM1400N Magnum Pro Mixing Bowl. This image shows the stainless steel mixing bowl, designed for use with compatible Pastamatic kneading machines.

## 2. COMPATIBILITY

This mixing bowl is compatible with the following Simac Pastamatic models. Please verify your machine's model number before use to ensure proper fit and function.

- **Article Number:** 8000030, **Name:** Pastamatic 1400, **Version:** EU
- **Code:** 80000305, **Name:** PM 1400N Pastamatic Magnum Pro, **Version:** EU
- **Code:** 1-07520000, **Name:** PM 1400 0N, **Version:** IT
- **Article Number:** 0201140000, **Name:** PM 1400N, **Version:** INT

If your specific model is not listed, it is recommended to contact customer support for compatibility confirmation before attempting to use the mixing bowl.

## 3. SETUP

Before first use, ensure the mixing bowl is clean. Refer to the "Maintenance and Cleaning" section for proper cleaning instructions.

1. Ensure your Simac Pastamatic machine is unplugged and turned off.
2. Carefully place the mixing bowl onto the designated base of your Pastamatic machine.
3. Rotate the bowl slightly until it securely locks into position. Ensure there is no wobbling or looseness.
4. Once the mixing bowl is securely attached, you may proceed with adding ingredients and operating the machine according to your Pastamatic machine's main instruction manual.

*Always consult your main Pastamatic machine manual for specific instructions on attaching accessories and safe operation.*

## 4. OPERATING INSTRUCTIONS

The mixing bowl functions as a container for ingredients during the kneading process. Its operation is directly linked to the functionality of your Simac Pastamatic machine.

- After securely attaching the mixing bowl (as per the Setup section), add your desired ingredients for pasta or dough preparation.
- Ensure that the total weight of ingredients does not exceed the bowl's capacity of 1.4 kg.
- Follow the operating instructions provided in your main Simac Pastamatic machine manual for selecting programs, speeds, and processing times.
- Always supervise the machine during operation.
- Do not attempt to remove the mixing bowl while the machine is running.

**Safety Note:** Always ensure the machine is stable and on a flat surface during operation. Keep hands and utensils away from moving parts.

## 5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your mixing bowl.

### **Cleaning Instructions:**

- **Do not wash in a dishwasher.** The mixing bowl is not suitable for dishwasher cleaning.
- After each use, unplug the Pastamatic machine and remove the mixing bowl.
- Wash the mixing bowl by hand using warm water and a mild dish soap.
- Use a soft sponge or cloth to clean the interior and exterior surfaces. Avoid abrasive cleaners or scouring pads, which can scratch the material.
- Rinse thoroughly with clean water to remove all soap residue.
- Dry the mixing bowl completely with a soft cloth before storing or reattaching to the machine.

### **Storage:**

Store the clean and dry mixing bowl in a safe place, away from direct sunlight and extreme temperatures, to prevent damage.

## **6. TROUBLESHOOTING**

This section addresses common issues related to the mixing bowl. For issues related to the Pastamatic machine's motor or electrical components, refer to the machine's main manual.

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Mixing bowl does not fit or is loose.	Incorrect model or improper attachment.	Verify compatibility (Section 2). Ensure the bowl is correctly aligned and rotated until it locks into place (Section 3).
Food residue is difficult to remove.	Dried-on food or improper cleaning method.	Soak the bowl in warm, soapy water for a few minutes before cleaning. Use a non-abrasive sponge. Do not use a dishwasher (Section 5).
Scratches on the bowl surface.	Use of abrasive cleaning tools or harsh chemicals.	Always use soft sponges and mild detergents. Avoid metal scouring pads or harsh chemical cleaners (Section 5).

## **7. SPECIFICATIONS**

<b>Feature</b>	<b>Detail</b>
<b>Model Number:</b>	PM1400N
<b>Brand:</b>	De'Longhi (Simac Pastamatic)
<b>Item Weight:</b>	1.4 kg (1.4 Kilogram)
<b>Material:</b>	Stainless Steel
<b>Color:</b>	Steel

Feature	Detail
<b>Dishwasher Safe:</b>	No
<b>Included Components:</b>	Mixing bowl
<b>Operation Mode:</b>	Manual
<b>ASIN:</b>	B076YZ39F7
<b>First Available Date:</b>	21 February 2020

## 8. WARRANTY AND SUPPORT

---

Specific warranty information for this mixing bowl is not available in the provided product data. For warranty details, technical support, or service inquiries, please refer to the documentation included with your original Simac Pastamatic machine or contact De'Longhi customer service directly.

You can typically find contact information on the official De'Longhi website or in the main product manual.